

R-410A

Engineering Data

Split Type Air Conditioners

- Heat Pump -

FFQ-Q Series











Split Type Air Conditioners FFQ-Q Series

Heat Pump

FFQ09Q2VJU RX09QMVJU FFQ12Q2VJU RX12QMVJU FFQ15Q2VJU RX15QMVJU

1.	Pow	er Supply	3
2.	Fund	ctions	4
3.	Spe	cifications	5
	•	ensions	
	4.1	Indoor Unit	
	4.2	Outdoor Unit	
5.	Wirir	ng Diagrams	11
	5.1	Indoor Unit	
	5.2	Outdoor Unit	12
6.	Pipir	ng Diagrams	13
	6.1	Indoor Unit	13
	6.2	Outdoor Unit	14
7.	Cap	acity Tables	15
	7.1	Capacity Correction Factor by the Length of Refrigerant Piping	
		(Reference)	24
8.	Ope	ration Limit	25
9.	Soul	nd Level	26
	9.1	Measuring Location	
	9.2	Indoor Unit	
	9.3	Outdoor Unit	28
10	.Elec	tric Characteristics	29
11	.Insta	allation Manual	
		Indoor Unit	
		<byfq60b3w1> Decoration Panel</byfq60b3w1>	
		S <byfq60c2w1w(s)> Decoration Panel</byfq60c2w1w(s)>	
		<brc1e73> Wired Remote Controller</brc1e73>	
		S <brc082a41w, brc082a42w(s)=""> Wireless Remote Controller</brc082a41w,>	
		Outdoor Unit	
12		ration Manual	
		With <brc1e73> Wired Remote Controller</brc1e73>	103
	12.2	With <brc082a41w, brc082a42w(s)=""></brc082a41w,>	450
		Wireless Remote Controller	153

3.	Option List	162
	13.1 Indoor Unit	162
	13.2 Outdoor Unit	162
	13.3 <krp1c75> Adaptor for Wiring</krp1c75>	163
	13.4 <krp4a74> Wiring Adaptor for Electrical Appendices</krp4a74>	164
	13.5 <krp1ba101> Installation Box for Adaptor PCB</krp1ba101>	165
	13.6 <krcs01-4b> Remote Sensor</krcs01-4b>	167
	13.7 <bryq60a2w(s)> Sensor Kit</bryq60a2w(s)>	170
	13.8 < KDBQ44BA60A > Panel Spacer	
	13.9 <kddq44xa60> Fresh Air Intake Kit</kddq44xa60>	
	13.10 <kpw937e4> Air Direction Adjustment Grille</kpw937e4>	
	13.11 <kpw063a4> Air Direction Adjustment Grille</kpw063a4>	178
	13.12 <ftdbhms, ftdbhml,="" keh063a4e="" keh067a41e,=""></ftdbhms,>	
	Drain Pan Heater	180
	13.13 <kps067a41> Snow Hood (Intake Side Plate)</kps067a41>	186
	13.14 <kps067a42> Snow Hood (Intake Rear Plate)</kps067a42>	188
	13.15 <kps067a44> Snow Hood (Outlet)</kps067a44>	190
	13.16 <kps063a41> Snow Hood (Intake Side Plate)</kps063a41>	192
	13.17 <kps063a44> Snow Hood (Intake Rear Plate)</kps063a44>	194
	13.18 <kps063a47> Snow Hood (Outlet)</kps063a47>	196

- Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
 If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided and choose an outdoor unit with anti-corrosion treatment.

EDUS091617 Power Supply

1. Power Supply

Indoor Unit	Outdoor Unit	Power Supply				
FFQ09Q2VJU	RX09QMVJU	1 phase, 208 - 230 V, 60 Hz				
FFQ12Q2VJU	RX12QMVJU					
FFQ15Q2VJU	RX15QMVJU					

Note: Power Supply Intake; Outdoor Unit

Functions EDUS091617

2. Functions

Category	Functions	FFQ09/12/15Q2VJU RX09/12/15QMVJU with BYFQ60B3W1	FFQ09/12/15Q2VJU RX09/12/15QMVJU with BYFQ60C2W1W(S)	Category	Functions	FFQ09/12/15Q2VJU RX09/12/15QMVJU with BYFQ60B3W1	FFQ09/12/15Q2VJU RX09/12/15QMVJU with BYFQ60C2W1W(S)
Basic	Inverter (with inverter power control)	•	•	Health &	Auto cleaning filter	_	
Functions	Operation limit for cooling	- .		Cleanliness	Air-purifying filter	_	_
	Operation limit for heating	Refer t	o P. 25		Photocatalytic deodorizing filter	_	_
	PAM control	_	_		Air-purifying filter with photocatalytic		
	Standby electricity saving	_	_		deodorizing function	_	_
Compressor	Oval scroll compressor	_	_		Titanium apatite photocatalytic		
	Swing compressor	•	•		air-purifying filter (option)	_	_
	Rotary compressor	_	_		Longlife filter	•	•
	Reluctance DC motor	•	•		Air filter	•	•
Comfortable	Power-airflow flap (horizontal blade)	_	_		Filter cleaning indicator	•	•
Airflow	Power-airflow dual flaps	_	_		Wipe-clean flat panel	_	_
	Power-airflow diffuser	_	_		Washable grille	•	•
	Wide-angle louvers (vertical blades)	_	_		MOLD PROOF operation	_	_
	Auto-swing (up and down)	•	•		Good-sleep cooling operation	_	_
	Auto-swing (right and left)	_	_	Timer	Schedule TIMER operation	●★1	●★1
	Individual flap control	_	●★1		72-hour ON/OFF TIMER	•★2	•★2
	3-D airflow	_	_		NIGHT SET mode	_	_
	COMFORT AIRFLOW operation		_		Off Timer (power off forget prevention)	●★1	●★1
Comfort	Auto fan speed	●★1	●★1	Worry Free	Auto-restart (after power failure)	•	•
Control	Indoor unit quiet operation	•	•	(Reliability & Durability)	Self-diagnosis (R/C, LED)	•	•
	NIGHT QUIET mode (automatic)	_	_	2 0. 00,	Wiring error check function	_	_
	OUTDOOR UNIT QUIET operation (manual)	 _ •*1			Anti-corrosion treatment of outdoor heat exchanger	_	_
	Presence and floor sensor (option)			Flexibility	Multi-split/split type compatible indoor		
	Hot-start function	•	•		unit		
	Draft prevention	•	•		H/P, C/O compatible indoor unit	_	_
	Automatic defrosting	•	•		Flexible power supply correspondence	_	_
Operation	Automatic operation Program dry function	•	•		Chargeless	32.8 ft (10 m)	
	Fan only	•	•		Either side drain (right or left)		
	Setback function	●★1	● ★1		Power selection	_	_
Lifestyle Convenience	New POWERFUL operation (non-inverter)	—	_		Low outdoor temperature cooling operation (-20°C) (-4°F)	•★3	•★3
	Inverter POWERFUL operation	_	_		°F/°C changeover R/C temperature		
	Priority-room setting	_	_		display (factory setting: °F)	●★1	●★1
	COOL/HEAT mode lock	_	_	Remote	Remote control adaptor		
	HOME LEAVE operation	<u> </u>	_	Control	(normal open pulse contact) (option)	-	-
	ECONO operation	 	_		Remote control adaptor		
	Indoor unit ON/OFF button		_		(normal open contact) (option)		_
	Signal receiving sign	•★2	•★2		DIII-NET compatible (adaptor) (option)		_
	<u> </u>	* 4	★4	Remote Controller	Wireless (option)	•	•
	R/C with back light	●★1	●★1	20	Wired (option)	•	•

Note: ●: Available

—: Not available

★1: With wired remote controller

★2: With wireless remote controller ★3: With air direction adjustment grille (option)

★4: Receiving sound only

EDUS091617 **Specifications**

3. Specifications

60 Hz, 208 - 230 V

Coping		Indoor Unit			Q2VJU	FFQ12Q2VJU					
County Section County	Model	Outdoor Unit									
Related (Rint - Maxx Salar Salar	Canacity		1			•					
Power Force surregion Power Force surregion W 700 (280 - 1.050) 641 (250 - 1.150) 864 (280 - 1.410) 968 (250 - 1.450)	Rated (Min. ~ Max.)		Btu/h	9,100 (4,600 ~ 11,000)	10,000 (4,600 ~ 14,000)	10,800 (4,600 ~ 13,300)	13,500 (4,600 ~ 16,800)				
Risked (Min Max.) W		d)	Α	3.64 - 3.29	3.43 - 3.10	4.61 - 4.17	4.96 - 4.49				
SEER HSPF	Power Consumption Rated (Min. ~ Max.)		W	700 (280 ~ 1,050)	641 (250 ~ 1,150)	864 (280 ~ 1,410)	985 (250 ~ 1,450)				
COP (Flarker) WW	Power Factor (Rated)		%								
EBR (Raider)				20.90		20.20					
Paging Connections	. ,			_	4.58	_	4.02				
Piping Connections	EER (Rated)				_						
Part	Dining Organizations						(1)				
Heat Instalation	Piping Connections		\ /								
Max. Internut Piprig Length ft (m) 65-58 (20) 65-58 (20) Max. Internut Height Difference ft (m) 49-14 (15) 49-14 (15) Chargales ft (m) 32-13 (610) 0.21 (20) Particle State (19) 0.21 (20) 0.21 (20) Decoration Panel (1) Model BYFC00638WI BYFC0063WI Decoration Panel (1) Color White White White Decoration Panel (2) Model BYFC00638WI BYFC0063WI Decoration Panel (2) Model BYFC00638WI BYFC0063WI White (1) White (1) White (1) BYFC0063WI Decoration Panel (2) Model BYFC0063WIW BYFC00C2WIS BYFC0063WIW BYFC00C2WIS Decoration Panel (2) Model BYFC0063WIW BYFC00C2WIS BYFC00C2WIW BYFC00C2WIW BYFC00C2WIS Decoration Panel (2) Weight (Mass) Libe (kg) BYFC00C2WIW BYFC00C2WIS BYFC00C2WIW BYF	Heat Inculation	Drain	iri. (mim)								
Max. Interunit Height Difference		anath	ft (m)	•	•						
Chargeless			. ,		` ,		,				
Amount of Additional Charge of Refrigerant 0.21 (20) 0.21 (20) 0.21 (20) Refrigerant Ref		illerence	. ,		` ,		,				
Refrigerant Gym World FR0302VJU FR0302VJU FR0302VJU FR0302VJU FR0302VJU		harne of	` '		. ,		` '				
Decoration Panel (1)	Refrigerant C	90 01			` '		` '				
Decoration Panel (1)	Indoor Unit										
Decoration Panel (1) Dimensions (H × W × D) Dimensions (H × W × D) Velight (Mass) Lbs (kg) S (2.7) S (
Decoration Panel (2)	Decoration Panel (1)										
Model	Dodoration (1)		,		,		, ,				
Color		. ,	Lbs (kg)								
Decoration Panel Decoration											
Differsions (F1 x W x D) 1-13/16 x 24-7/16 x 42-7/16	Decoration Panel (2)										
H					, ,		,				
Airflow Rate		. ,	Lbs (kg)		,	1 ,					
Marriade Marriade	A: 0 D .		cfm	` ,	` '	` '	` '				
Type	Airtiow Hate			, ,	` '	` '	` '				
Speed Steps 3 Steps 6				, ,	, ,	. ,	. ,				
Running Current (Rated)	Fan		Stens								
Power Consumption (Rated) W 23 23 27 27	Running Current (Rate				•	·					
Power Factor (Rated) % 48.1 - 47.6 48.1 - 47.6 48.1 - 48.9 48.1 - 48.9		,									
Temperature Control Microcomputer Microc											
Dimensions (H × W × D)	Temperature Control			Microcomp	uter Control	Microcomp	uter Control				
Packaged Dimensions (H × W × D) in. (mm) 11 × 27 × 23-1/2 (280 × 686 × 597) 11 × 27 × 23-1/2 (280 × 686 × 597) 36 (16) 36 (Dimensions (H × W × D	0)	in. (mm)								
Circle Compressor Compres	Packaged Dimensions	$(H \times W \times D)$	in. (mm)								
Sound Pressure Level H / M / L dB(A) 38 / 35 / 29 38 / 35 / 29 39 / 36 / 30 39 / 36 / 30	Weight		Lbs (kg)	36 ((16)	36	(16)				
Outdoor Unit RX09QMVJU RX12QMVJU Casing Color Type Hermetically Sealed Swing Type Hermetically Sealed Swing Type Compressor Model 17/223AUXD Hermetically Sealed Swing Type Model 17/223AUXD 19/223AUXD Refrigerant Oil Type FVC50K F	Gross Weight		Lbs (kg)	40 ((18)	40	(18)				
Vory White Vor		H/M/L	dB(A)								
Type						· · · · · · · · · · · · · · · · · · ·					
Model	Casing Color	-				,					
Motor Output W 790 790 790					0 71						
Type	Compressor		14/								
Refrigerant Oil Charge oz (L) 12.68 (0.375) 12.68 (0.375) 12.68 (0.375) 12.68 (0.275) 12.68 (0.275)			VV								
Type	Refrigerant Oil		07/11								
Charge Lbs (kg) 2.09 (0.95) 2.09 (0.95) 2.09 (0.95)			02 (L)								
Airflow Rate H (m³/min) 985 (27.9) 992 (28.1) 1,104 (31.27) 992 (28.1) Fan Type Propeller Propeller Running Current (Rated) A 3.41 - 3.08 3.20 - 2.89 4.34 - 3.93 4.69 - 4.25 Power Consumption (Rated) W 677 618 837 958 Power Factor (Rated) % 95.4 - 95.6 92.8 - 93.0 92.7 - 92.6 98.2 - 98.0 Starting Current A 7.5 7.5 Dimensions (H × W × D) in. (mm) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) Packaged Dimensions (H × W × D) in. (mm) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49	Refrigerant		Lbs (ka)								
Fam Type Propeller Pro	Airflow D-4-		` 0,		,		i ,				
Running Current (Rated) A 3.41 - 3.08 3.20 - 2.89 4.34 - 3.93 4.69 - 4.25 Power Consumption (Rated) W 677 618 837 958 Power Factor (Rated) % 95.4 - 95.6 92.8 - 93.0 92.7 - 92.6 98.2 - 98.0 Starting Current A 7.5				* *	` ′	, , ,	` ′				
Power Consumption (Rated) W 677 618 837 958 Power Factor (Rated) % 95.4 - 95.6 92.8 - 93.0 92.7 - 92.6 98.2 - 98.0 Starting Current A 7.5 7.5 Dimensions (H × W × D) in. (mm) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) Packaged Dimensions (H × W × D) in. (mm) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51			Α								
Power Factor (Rated) % 95.4 - 95.6 92.8 - 93.0 92.7 - 92.6 98.2 - 98.0 Starting Current A 7.5 7.5 Dimensions (H × W × D) in. (mm) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) Packaged Dimensions (H × W × D) in. (mm) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51		,									
Starting Current A 7.5 7.5 Dimensions (H × W × D) in. (mm) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) Packaged Dimensions (H × W × D) in. (mm) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51	Power Factor (Rated)	,									
Dimensions (H × W × D) in. (mm) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) 21-5/8 × 26-9/16 × 11-3/16 (550 × 675 × 284) Packaged Dimensions (H × W × D) in. (mm) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51	Starting Current										
Packaged Dimensions (H × W × D) in. (mm) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) 24-3/4 × 32-11/16 × 16 (629 × 830 × 407) Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51	ĕ										
Weight Lbs (kg) 60 (27) 60 (27) Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51	Packaged Dimensions (H × W × D)				,						
Gross Weight Lbs (kg) 71 (32) 71 (32) Sound Pressure Level H dB(A) 46 50 49 51	Weight	•			, ,	60	(27)				
Sound Pressure Level H dB(A) 46 50 49 51	Gross Weight										
	Sound Pressure Level	Н		46	50	` '					
	Drawing No.			3D106	6061A	3D10	06062				

Notes:

SL: The Quiet fan level of the airflow rate setting.
 The data are based on the conditions shown in the table below.

Cooling	Indoor; 80.0°FDB (26.7°CDB) / 67.0°FWB (19.4°CWB) Outdoor; 95.0°FDB (35°CDB) / 75°FWB (23.9°CWB)
Heating	Indoor; 70.0°FDB (21.1°CDB) / 60.0°FWB (15.6°CWB) Outdoor; 47°FDB (8.33°CDB) / 43.0°FWB (6.11°CWB)
Piping Length	25 ft (7.5 m)

Conversion Formulae $kcal/h = kW \times 860$ $Btu/h = kW \times 3412$ $cfm = m^3/min \times 35.3$

Specifications EDUS091617

60 Hz, 208 - 230V

Max. Interunt Piprig Length ft (m) \$9-7/16 (30)		Indoor Unit		FFQ15Q2VJU									
Cooling Cool	Model	Outdoor Unit											
Relad (Min - Max.) South Min, (Min, - Max.)	0 "	Outdoor Orint		Cooling	Heating								
Raming Current (filleto)	Capacity Rated (Min. ~ Max.)		Btu/h	14,400 (5,100 ~ 16,200)	16,200 (5,200 ~ 16,300)								
Rated (Min Max.)		d)	Α	5.83 - 5.27	6.23 - 5.63								
Felicit (Inc. May 1963 1963 1963 1963 1963 1963 1964 1963 1964 1963 1964 1965 1964 1965 1964 1965 1964 1965	Power Consumption		W	1 152 (310 ~ 1 640)	1 235 (330 ~ 1 300)								
SEEP HSPF	, ,			, , , , ,									
COP Plate() WW	. ,		%										
EER (Rater) Sturk W 12:50			١٨/٨٨/	20.70									
Decoration Panel (a) Decoration Panel (b) Decoration Panel (c)	. ,			12.50									
Piping Connections	LLIT (Hatou)	Liquid		l l	h 6.4)								
Decoration Panel Color C	Piping Connections		` '	1 3	,								
Max. Interunt Piprig Length ft (m) 98-7/16 (30)	, 0	Drain	in. (mm)	1 11	,								
Max. Internal Height Difference	Heat Insulation			Both Liquid ar	nd Gas Pipes								
Chargeless			ft (m)	98-7/10	6 (30)								
Amount of Additional Charge of Refrigerant Refrigeran	Max. Interunit Height D	ifference	ft (m)	65-5/8	3 (20)								
Refrigerant Ug/m			ft (m)	32-13/1	6 (10)								
Mode	Amount of Additional C	harge of	oz/ft	0.21	(20)								
Decoration Panel (1)			(9/11)										
Decoration Panel (1) Decoration Panel (1) Decoration Panel (2) Decoration Panel (3) Decoration Panel (4) Decoration Panel (5) Decoration Panel (6) Decoration Panel (7) Decoration Panel (8) Decoration Panel	macor onit	Model											
Decoration Panel (1) Dimensions (H × W × D) 2-3/16 × 27-9/16 (55 × 700 × 700)													
Weight (Mass) Lbs (kg) BYFQ60C2WW PSYFC60C2WHS	Decoration Panel (1)		$\times W \times D$)										
Decoration Panel (2) Color White SWPG60C2WW SWPC60C2WW SWPC60C2W SWPC60C2WW SWPC60C2W SWPC60C			,		,								
Decoration Planel (2) Dimensions (H × W × D)		. ,	11 (3)	,	,								
Limension (H × W × L)	D " D 1(0)	Color		White /	Silver								
Arflow Rate	Decoration Panel (2)	Dimensions (H	\times W \times D)	1-13/16 × 24-7/16 × 24-	-7/16 (46 × 620 × 620)								
M		Weight (Mass)	Lbs (kg)	6.2 (/	2.8)								
Marriage Marriage		Н	,	420 (11.9)	441 (12.5)								
L	Airflow Rate	М	(m³/min)	367 (10.4)	385 (10.9)								
Speed Steps Ste		L	(,)	293 (8.3)	307 (8.7)								
Speed Steps Steps 3 steps 3 steps	Fan												
Power Consumption (Rated) W 28				· · · · · · · · · · · · · · · · · · ·									
Power Factor (Pated)													
Temperature Control Microcomputer Control	1 1	Rated)											
Dimensions (H × W × D) in. (mm) 10-1/4 × 22-5/8 × 22-5/8 (260 × 575 × 575) Packaged Dimensions (H × W × D) in. (mm) 11 × 27 × 23-1/2 (280 × 686 × 597) Weight Lbs (kg) 36 (16) Gross Weight Lbs (kg) 40 (18) Sound Pressure Level H / M / L dB(A) 40 / 37 / 31 40 / 37 / 31 Outdoor Unit RX15QMVU Casing Color Now White Early (Model Motor Output W Hermetically Sealed Swing Type Compressor Type FVCSOK Charge oz (L) 2.0 (0.65) Type FVCSOK Charge oz (L) 2.314 (65.53) 1.896 (53.7) Fall (missing Current (Rated) A 5.54	, ,		%										
Packaged Dimensions (H × W × D) in. (mm) 11 × 27 × 23-1/2 (280 × 686 × 597)		3)	in (mana)										
Weight	,	,	. ,	,									
Gross Weight Lbs (kg) 40 (18) Sound Pressure Level H /M / L dB(A) 40 / 37 / 31 40 / 37 / 31 Outdoor Unit RX150MVJU Compressor Type Hermetically Sealed Swing Type Compressor Model 2 YC36PXD Colspan="2">Colspan="2">2 YC36PXD Colspan="2">2 YC36PXD PA YC50K		(IIX W X D)	` '	,	·								
Sound Pressure Level H / M / L dB(A) 40 / 37 / 31 40 / 37 / 31 Outdoor Unit RX15QMVJU Casing Color Nory White Type Hermetically Sealed Swing Type Model 2YC36PXD Motor Output W 1,100 FVC50K Charge oz (L) 22.0 (0.65) Charge Lbs (kg) 2.49 (1.13) Airflow Rate H cfm (m³/min) 2,314 (65.53) 1,896 (53.7) Fan Type Propeller Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464)	•		` 0,	· ·	•								
Outdoor Unit RX15QMVJU Casing Color Iype Hermetically Sealed Swing Type Compressor Model 2YC36PXD Motor Output W 1,100 PVC50K Refrigerant Oil Type PVC50K Refrigerant Type R-410A Charge Lbs (kg) 2.94 (1.13) Airflow Rate H (cfm (m/m/min) 2.314 (65.53) 1,896 (53.7) Fan Type Propeller Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) W 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.05 8.0 Dimensions (H × W × D)<		H/M/I		· ·	•								
Type		,, _	u2(/ i)										
Compressor Model Motor Output W 1,100 Refrigerant Oil Type Type Charge oz (L) FVC50K Refrigerant Type Refrigerant R-410A Airflow Rate H Charge Lbs (kg) 2.49 (1.13) Airflow Rate H Cfm (m³/min) 2,314 (65.53) 1,896 (53.7) Fan Type Propeller Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 50 Sound Pressure Level H dB(A) 50	Casing Color												
Compressor Model Motor Output W 1,100 Refrigerant Oil Type Type Charge oz (L) EVC50K Refrigerant Type Type Type Type Type Type Type Type	-	Туре											
Refrigerant Oil Type	Compressor	Model											
Refrigerant Oil		Motor Output	W	,									
Charge Oz (L) Refrigerant Type R-410A Airflow Rate H Charge Lbs (kg) Cfm (m³/min) C,314 (65.53) 1,896 (53.7) Fan Type Propeller Running Current (Rated) A S.54 - 5.01 S.94 - 5.37 Power Consumption (R±d) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 50 51 Sound Pressure Level H dB(A) 50 51 Constant Constant Constant Charge Constant Charge Constant Charge Constant Charge	Refrigerant Oil												
Heringerant Charge Lbs (kg) 2.49 (1.13) Airflow Rate H cfm (m³/min) 2,314 (65.53) 1,896 (53.7) Fan Type Propeller Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51			oz (L)										
Airflow Rate H Crarge (m³/min) Lbs (kg) 2.49 (1.13) Airflow Rate H (m³/min) 2,314 (65.53) 1,896 (53.7) Fan Type Propeller Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51	Refrigerant												
Fan Type Propeller Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51	g ·	_ <u> </u>		2.49 (1.13)								
Running Current (Rated) A 5.54 - 5.01 5.94 - 5.37 Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51				, , ,	<u> </u>								
Power Consumption (Rated) W 1,124 1,207 Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51													
Power Factor (Rated) % 97.5 - 97.5 97.7 - 97.7 Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51		,											
Starting Current A 8.0 Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51		nateu)		·									
Dimensions (H × W × D) in. (mm) 28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320) Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51													
Packaged Dimensions (H × W × D) in. (mm) 31-7/8 × 41-9/16 × 18-1/4 (810 × 1,056 × 464) Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51))											
Weight Lbs (kg) 97 (44) Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51	,		. ,		,								
Gross Weight Lbs (kg) 115 (52) Sound Pressure Level H dB(A) 50 51	· ,		. ,										
Sound Pressure Level H dB(A) 50 51													
	Drawing No.	1	- (-7										

Notes:

SL: The Quiet fan level of the airflow rate setting.
 The data are based on the conditions shown in the table below.

	Indoor; 80.0°FDB (26.7°CDB) / 67.0°FWB (19.4°CWB) Outdoor; 95.0°FDB (35°CDB) / 75°FWB (23.9°CWB)
Heating	Indoor; 70.0°FDB (21.1°CDB) / 60.0°FWB (15.6°CWB) Outdoor; 47°FDB (8.33°CDB) / 43.0°FWB (6.11°CWB)
Piping Length	25 ft (7.5 m)


Conversion Formulae $\begin{aligned} & \text{kcal/h} = \text{kW} \times 860 \\ & \text{Btu/h} = \text{kW} \times 3412 \\ & \text{cfm} = \text{m}^3/\text{min} \times 35.3 \end{aligned}$

EDUS091617 Dimensions


4. Dimensions

4.1 Indoor Unit

FFQ09/12/15Q2VJU with BYFQ60B3W1 (Decoration Panel)




FFQ09/12/15Q2VJU with BYFQ60C2W1W(S) (Decoration Panel)




Dimensions EDUS091617

BRC1E73 — Wired Remote Controller (Option) —




BRC082A41W — Wireless Remote Controller (Option) —



EDUS091617 Dimensions


BRC082A42W(S) — Wireless Remote Controller (Option) —




Dimensions EDUS091617

4.2 Outdoor Unit

RX09/12QMVJU



RX15QMVJU




EDUS091617 Wiring Diagrams

5. Wiring Diagrams

5.1 Indoor Unit


FFQ09/12/15Q2VJU




Wiring Diagrams EDUS091617

5.2 Outdoor Unit

RX09/12QMVJU



RX15QMVJU




EDUS091617 Piping Diagrams

6. Piping Diagrams

6.1 Indoor Unit


FFQ09/12/15Q2VJU



Piping Diagrams EDUS091617


6.2 Outdoor Unit

RX09/12QMVJU



3D092207A

RX15QMVJU



Split Type Air Conditioners FFQ-Q Series

EDUS091617 Capacity Tables

7. Capacity Tables

FFQ09Q2VJU + RX09QMVJU

60 Hz, 208 V

Cooling

AFR	10.7
BF	0.18

Temp: Celsius TC, SHC, PI: kW

INDO	OOR	OUTDOOR TEMPERATURE (°CDB)																	
EWB	EDB	10			20				30		35			40					
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	2.98	2.35	0.43	2.74	2.23	0.54	2.49	2.12	0.64	2.36	2.06	0.69	2.24	2.00	0.74	2.09	1.94	0.81
16.0	22.0	3.11	2.31	0.44	2.86	2.20	0.54	2.61	2.09	0.64	2.49	2.03	0.70	2.36	1.98	0.75	2.21	1.92	0.81
18.0	25.0	3.23	2.43	0.44	2.98	2.33	0.54	2.73	2.23	0.65	2.61	2.18	0.70	2.48	2.13	0.75	2.33	2.07	0.81
19.4	26.7	3.29	2.59	0.44	3.04	2.49	0.54	2.79	2.39	0.65	2.67	2.34	0.70	2.55	2.29	0.75	2.40	2.24	0.81
22.0	30.0	3.48	2.50	0.45	3.23	2.41	0.55	2.98	2.32	0.65	2.85	2.28	0.70	2.73	2.24	0.76	2.58	2.19	0.82
24.0	32.0	3.60	2.43	0.50	3.35	2.35	0.55	3.10	2.28	0.66	2.98	2.24	0.71	2.85	2.20	0.76	2.70	2.15	0.82

Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

INDO	OOR		OUTDOOR TEMPERATURE (°FDB)																
EWB	EDB	50			68				86		95			104					
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.18	8.03	0.43	9.33	7.62	0.54	8.48	7.23	0.64	8.06	7.03	0.69	7.64	6.84	0.74	7.13	6.61	0.81
60.8	71.6	10.60	7.88	0.44	9.75	7.50	0.54	8.90	7.13	0.64	8.48	6.94	0.70	8.06	6.76	0.75	7.55	6.55	0.81
64.4	77.0	11.02	8.31	0.44	10.17	7.95	0.54	9.32	7.61	0.65	8.90	7.44	0.70	8.48	7.27	0.75	7.97	7.07	0.81
67.0	80.0	11.23	8.82	0.44	10.38	8.48	0.54	9.53	8.15	0.65	9.10	7.99	0.70	8.69	7.82	0.75	8.18	7.63	0.81
71.6	86.0	11.86	8.51	0.45	11.01	8.22	0.55	10.16	7.92	0.65	9.74	7.78	0.70	9.32	7.63	0.76	8.81	7.47	0.82
75.2	89.6	12.28	8.30	0.50	11.43	8.03	0.55	10.58	7.76	0.66	10.16	7.63	0.71	9.74	7.50	0.76	9.23	7.35	0.82

Heating

AFR 11.3

Temp: Celsius TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUF	RE (°CW	'B)				
EDB		15		10	_	5	()	(5	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.40	0.41	1.68	0.43	1.96	0.45	2.25	0.48	3.04	0.63	3.31	0.65	3.84	0.69
21.1	1.31	0.42	1.60	0.45	1.88	0.47	2.16	0.49	2.94	0.64	3.21	0.66	3.74	0.70
22.0	1.28	0.43	1.56	0.45	1.84	0.47	2.13	0.49	2.90	0.65	3.16	0.67	3.70	0.71
24.0	1.24	0.43	1.53	0.45	1.81	0.48	2.09	0.50	2.86	0.65	3.12	0.67	3.66	0.72
25.0	1.23	0.44	1.51	0.46	1.79	0.48	2.07	0.50	2.84	0.66	3.10	0.68	3.64	0.72
27.0	1.19	0.44	1.48	0.46	1.76	0.48	2.04	0.50	2.80	0.66	3.06	0.68	3.59	0.72

Temp: Fahrenheit TC: kBtu/h PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	į	5	1	4	2	:3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	4.78	0.41	5.74	0.43	6.70	0.45	7.67	0.48	10.38	0.63	11.28	0.65	13.10	0.69
70.0	4.48	0.42	5.45	0.45	6.41	0.47	7.37	0.49	10.00	0.64	10.94	0.66	12.75	0.70
71.6	4.37	0.43	5.33	0.45	6.29	0.47	7.25	0.49	9.89	0.65	10.80	0.67	12.61	0.71
75.2	4.25	0.43	5.21	0.45	6.17	0.48	7.14	0.50	9.75	0.65	10.66	0.67	12.47	0.72
77.0	4.19	0.44	5.15	0.46	6.11	0.48	7.08	0.50	9.69	0.66	10.59	0.68	12.40	0.72
80.6	4.07	0.44	5.03	0.46	6.00	0.48	6.96	0.50	9.55	0.66	10.45	0.68	12.27	0.72

Capacity Tables EDUS091617

60 Hz, 230 V

Cooling

AFR	10.7
BF	0.18

Temp: Celsius TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATUI	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	2.98	2.35	0.43	2.74	2.23	0.54	2.49	2.12	0.64	2.36	2.06	0.69	2.24	2.00	0.74	2.09	1.94	0.81
16.0	22.0	3.11	2.31	0.44	2.86	2.20	0.54	2.61	2.09	0.64	2.49	2.03	0.70	2.36	1.98	0.75	2.21	1.92	0.81
18.0	25.0	3.23	2.43	0.44	2.98	2.33	0.54	2.73	2.23	0.65	2.61	2.18	0.70	2.48	2.13	0.75	2.33	2.07	0.81
19.4	26.7	3.29	2.59	0.44	3.04	2.49	0.54	2.79	2.39	0.65	2.67	2.34	0.70	2.55	2.29	0.75	2.40	2.24	0.81
22.0	30.0	3.48	2.50	0.45	3.23	2.41	0.55	2.98	2.32	0.65	2.85	2.28	0.70	2.73	2.24	0.76	2.58	2.19	0.82
24.0	32.0	3.60	2.43	0.50	3.35	2.35	0.55	3.10	2.28	0.66	2.98	2.24	0.71	2.85	2.20	0.76	2.70	2.15	0.82

Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATUI	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.18	8.03	0.43	9.33	7.62	0.54	8.48	7.23	0.64	8.06	7.03	0.69	7.64	6.84	0.74	7.13	6.61	0.81
60.8	71.6	10.60	7.88	0.44	9.75	7.50	0.54	8.90	7.13	0.64	8.48	6.94	0.70	8.06	6.76	0.75	7.55	6.55	0.81
64.4	77.0	11.02	8.31	0.44	10.17	7.95	0.54	9.32	7.61	0.65	8.90	7.44	0.70	8.48	7.27	0.75	7.97	7.07	0.81
67.0	80.0	11.23	8.82	0.44	10.38	8.48	0.54	9.53	8.15	0.65	9.10	7.99	0.70	8.69	7.82	0.75	8.18	7.63	0.81
71.6	86.0	11.86	8.51	0.45	11.01	8.22	0.55	10.16	7.92	0.65	9.74	7.78	0.70	9.32	7.63	0.76	8.81	7.47	0.82
75.2	89.6	12.28	8.30	0.50	11.43	8.03	0.55	10.58	7.76	0.66	10.16	7.63	0.71	9.74	7.50	0.76	9.23	7.35	0.82

Heating

AFR 11.3

Temp: Celsius TC, PI: kW

INDOOR					0	UTDOOI	R TEMP	ERATUF	RE (°CW	B)				
EDB		15		10	_	-5	()	Ò	<u>, </u>	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.40	0.41	1.68	0.43	1.96	0.45	2.25	0.48	3.04	0.63	3.31	0.65	3.84	0.69
21.1	1.31	0.42	1.60	0.45	1.88	0.47	2.16	0.49	2.94	0.64	3.21	0.66	3.74	0.70
22.0	1.28	0.43	1.56	0.45	1.84	0.47	2.13	0.49	2.90	0.65	3.16	0.67	3.70	0.71
24.0	1.24	0.43	1.53	0.45	1.81	0.48	2.09	0.50	2.86	0.65	3.12	0.67	3.66	0.72
25.0	1.23	0.44	1.51	0.46	1.79	0.48	2.07	0.50	2.84	0.66	3.10	0.68	3.64	0.72
27.0	1.19	0.44	1.48	0.46	1.76	0.48	2.04	0.50	2.80	0.66	3.06	0.68	3.59	0.72

Temp: Fahrenheit TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	į	5	1	4	2	:3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	4.78	0.41	5.74	0.43	6.70	0.45	7.67	0.48	10.38	0.63	11.28	0.65	13.10	0.69
70.0	4.48	0.42	5.45	0.45	6.41	0.47	7.37	0.49	10.00	0.64	10.94	0.66	12.75	0.70
71.6	4.37	0.43	5.33	0.45	6.29	0.47	7.25	0.49	9.89	0.65	10.80	0.67	12.61	0.71
75.2	4.25	0.43	5.21	0.45	6.17	0.48	7.14	0.50	9.75	0.65	10.66	0.67	12.47	0.72
77.0	4.19	0.44	5.15	0.46	6.11	0.48	7.08	0.50	9.69	0.66	10.59	0.68	12.40	0.72
80.6	4.07	0.44	5.03	0.46	6.00	0.48	6.96	0.50	9.55	0.66	10.45	0.68	12.27	0.72

EDUS091617 **Capacity Tables**

Symbols:

AFR : Airflow rate (m³/min.)

BF : Bypass factor

EWB : Entering wet bulb temp. (°C) / (°F) EDB : Entering dry bulb temp. (°C) / (°F) TC : Total capacity (kW) / (kBtu/h) SHC (kW) / (kBtu/h) : Sensible heat capacity

Ы : Power input (kW)

Notes:

shows nominal (rated) capacities and power input.
 TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
 Capacities are based on the following conditions.
 Corresponding refrigerant piping length: 25 ft (7.5 m)
 Level difference: 0 ft (0 m)

 Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106252A

Capacity Tables EDUS091617

FFQ12Q2VJU + RX12QMVJU

60 Hz, 208 V

Cooling

AFR	11.5
BF	0.28

Temp: Celsius TC, SHC, PI: kW

INDO	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.55	2.59	0.54	3.26	2.44	0.66	2.96	2.29	0.79	2.81	2.22	0.85	2.67	2.15	0.92	2.49	2.06	0.99
16.0	22.0	3.70	2.54	0.54	3.40	2.40	0.67	3.11	2.26	0.79	2.96	2.19	0.86	2.81	2.12	0.92	2.63	2.05	1.00
18.0	25.0	3.85	2.64	0.54	3.55	2.51	0.67	3.25	2.39	0.80	3.11	2.32	0.86	2.96	2.26	0.93	2.78	2.19	1.00
19.4	26.7	3.92	2.78	0.54	3.62	2.65	0.67	3.33	2.53	0.80	3.18	2.47	0.86	3.03	2.41	0.93	2.85	2.34	1.00
22.0	30.0	4.14	2.67	0.55	3.84	2.56	0.68	3.55	2.45	0.81	3.40	2.40	0.87	3.25	2.34	0.93	3.07	2.28	1.01
24.0	32.0	4.29	2.60	0.55	3.99	2.49	0.68	3.69	2.39	0.81	3.55	2.35	0.87	3.40	2.30	0.94	3.22	2.24	1.01

Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

INDO	OOR							0	UTDOO	R TEMP	ERATUI	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	12.13	8.83	0.54	11.12	8.32	0.66	10.11	7.82	0.79	9.60	7.57	0.85	9.10	7.33	0.92	8.49	7.04	0.99
60.8	71.6	12.63	8.66	0.54	11.62	8.17	0.67	10.61	7.71	0.79	10.10	7.48	0.86	9.60	7.25	0.92	8.99	6.98	1.00
64.4	77.0	13.13	9.02	0.54	12.12	8.57	0.67	11.11	8.14	0.80	10.60	7.92	0.86	10.10	7.71	0.93	9.49	7.46	1.00
67.0	80.0	13.38	9.48	0.54	12.37	9.05	0.67	11.36	8.63	0.80	10.80	8.43	0.86	10.34	8.22	0.93	9.74	7.98	1.00
71.6	86.0	14.13	9.11	0.55	13.12	8.73	0.68	12.11	8.36	0.81	11.60	8.18	0.87	11.09	8.00	0.93	10.49	7.79	1.01
75.2	89.6	14.63	8.85	0.55	13.62	8.51	0.68	12.61	8.17	0.81	12.10	8.00	0.87	11.59	7.84	0.94	10.99	7.64	1.01

Heating

AFR 12.1

Temp: Celsius TC, PI: kW

INDOOR					0	UTDOOI	RTEMP	ERATUF	RE (°CW	B)				
EDB		15		10	_	5	()	(3	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.89	0.63	2.27	0.67	2.65	0.70	3.03	0.73	4.10	0.96	4.45	1.00	5.17	1.06
21.1	1.77	0.65	2.15	0.68	2.53	0.72	2.91	0.75	3.96	0.99	4.32	1.02	5.03	1.08
22.0	1.72	0.66	2.10	0.69	2.48	0.72	2.86	0.76	3.91	0.99	4.26	1.03	4.98	1.09
24.0	1.68	0.67	2.06	0.70	2.44	0.73	2.82	0.76	3.85	1.00	4.21	1.04	4.92	1.10
25.0	1.65	0.67	2.03	0.70	2.41	0.73	2.79	0.77	3.82	1.01	4.18	1.04	4.90	1.10
27.0	1.61	0.68	1.99	0.71	2.37	0.74	2.75	0.77	3.77	1.02	4.13	1.05	4.84	1.11

Temp: Fahrenheit TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	į	5	1	4	2	:3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	6.43	0.63	7.73	0.67	9.03	0.70	10.33	0.73	13.98	0.96	15.20	1.00	17.64	1.06
70.0	6.04	0.65	7.33	0.68	8.63	0.72	9.93	0.75	13.50	0.99	14.73	1.02	17.17	1.08
71.6	5.88	0.66	7.18	0.69	8.47	0.72	9.77	0.76	13.32	0.99	14.55	1.03	16.99	1.09
75.2	5.72	0.67	7.02	0.70	8.31	0.73	9.61	0.76	13.14	1.00	14.36	1.04	16.80	1.10
77.0	5.64	0.67	6.94	0.70	8.24	0.73	9.53	0.77	13.05	1.01	14.27	1.04	16.71	1.10
80.6	5.48	0.68	6.78	0.71	8.08	0.74	9.37	0.77	12.86	1.02	14.08	1.05	16.52	1.11

EDUS091617 Capacity Tables

60 Hz, 230 V

Cooling

AFR	11.5
BF	0.28

Temp: Celsius TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATUI	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.55	2.59	0.54	3.26	2.44	0.66	2.96	2.29	0.79	2.81	2.22	0.85	2.67	2.15	0.92	2.49	2.06	0.99
16.0	22.0	3.70	2.54	0.54	3.40	2.40	0.67	3.11	2.26	0.79	2.96	2.19	0.86	2.81	2.12	0.92	2.63	2.05	1.00
18.0	25.0	3.85	2.64	0.54	3.55	2.51	0.67	3.25	2.39	0.80	3.11	2.32	0.86	2.96	2.26	0.93	2.78	2.19	1.00
19.4	26.7	3.92	2.78	0.54	3.62	2.65	0.67	3.33	2.53	0.80	3.18	2.47	0.86	3.03	2.41	0.93	2.85	2.34	1.00
22.0	30.0	4.14	2.67	0.55	3.84	2.56	0.68	3.55	2.45	0.81	3.40	2.40	0.87	3.25	2.34	0.93	3.07	2.28	1.01
24.0	32.0	4.29	2.60	0.55	3.99	2.49	0.68	3.69	2.39	0.81	3.55	2.35	0.87	3.40	2.30	0.94	3.22	2.24	1.01

Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATUI	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	12.13	8.83	0.54	11.12	8.32	0.66	10.11	7.82	0.79	9.60	7.57	0.85	9.10	7.33	0.92	8.49	7.04	0.99
60.8	71.6	11.62	8.66	0.54	11.62	8.17	0.67	10.61	7.71	0.79	10.10	7.48	0.86	9.60	7.25	0.92	8.99	6.98	1.00
64.4	77.0	12.12	9.02	0.54	12.12	8.57	0.67	11.11	8.14	0.80	10.60	7.92	0.86	10.10	7.71	0.93	9.49	7.46	1.00
67.0	80.0	12.37	9.48	0.54	12.37	9.05	0.67	11.36	8.63	0.80	10.80	8.43	0.86	10.34	8.22	0.93	9.74	7.98	1.00
71.6	86.0	13.12	9.11	0.55	13.12	8.73	0.68	12.11	8.36	0.81	11.60	8.18	0.87	11.09	8.00	0.93	10.49	7.79	1.01
75.2	89.6	13.62	8.85	0.55	13.62	8.51	0.68	12.61	8.17	0.81	12.10	8.00	0.87	11.59	7.84	0.94	10.99	7.64	1.01

Heating

AFR 12.1

Temp: Celsius TC, PI: kW

		OUTDOOR TEMPERATURE (°CWB)												
INDOOR					0	UTDOO	R TEMP	ERATUR	RE (°CW	'B)				
EDB		15		10	-	-5	()	(ĵ	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.89	0.63	2.27	0.67	2.65	0.70	3.03	0.73	4.10	0.96	4.45	1.00	5.17	1.06
21.1	1.77	0.65	2.15	0.68	2.53	0.72	2.91	0.75	3.96	0.99	4.32	1.02	5.03	1.08
22.0	1.72	0.66	2.10	0.69	2.48	0.72	2.86	0.76	3.91	0.99	4.26	1.03	4.98	1.09
24.0	1.68	0.67	2.06	0.70	2.44	0.73	2.82	0.76	3.85	1.00	4.21	1.04	4.92	1.10
25.0	1.65	0.67	2.03	0.70	2.41	0.73	2.79	0.77	3.82	1.01	4.18	1.04	4.90	1.10
27.0	1.61	0.68	1.99	0.71	2.37	0.74	2.75	0.77	3.77	1.02	4.13	1.05	4.84	1.11

Temp: Fahrenheit TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	į	5	1	4	2	:3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	6.43	0.63	7.73	0.67	9.03	0.70	10.33	0.73	13.98	0.96	15.20	1.00	17.64	1.06
70.0	6.04	0.65	7.33	0.68	8.63	0.72	9.93	0.75	13.50	0.99	14.73	1.02	17.17	1.08
71.6	5.88	0.66	7.18	0.69	8.47	0.72	9.77	0.76	13.32	0.99	14.55	1.03	16.99	1.09
75.2	5.72	0.67	7.02	0.70	8.31	0.73	9.61	0.76	13.14	1.00	14.36	1.04	16.80	1.10
77.0	5.64	0.67	6.94	0.70	8.24	0.73	9.53	0.77	13.05	1.01	14.27	1.04	16.71	1.10
80.6	5.48	0.68	6.78	0.71	8.08	0.74	9.37	0.77	12.86	1.02	14.08	1.05	16.52	1.11

Capacity Tables EDUS091617

Symbols:

AFR : Airflow rate (m³/min.)

BF : Bypass factor

EWB : Entering wet bulb temp. (°C) / (°F) EDB : Entering dry bulb temp. (°C) / (°F) TC : Total capacity (kW) / (kBtu/h) SHC : Sensible heat capacity (kW) / (kBtu/h)

Ы : Power input (kW)

Notes:

shows nominal (rated) capacities and power input.
 TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
 Capacities are based on the following conditions.
 Corresponding refrigerant piping length: 25 ft (7.5 m)
 Level difference: 0 ft (0 m)

 Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106253

EDUS091617 Capacity Tables

FFQ15Q2VJU + RX15QMVJU

60 Hz, 208 V

Cooling

AFR	11.9
BF	0.32

Temp: Celsius TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.94	2.77	0.66	3.94	2.77	0.86	3.91	2.76	1.05	3.72	2.66	1.14	3.52	2.55	1.22	3.29	2.43	1.33
16.0	22.0	4.84	3.10	0.72	4.50	2.92	0.89	4.11	2.72	1.06	3.91	2.62	1.14	3.71	2.53	1.23	3.48	2.41	1.33
18.0	25.0	5.08	3.21	0.72	4.69	3.02	0.89	4.30	2.83	1.06	4.10	2.74	1.15	3.91	2.65	1.23	3.67	2.55	1.34
19.4	26.7	5.18	3.33	0.73	4.79	3.15	0.90	4.40	2.97	1.07	4.20	2.88	1.15	4.00	2.79	1.24	3.77	2.69	1.34
22.0	30.0	5.47	3.19	0.73	5.08	3.02	0.90	4.69	2.86	1.07	4.49	2.78	1.16	4.29	2.71	1.24	4.06	2.62	1.35
24.0	32.0	5.66	3.08	0.74	5.27	2.93	0.91	4.88	2.78	1.08	4.68	2.71	1.16	4.49	2.64	1.25	4.25	2.56	1.35

Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	13.44	9.47	0.66	13.44	9.47	0.86	13.35	9.42	1.05	12.68	9.06	1.14	12.01	8.72	1.22	11.21	8.31	1.33
60.8	71.6	16.51	10.58	0.72	15.34	9.96	0.89	14.01	9.28	1.06	13.34	8.95	1.14	12.67	8.62	1.23	11.87	8.23	1.33
64.4	77.0	17.34	10.96	0.72	16.00	10.30	0.89	14.67	9.66	1.06	14.00	9.35	1.15	13.33	9.05	1.23	12.53	8.69	1.34
67.0	80.0	17.67	11.37	0.73	16.33	10.74	0.90	15.00	10.12	1.07	14.40	9.82	1.15	13.66	9.53	1.24	12.86	9.18	1.34
71.6	86.0	18.66	10.87	0.73	17.32	10.31	0.90	15.99	9.76	1.07	15.32	9.50	1.16	14.65	9.23	1.24	13.85	8.93	1.35
75.2	89.6	19.32	10.51	0.74	17.98	10.00	0.91	16.65	9.50	1.08	15.98	9.25	1.16	15.31	9.01	1.25	14.51	8.73	1.35

Heating

AFR 12.5

Temp: Celsius TC, PI: kW

INDOOR					0	UTDOOI	RTEMP	ERATUF	RE (°CW	B)				
EDB		15		10	_	5	()	(3	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	2.26	0.79	2.71	0.84	3.17	0.88	3.62	0.92	4.90	1.21	5.33	1.25	6.19	1.33
21.1	2.12	0.82	2.57	0.86	3.03	0.90	3.48	0.94	4.74	1.24	5.17	1.28	6.02	1.36
22.0	2.06	0.83	2.52	0.87	2.97	0.91	3.43	0.95	4.67	1.25	5.10	1.29	5.96	1.37
24.0	2.01	0.83	2.46	0.88	2.92	0.92	3.37	0.96	4.61	1.26	5.04	1.30	5.89	1.38
25.0	1.98	0.84	2.43	0.88	2.89	0.92	3.34	0.96	4.58	1.26	5.00	1.30	5.86	1.38
27.0	1.92	0.85	2.38	0.89	2.83	0.93	3.29	0.97	4.51	1.27	4.94	1.31	5.80	1.40

Temp: Fahrenheit TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUI	RE (°FW	B)				
EDB		5	1	4	2	:3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	7.70	0.79	9.25	0.84	10.81	0.88	12.36	0.92	16.73	1.21	18.19	1.25	21.11	1.33
70.0	7.23	0.82	8.78	0.86	10.33	0.90	11.88	0.94	16.20	1.24	17.63	1.28	20.56	1.36
71.6	7.04	0.83	8.59	0.87	10.14	0.91	11.69	0.95	15.95	1.25	17.41	1.29	20.33	1.37
75.2	6.85	0.83	8.40	0.88	9.95	0.92	11.50	0.96	15.73	1.26	17.19	1.30	20.11	1.38
77.0	6.75	0.84	8.31	0.88	9.86	0.92	11.41	0.96	15.61	1.26	17.08	1.30	20.00	1.38
80.6	6.56	0.85	8.12	0.89	9.67	0.93	11.22	0.97	15.39	1.27	16.85	1.31	19.77	1.40

Capacity Tables EDUS091617

60 Hz, 230 V

Cooling

AFR	11.9
BF	0.32

Temp: Celsius TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.94	2.77	0.66	3.94	2.77	0.86	3.91	2.76	1.05	3.72	2.66	1.14	3.52	2.55	1.22	3.29	2.43	1.33
16.0	22.0	4.84	3.10	0.72	4.50	2.92	0.89	4.11	2.72	1.06	3.91	2.62	1.14	3.71	2.53	1.23	3.48	2.41	1.33
18.0	25.0	5.08	3.21	0.72	4.69	3.02	0.89	4.30	2.83	1.06	4.10	2.74	1.15	3.91	2.65	1.23	3.67	2.55	1.34
19.4	26.7	5.18	3.33	0.73	4.79	3.15	0.90	4.40	2.97	1.07	4.20	2.88	1.15	4.00	2.79	1.24	3.77	2.69	1.34
22.0	30.0	5.47	3.19	0.73	5.08	3.02	0.90	4.69	2.86	1.07	4.49	2.78	1.16	4.29	2.71	1.24	4.06	2.62	1.35
24.0	32.0	5.66	3.08	0.74	5.27	2.93	0.91	4.88	2.78	1.08	4.68	2.71	1.16	4.49	2.64	1.25	4.25	2.56	1.35

Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

IND	OOR		OUTDOOR TEMPERATURE (°FDB)																
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	13.44	9.47	0.66	13.44	9.47	0.86	13.35	9.42	1.05	12.68	9.06	1.14	12.01	8.72	1.22	11.21	8.31	1.33
60.8	71.6	15.34	10.58	0.72	15.34	9.96	0.89	14.01	9.28	1.06	13.34	8.95	1.14	12.67	8.62	1.23	11.87	8.23	1.33
64.4	77.0	16.00	10.96	0.72	16.00	10.60	0.89	14.67	9.66	1.06	14.00	9.35	1.15	13.33	9.05	1.23	12.53	8.69	1.34
67.0	80.0	16.33	11.37	0.73	16.33	10.74	0.90	15.00	10.12	1.07	14.40	9.82	1.15	13.66	9.53	1.24	12.86	9.18	1.34
71.6	86.0	17.32	10.87	0.73	17.32	10.31	0.90	15.99	9.76	1.07	15.32	9.50	1.16	14.65	9.23	1.24	13.85	8.93	1.35
75.2	89.6	17.98	10.51	0.74	17.98	10.00	0.91	16.65	9.50	1.08	15.98	9.25	1.16	15.31	9.01	1.25	14.51	8.73	1.35

Heating

AFR 12.5

Temp: Celsius TC, PI: kW

INDOOR		OUTDOOR TEMPERATURE (°CWB)												
EDB		15		10	_	-5	()	(3	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	2.26	0.79	2.71	0.84	3.17	0.88	3.62	0.92	4.90	1.21	5.33	1.25	6.19	1.33
21.1	2.12	0.82	2.57	0.86	3.03	0.90	3.48	0.94	4.74	1.24	5.17	1.28	6.02	1.36
22.0	2.06	0.83	2.52	0.87	2.97	0.91	3.43	0.95	4.67	1.25	5.10	1.29	5.96	1.37
24.0	2.01	0.83	2.46	0.88	2.92	0.92	3.37	0.96	4.61	1.26	5.04	1.30	5.89	1.38
25.0	1.98	0.84	2.43	0.88	2.89	0.92	3.34	0.96	4.58	1.26	5.00	1.30	5.86	1.38
27.0	1.92	0.85	2.38	0.89	2.83	0.93	3.29	0.97	4.51	1.27	4.94	1.31	5.80	1.40

Temp: Fahrenheit TC: kBtu/h

PI: kW

INDOOR		OUTDOOR TEMPERATURE (°FWB)												
EDB	į	5	1	4	2	:3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	7.70	0.79	9.25	0.84	10.81	0.88	12.36	0.92	16.73	1.21	18.19	1.25	21.11	1.33
70.0	7.23	0.82	8.78	0.86	10.33	0.90	11.88	0.94	16.20	1.24	17.63	1.28	20.56	1.36
71.6	7.04	0.83	8.59	0.87	10.14	0.91	11.69	0.95	15.95	1.25	17.41	1.29	20.33	1.37
75.2	6.85	0.83	8.40	0.88	9.95	0.92	11.50	0.96	15.73	1.26	17.19	1.30	20.11	1.38
77.0	6.75	0.84	8.31	0.88	9.86	0.92	11.41	0.96	15.61	1.26	17.08	1.30	20.00	1.38
80.6	6.56	0.85	8.12	0.89	9.67	0.93	11.22	0.97	15.39	1.27	16.85	1.31	19.77	1.40

EDUS091617 **Capacity Tables**

Symbols:

AFR : Airflow rate (m³/min.)

BF : Bypass factor

EWB : Entering wet bulb temp. (°C) / (°F) EDB : Entering dry bulb temp. (°C) / (°F) TC : Total capacity (kW) / (kBtu/h) SHC (kW) / (kBtu/h) : Sensible heat capacity

Ы : Power input (kW)

Notes:

shows nominal (rated) capacities and power input.
 TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
 Capacities are based on the following conditions.
 Corresponding refrigerant piping length: 25 ft (7.5 m)
 Level difference: 0 ft (0 m)

 Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106254A


Capacity Tables EDUS091617

7.1 Capacity Correction Factor by the Length of Refrigerant Piping (Reference)


The cooling capacity and the heating capacity of the unit have to be corrected in accordance with the length of refrigerant piping — the distance between the indoor unit and the outdoor unit.

<-- line : cooling capacity>
<--- line : heating capacity>

7.1.1 09/12 Class



7.1.2 15 Class



Note: The graphs show the factor when additional refrigerant of the proper quantity is charged.

EDUS091617 **Operation Limit**

Continuous operation


68

86

3D092209A

Operation Limit


RX09/12/15QMVJU



Sound Level EDUS091617

9. Sound Level

9.1 Measuring Location



Notes:


- 1. Operation sound is measured in an anechoic chamber.
- 2. The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB) Outdoor ; 95°FDB (35°CDB)	Indoor ; 70°FDB (21°CDB) / 60°FWB (15.6°CWB) Outdoor ; 47°FDB (8.3°CDB)	16.4 ft (5 m)


EDUS091617 Sound Level

9.2 Indoor Unit


FFQ09Q2VJU



FFQ12Q2VJU




FFQ15Q2VJU




Sound Level EDUS091617

9.3 Outdoor Unit


RX09QMVJU






3D106145


RX12QMVJU






3D106146

RX15QMVJU





3D106147

EDUS091617 **Electric Characteristics**

10. Electric Characteristics

Unit Con	nbination		Power Supply				Compressor OFM			IFM	
Indoor Unit	Outdoor Unit	Hz - Volts	Voltage Range	MCA	MFA	RLA	W	FLA	W	FLA	
FFQ09Q2VJU	RX09QMVJU	60 - 208	Max. 253 V	8.6	15	7.5	18	0.15	50	0.28	
FFQ09Q2V30	9Q2VJU HXU9QWVJU		Min. 187 V	0.0	15	7.5	10	0.15	30	0.20	
FFQ12Q2VJU	RX12QMVJU	60 - 208	Max. 253 V	8.6	15	7.5	18	0.15	50	0.28	
FFQ12Q2V30	HX12QWIVJU	60 - 230	Min. 187 V	0.0	15	7.5	10	0.15	50	0.20	
FFQ15Q2VJU	RX15QMVJU	60 - 208	Max. 253 V	9.1	15	8.0	59	0.39	50	0.00	
FFQ15Q2V30	HATOQIVIVJU	60 - 230	Min. 187 V	9.1	15	6.0	59			0.28	

Symbols:

MCA : Min. circuit amps (A) MFA : Max. fuse amps (A) RLA : Rated load amps (A) OFM : Outdoor fan motor IFM : Indoor fan motor

: Fan motor rated output (W)

: Full load amps (A) FLA

Notes:

- 1. RLA is the max current that comes in cooling operation and heating

- According to the first comes in cooling operation and reading operation.
 Maximum allowable voltage variation between phases is 2%.
 Select wire size based on the larger value of MCA.
 Be sure to install a ground leak detector.
 (This unit uses an inverter, which means that a ground leak detector capable of handling high harmonics must be used in order to prevent malfunctioning of the ground leak detector.)

3D106058

Installation Manual EDUS091617

11. Installation Manual

11.1 Indoor Unit

Contents

Safe	ty Considerations	1
Befo	re Installation	3
Acc	essories	3
Cho	osing an Installation Site	4
Indo	or Unit Installation	6
	Relation of ceiling opening to unit and suspension bolt position	6
2	Make the ceiling opening needed for installation where applicable (For existing ceilings)	
	Installing the suspension bolts	
4.	Installing the indoor unit	7
5.	Drain piping work	8
	Wiring	

Refrigerant Piping Work	14
1. Flaring the pipe end	14
2. Refrigerant piping	
Installation of the Decoration Panel	16
Field Settings	16
Setting air outlet direction	16
2. Setting for options	16
Setting air filter sign	
4. When implementing group control	17
2 remote controllers (controlling 1 indoor unit by 2 remote controllers)	17
Trial Operation and Testing	17
1. Trial operation and testing	17
2. Test items	
How to diagnose for malfunction	

Safety Considerations

Read these **Safety Considerations for Installation** carefully before installing an air conditioner or heat pump. After completing the installation, make sure that the unit operates properly during the startup operation.

Instruct the user on how to operate and maintain the unit. Inform users that they should store this installation manual with the operation manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electric shock, fire, or explosion.

Meanings of DANGER, WARNING, CAUTION, and NOTE Symbols:

↑ DANGER ········ Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

↑ WARNING ····· Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

↑ CAUTION ···· Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTE Indicates situations that may result in equipment or property-damage accidents only.

A DANGER -

- Refrigerant gas is heavier than air and replaces oxygen.
 A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death.
 Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.

- If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.
- After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.
- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.

MARNING -

- Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency.
- Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling.
- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit.
 A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.

EDUS091617 Installation Manual

- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- · Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a fuse, a circuit breaker, a disconnect or a GFCI.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may occur.

A CAUTION .

- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately
 after operation as the refrigerant pipes may be hot or
 cold, depending on the condition of the refrigerant flowing
 through the refrigerant piping, compressor, and other
 refrigerant cycle parts. Your hands may suffer burns or
 frostbite if you touch the refrigerant pipes. To avoid injury,
 give the pipes time to return to normal temperature or, if
 you must touch them, be sure to wear proper gloves.
- Install drain piping to proper drainage. Improper drain piping may result in water leakage and property damage.
- · Insulate piping to prevent condensation.
- · Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R410A in the system must be kept clean, dry, and tight.
 - (a) Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.

- (b) Tight -- R410A does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection again harmful ultraviolet radiation. R410A can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation. Read the chapter Refrigerant Piping Work and follow the procedures.
- Since R410A is a blend, the required additional refrigerant must be charged in its liquid state. If the refrigerant is charged in a state of gas, its composition can change and the system will not work properly.
- The indoor unit is for R410A. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit far away from fluorescent lamps as much as possible.
- Indoor units are for indoor installation only. Outdoor units can be installed either outdoors or indoors. This unit is for indoor use.
- Do not install the air conditioner or heat pump in the following locations:
- (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate and fall off or result in water leakage.
- (b) Where corrosive gas, such as sulfurous acid gas, is produced. Corroding copper pipes or soldered parts may result in refrigerant leakage.
- (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
- (d) Where flammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.

NOTE -

- The indoor unit should be positioned where the unit and inter-unit wires (outdoor to indoor) are at least 3.3ft (1m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 3.3ft (1m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with conventional refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R410A, the refrigerant may deteriorate.
- This air conditioner or heat pump is an appliance that should not be accessible to the general public.
- As design pressure is 604 psi, the wall thickness of fieldinstalled pipes should be selected in accordance with the relevant local, state, and national regulations.

Installation Manual EDUS091617

Before Installation


Leave the unit inside its packaging until you reach the installation site. Where unpacking is unavoidable, use a sling of soft
material or protective plates together with a rope when lifting, this to avoid damage or scratches to the unit.
 When unpacking the unit or when moving the unit after unpacking, be sure to lift the unit by holding on to the hanger bracket
without exerting any pressure on other parts, especially on refrigerant piping, drain piping and other resin parts.

- · Refer to the installation manual of the outdoor unit for items not described in this manual.
- Caution concerning refrigerant series R410A:
 The connectable outdoor units must be designed exclusively for R410A.

Precautions

- . Do not install or operate the unit in places mentioned below.
 - Places with mineral oil, or filled with oil vapor or spray like in kitchens. (Plastic parts may deteriorate.)
 - Where corrosive gas like sulphurous gas exists. (Copper tubing and brazed spots may corrode.)
 - Where volatile flammable gas like thinner or gasoline is used.
 - Where machines generating electromagnetic waves exist. (Control system may malfunction.)
 - Where the air contains high levels of salt such as near the ocean and where voltage fluctuates a lot (e.g. in factories). Also inside vehicles or vessels.
- . When selecting the installation site, use the supplied template for installation.
- Do not install accessories on the casing directly. Drilling holes in the casing may damage electrical wires and consequently cause fire.

Accessories



EDUS091617 Installation Manual

Optional Accessories

· The optional decoration panel and remote controller are required for this indoor unit.

Table 1

	Optional decoration	panel
Type A	BYFQ60B3W1	Color: White
Type B	BYFQ60C2W1W	Color: White
Type B	BYFQ60C2W1S	Color: Silver

 There are 2 types of remote controllers: wired and wireless. Select a remote controller from Table 2 according to customer request and install in an appropriate place.

Table 2

Remote controller type	Heat Pump type
Wired type	BRC1E73
Wireless type	BRC082A41W / BRC082A42W / BRC082A42S

If you wish to use a remote controller that is not listed in Table 2, select a suitable remote controller after consulting catalogs and technical materials.

Choosing an Installation Site

Hold the unit by the 4 hanger brackets when opening the box and moving it, and do not exert pressure on to any other part, piping (refrigerant, drain, etc.), or plastic parts.

If the temperature or humidity inside the ceiling might rise above 86°F (30°C) or RH 80%, respectively, add extra insulation to the unit.

Use polyethylene foam as insulation and make sure it is at least 3/8 inch (10mm) thick and fits inside the ceiling opening.

Select the air flow directions best suited to the room and point of installation.

For air discharge in 3 directions, it is necessary to make field settings by means of the remote controller and to close the air outlet (s).


Refer to the installation manual of the blocking pad kit (sold separately) and to "Field Settings" on page 16.


- · Before choosing the installation site, obtain user approval.
 - The indoor unit should be positioned in a place where:
 - 1) both the air inlet and air outlet are unobstructed,
 - 2) the unit is not exposed to direct sunlight,
 - 3) the unit is away from the source of heat or steam,
 - 4) there is no source of machine oil vapor (this may shorten the indoor unit service life),
 - 5) cool/warm air is circulated throughout the room,
 - the unit is away from electronic ignition type fluorescent lamps (inverter or rapid start type) as they may affect the remote controller range,
 - 7) no laundry equipment is nearby,
 - 8) drainage can be performed without any problem,
 - 9) the weight of the indoor unit can be adequately supported,
- 10) the wall is not significantly tilted,
- 11) room can be left for installation and service work,
- 12) there is no risk of flammable gas leaking,
- 13) the required length of indoor-outdoor piping would not exceed the specified maximum length (see the installation manual that came with the outdoor unit for details).

Installation Manual EDUS091617

Choosing an Installation Site

Installation Space Requirements






unit:inch (mm)

. Leave 8 inch (200mm) or more space where marked with the *, on sides where the air outlet is closed.

Air flow direction

- · The air direction shown is an example.
- Select the appropriate number of directions according to the shape of the room and the location of the unit. (Field settings have to be made using the remote controller and the outlet vents have to be shut off if 2 or 3 directions are selected.
 See the blocking pad kit (sold separately) installation manual for details.)

Air flow direction (Example)







Air outlet in 2 directions

Air outlet in 3 directions


Air outlet in 4 directions

Use suspension bolts for installation. Check whether the ceiling is strong enough to support the weight of the unit or not. If there is a risk, reinforce the ceiling before installing the unit.

(Installation pitch is marked on the template. Refer to it to check for points requiring reinforcing.)


Indoor Unit Installation

1. Relation of ceiling opening to unit and suspension bolt position



NOTE

- *If the panel does not extend over the ceiling by this amount, supplement with extra ceiling material or restore the ceiling.
- Install the inspection opening on the electrical wiring box side where maintenance and inspection of the electrical wiring box and drain pump are easy.



Indoor Unit Installation


2. Make the ceiling opening needed for installation where applicable (For existing ceilings)

- . Refer to the (E) template for ceiling opening dimensions.
- Create the ceiling opening required for installation. From the side of the opening to the casing outlet, implement the
 refrigerant and drain piping and wiring for remote controller (unnecessary for wireless type) and wiring between units.
 Refer to each Drain piping work or Wiring section.
- After making an opening in the ceiling, it may be necessary to reinforce ceiling beams to keep the ceiling level and to
 prevent it from vibrating. Consult the builder for details.

3. Installing the suspension bolts

(Use either a M8-M10 size bolt or the equivalent)
Use a hole-in anchor for existing ceilings, and a sunken insert, sunken anchor or other field supplied parts for new ceilings to reinforce the ceiling to bear the weight of the unit. Adjust clearance (2-4 inch (50-100mm)) from the ceiling before proceeding further.

· All the above parts are field supplied.




4. Installing the indoor unit

When installing optional accessories (except for the decoration panel), read also the installation manual of the optional accessories. Depending on the field conditions, it may be easier to install optional accessories before the indoor unit is installed. However, for existing ceilings, always install fresh air intake kit before installing the unit. As for the parts to be used for installation work, be sure to use the provided accessories and specified parts designated by Daikin.

For new ceilings


- 1) Install the indoor unit temporarily.

Securing the hanger bracket



- Refer to the (E) template for ceiling opening dimension.
 Consult the builder or carpenter for details.
- The center of the ceiling opening is indicated on the
 E template. This indication also indicates the center of the
 unit
- The (E) template can be rotated by 90° to be able to indicate the correct dimensions on all 4 sides.
- After cutting the template from the packaging, attach the
 (E) template to the unit with (F) screws (x4) as shown in
 figure.
- Ceiling height is shown on the side of the (E) template.
 Adjust the height of the unit according to this indication.

Installation of template



Ceiling work

Adjust the unit to the right position for installation.
 (Refer to 1. Relation of ceiling opening to unit and suspension bolt position.)

⚠ CAUTION

If the unit is tilted against condensate flow, the float switch may malfunction and cause water to drip.


- 4) Check the unit is horizontally level.
 - The indoor unit is equipped with a built-in drain pump and float switch. Verify that it is level by using a water level or a water-filled vinyl tube.
- 5) Remove the (E) template.



For existing ceilings

- 1) Install the indoor unit temporarily.
- Attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and
 washer from the upper and lower sides of hanger bracket.





- Adjust the height and position of the unit.
 (Refer to 1. Relation of ceiling opening to unit and suspension bolt position.)
- 3) Perform steps 4) in For new ceilings


5. Drain piping work

⚠ CAUTION

- · Water pooling in the drainage piping can cause the drain to clog.
- Do not connect the drain piping directly to sewage pipes that smell of ammonia. The ammonia in the sewage might enter the indoor unit through the drain pipes and corrode the heat exchanger.
- . Keep in mind that the drain pipe becomes blocked if water collects on it.

1. Install of drain piping

- Install the drain piping as shown in the figure and take measures against condensation. Improperly rigged piping could lead to leaks and eventually wet furniture and belongings.
- Keep piping as short as possible and slope it downwards at a gradient of at least 1/100 so that air may not remain trapped inside the pipe.
- Keep pipe size equal to or greater than that of the connecting pipe (vinyl pipe of nominal diameter 13/16 inch (20mm) and outer diameter 1 inch (26mm)).
- Push the supplied drain hose as far as possible over the drain socket.
- · If the drain hose cannot be sufficiently set on a slope, refer to "Precautions for drain raising piping".
- To keep the drain hose from sagging, space hanger bracket every 40-60 inch (1000-1500mm).




Indoor Unit Installation

- After the testing of drain piping is finished, attach the drain sealing pad (large) supplied with the unit over the uncovered part of the drain socket (= between drain hose and unit body).
- Insulate the complete drain piping inside the building (field supply).
- If the drain hose cannot be sufficiently set on a slope, fit the hose with drain raising piping (field supply).


Drain socket B Clamp metal J Sealing pad (large) B Clamp metal Drain socket A Drain piping (field supply) A Drain hose

Precautions for drain raising piping

- . Install the drain raising pipes at a height of less than H2.
- . Install the drain raising pipes at a right angle to the indoor unit and no more than 11-3/4 inch (300mm) from the unit.




- To ensure no excessive pressure is applied to the included (A) drain hose, do not bend or twist the hose when installing as it could cause leakage.
- · If converging multiple drain pipes, install according to the procedure shown below.



Select converging drain pipes with gauges is suitable for the operating capacity of the unit.

2. After piping work is finished, check if drainage flows smoothly

· Add approximately 1/4 gal of water slowly from the air outlet and check drainage flow.



When electric wiring work is finished


· Check drainage flow during COOL operation, explained in "Trial operation and testing" on page 17.


When electric wiring work is not finished

⚠ CAUTION

Electrical wiring work should be done by a certified electrician.

- If someone who does not have the proper qualifications performs the work, perform the following actions after the trial
 operation is complete.
- 1) Remove the electrical wiring box cover (2 screws). Connect the single phase power supply (SINGLE PHASE 60 Hz 208/230V) to connections No.1 and No.2 on the terminal block for power supply. Do not connect to No.3 of the terminal block for power supply or the drain pump will not operate. When carrying out wiring work around the electrical wiring box, make sure none of the connectors come undone. Be sure to attach the electrical wiring box cover before turning on the power.
- 2) After confirming drainage, turn off the power supply and remove the power supply wiring.
- 3) Attach the electrical wiring box cover as before.





Indoor Unit Installation

6. Wiring

Refer also to the installation manual for the outdoor unit.

♠ WARNING -

- . Do not use tapped wires, extension cords, or starburst connections, as they may cause overheating, electric shock, or fire.
- Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- . Do not connect the power wire to the indoor unit. Doing so may cause electric shock or fire.

↑ CAUTION

 When connecting the connection wire to the terminal block using a single core wire, be sure to perform curling.

Problems with the installation may cause heat and fires.





- When clamping wiring, use the included clamping material to prevent outside pressure being exerted on the wiring
 connections and clamp firmly. When doing the wiring, make sure the wiring is neat and does not cause the electrical wiring
 box cover to stick up, then close the cover firmly.
- Outside the unit, separate the low voltage wiring (remote controller wiring) and high voltage wiring (wiring between units, ground, and other power wiring) at least 2 in. so that they do not pass through the same place together. Proximity may cause electrical interference, malfunctions, and breakage.

Tightening torque for the terminal blocks

- Use the correct screwdriver for tightening the terminal screws. If the blade of screwdriver is too small, the head of the screw might be damaged, and the screw will not be properly tightened.
- If the terminal screws are tightened too hard, screws might be damaged.
- · Refer to the table below for the tightening torque of the terminal screws.

unit: lbf • ft (N • m)

	Tightening torque
Terminal block for remote controller (6P)	0.58 - 0.72 (0.79 - 0.98)
Terminal block for power supply (4P)	0.87 - 1.06 (1.18 - 1.44)

Precautions for power supply wiring

Use a round crimp-style terminal for connection to the terminal block for power supply. If it cannot be used due to unavoidable reasons, be sure to observe the following instructions:

In wiring, make certain that prescribed wires are used, carry out complete connections, and fix the wires so that external
forces are not applied to the terminals.



- · Use copper wire only.
- · For electric wiring work, refer also to "Wiring diagram label" attached to the electrical wiring box cover.
- · For remote controller wiring details, refer to the installation manual attached to the remote controller.
- · A circuit breaker capable of shutting down power supply to the entire system must be installed.
- · Specifications for field wire

The remote controller wiring should be procured locally.

Table 3

	Wire	Size	Length (ft.)
Wiring between units	Wire size and length must comply with local codes.	-	-
Remote controller wiring	Sheathed (2 wire)	AWG 18 - 16	Max.1640*
Wiring to ground terminal	Wire size and length must comply with local codes.	7 4	-

^{*} This will be the total extended length in the system when doing group control.

⚠ CAUTION


- · Arrange the wires and fix a cover firmly so that the cover does not float during wiring work.
- . Do not clamp remote controller wiring together with wiring between units. Doing so may cause malfunction.
- Remote controller wiring and wiring between units should be located at least 2 inch (50mm) from other electric wires.
 Not following this guideline may result in malfunction due to electrical noise.

Indoor Unit Installation


Connection of wiring between units, ground wire and remote controller wiring

Wiring between units and ground wire


1) Remove the electrical wiring box cover (2 screws).



2) Insert the wires including the ground wire into the conduit, and secure the conduit to the hole in the electrical wiring box using a lock nut and the (N) washer for conduit, as shown in the illustration.



- 3) Connect the ground wire to the corresponding terminals.
- 4) Match wire colors with terminal numbers on the terminal block for power supply of indoor and outdoor unit and firmly secure the wires in the corresponding terminals with screws.
- 5) In doing this, pull the wires inside through the hole and fix the wires securely with the included (D) clamp.
- 6) Give enough slack to the wires between the (D) clamp and terminal block for power supply.
- 7) Pull the wires inside through the hole and connect them to the terminal block for remote controller (no polarity). Securely fix the remote controller wiring with the included (D) clamp.
- 8) Give enough slack to the wires between the (D) clamp and the terminal block for remote controller.
- 9) Attach the electrical wiring box cover as before.
- 10) After all wiring connections are done, fill in any gaps in the casing wiring holes with putty or (M) sealing pad (small) thus to prevent small animals or dirt from entering the unit from outside and causing short circuits in the electrical wiring box.



Refrigerant Piping Work

Refer also to the installation manual for the outdoor unit.

↑ WARNING

- . Do not apply mineral oil on flared part.
- Prevent mineral oil from getting into the system as this would reduce the service life of the units.
- · Never use piping which has been used for previous installations. Only use parts which are delivered with the unit.
- . Never install a dryer to this R410A unit in order to guarantee its service life.
- . The drying material may dissolve and damage the system.
- · Incomplete flaring may result in refrigerant gas leakage.

Execute thermal insulation work completely on both sides of the gas and the liquid piping. Otherwise, a water leakage can result sometimes.


Be sure to use insulation designed for use with HVAC systems.


Also, in cases where the temperature and humidity of the refrigerant piping sections might exceed 86°F (30°C) or RH80%, reinforce the refrigerant insulation. (13/16 inch (20mm) or thicker) Condensation may form on the surface of the insulating material.

Before refrigerant piping work, check which type of refrigerant is used. Proper operation is not possible if the types of refrigerant are not the same.

Flaring the pipe end

- 1) Cut the pipe end with a pipe cutter.
- Remove burrs with the cut surface facing downward so that the filings do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring has been done correctly.






2. Refrigerant piping

↑ CAUTION

- Use the flare nut fixed to the main unit. (This is to prevent the flare nut from cracking as a result of deterioration over time.)
- To prevent gas leakage, apply refrigeration oil only to the inner surface of the flare. (Use refrigeration oil for R410A.)
- . Use a torque wrench when tightening the flare nuts to prevent damage to the flare nuts and gas leakage.
 - Align the centers of both flares and tighten the flare nuts 3 or 4 turns by hand, then tighten them fully with a spanner and a torque wrench.



	Piping size	Flare nut tightening torque
Cid-	O.D. 3/8 inch (9.5mm)	24-1/8-29-1/2lbf • ft (32.7-39.9N • m)
Gas side	O.D. 1/2 inch (12.7mm)	36-1/2-44-1/2lbf • ft (49.5-60.3N • m)
Liquid side	O.D. 1/4 inch (6.4mm)	10-1/2-12-3/4lbf • ft (14.2-17.2N • m)

Refrigerant Piping Work

Cautions on piping handling


- · Protect the open end of the pipe from dust and moisture.
- All pipe bends should be as gentle as possible. Use a pipe bender for bending.



Selection of copper and heat insulation materials

When using commercial copper pipes and fittings, observe the following:

- Insulation material: Polyethylene foam
- Heat transfer rate: 0.041 to 0.052W/mK (0.024 to 0.030Btu/fth°F (0.035 to 0.045kcal/mh°C))
- Be sure to use insulation that is designed for use with HVAC Systems.
- · ACR Copper pipe only.




Be sure to insulate both the gas and liquid piping and observe the insulation dimensions as below.

	Piping size	Minimum bend radius	Piping thickness	Thermal insulation size	Thermal insulation thickness
Canada	O.D. 3/8 inch (9.5mm)	1-3/16 inch (30mm) or more		I.D. 15/32-19/32 inch (12-15mm)	
Gas side	O.D. 1/2 inch (12.7mm)	1-9/16 inch (40mm) or more	0.031 inch (0.8mm) (C1220T-O)	I.D. 9/16-5/8 inch (14-16mm)	13/32 inch (10mm) Min.
Liquid side	O.D. 1/4 inch (6.4mm)	1-3/16 inch (30mm) or more	27 371	I.D. 5/16-13/32 inch (8-10mm)	1991 AF

- · Use separate thermal insulation pipes for gas and liquid refrigerant pipes.
- Make absolutely sure to execute thermal insulation works on the pipe-connecting section, after checking for gas leakage, by thoroughly studying the following figures and using the included thermal insulating materials (a) fitting insulation and (H) fitting insulation. Fasten both ends with the (D) clamps.

Piping insulation procedure



↑ CAUTION

Be sure to insulate any field piping all the way to the piping connection inside the unit. Any exposed piping may cause condensation or burns if touched.

Installation of the Decoration Panel

With the wireless remote controller, field setting and trial operation cannot be performed without attaching the decoration panel.

Read "Trial Operation and Testing" before making a trial operation without attaching the decoration panel.

Refer to the installation manual attached to the decoration panel.


After installing the decoration panel, ensure that there is no space between the unit body and decoration panel.

Field Settings

↑ CAUTION

When performing field setting or trial operation without attaching the decoration panel, do not touch the drain pump. This may cause electric shock.

- Make sure the electrical wiring box cover is closed on the indoor and outdoor units.
- Field settings must be made from the remote controller and in accordance with installation conditions.
- Setting can be made by changing the "Mode No.", "FIRST CODE NO." and "SECOND CODE NO."
- The "Field Settings" included with the remote control lists the order of the settings and method of operation.



Setting air outlet direction

 For changing air outlet direction (2 or 3 directions), refer to the installation manual attached to the blocking pad kit (sold separately) or the service manual.
 (SECOND CODE NO. is factory set to "01" for air outlet in 4 directions.)

2. Setting for options

· For settings for options, see the installation manual provided with the option.

Setting air filter sign

- · Remote controllers are equipped with liquid crystal display air filter signs to display the time to clean air filters.
- Change the SECOND CODE NO. depending on the amount of dirt or dust in the room. (SECOND CODE NO. is factory set to "01" for air filter contamination-light.)

Setting	Time until AIR FILTER CLEANING TIME INDICATOR lamp lights up (Long life type)	Mode No.	FIRST CODE NO.	SECOND CODE NO.
Air filter contamination-light	Approx. 2500 hrs		_	01
Air filter contamination-heavy	Approx. 1250 hrs	10 (00)	0	02
Display on		10 (20)		01
Display off	_		3	02


When using wireless remote controllers

 When using the wireless remote controllers, wireless remote controller address setting is necessary. Refer to the installation manual attached to the wireless remote controller.

Field Settings

4. When implementing group control

- When using as a pair unit, you may control up to 16 units with the remote controller.
- In this case, all the indoor units in the group will operate in accordance with the group control remote controller.
- Select a remote controller which matches as many of the functions (swing flap, etc.) in the group as possible.



Wiring Method (Refer to "6. Wiring" on page 11.)

- 1) Remove the electrical wiring box cover.
- Cross-wire the terminal block for remote controller (P1, P2) inside the electrical wiring box. (There is no polarity.)
 (Refer to Table 3 in "6. Wiring" on page 12)

5. 2 remote controllers (controlling 1 indoor unit by 2 remote controllers)

· When using 2 remote controllers, one must be set to "MAIN" and the other to "SUB".

Wiring Method (Refer to "6. Wiring" on page11.)

- 1) Remove the electrical wiring box cover.
- Add remote controller 2 to the terminal block for remote controller (P1, P2) in the electrical wiring box. (There is no polarity.) (Refer to Table 3 in "6. Wiring" on page 12)

Trial Operation and Testing

↑ CAUTION

When performing field settings or trial operation without attaching the decoration panel, do not touch the drain pump. This may cause electric shock.

After finishing the construction of refrigerant piping, drain piping, and electric wiring, conduct trial operation accordingly to protect
the unit.

1. Trial operation and testing

Make sure to install the decoration panel before carrying out trial operation if the wireless remote controller is used.

- · Trial operation should be carried out in either COOL or HEAT operation.
- 1-1. Measure the supply voltage and make sure that it is within the specified range.
- 1-2. In COOL operation, select the lowest programmable temperature; in HEAT operation, select the highest programmable temperature.
- 1-3. Carry out the trial operation following the instructions in the operation manual to ensure that all functions and parts, such as the movement of the louvers, are working properly.
 - · To protect the air conditioner, restart operation is disabled for 3 minutes after the system has been turned off.
- 1-4. After trial operation is complete, set the temperature to a normal level (78°F to 82°F (26°C to 28°C) in COOL operation, 68°F to 75°F (20°C to 24°C) in HEAT operation).
- When operating the air conditioner in COOL operation in winter, or HEAT operation in summer, set it to the trial operation mode using the following method.


Refer to For wired remote controller on page 18.

Refer to For wireless remote controller on page 19.

For wired remote controller

setpoint and room temperature.

- Set to COOL or HEAT operation using the remote controller.
- Press and hold Cancel button for 4 seconds or longer. Service settings menu is displayed.
- Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and "Test Operation" is displayed at the bottom.
- 4) Press On/Off button within 10 seconds, and the test operation starts. Monitor the operation of the indoor unit for a minimum of 10 minutes. During test operation, the indoor unit will continue to cool/heat regardless of the temperature
 - In the case of above-mentioned procedures 3) and 4) in reverse order, test operation can start as well.
- Press Menu/OK button in the basic screen. Main menu is displayed.
- 6) Select Air Flow Direction in the main menu and check that air flow direction is actuated according to the setting. For operation of air flow direction setting, see the operation manual.
- After the operation of air flow direction is confirmed, press Menu/OK button. Basic screen returns.
- Press and hold Cancel button for 4 seconds or longer in the basic screen.
 - Service settings menu is displayed.
- Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and normal operation is conducted.
 - Test operation will stop automatically after 15-30 minutes. To stop the operation, press On/Off button.
- 10) If the decoration panel has not been installed, turn off the power after the test operation.



Trial Operation and Testing

For wireless remote controller


1) Press and select the COOL or HEAT operation.


2) Press twice. "Test" is displayed.

3) Press within 10 seconds, and the test operation starts.

Monitor the operation of the indoor unit for a minimum of 10 minutes. During test operation, the indoor unit will continue to cool/heat regardless of the temperature setpoint and room temperature.

. In the case of above-mentioned procedures 1) and 2) in reverse order, test operation can start as well.







Precautions

1) Refer to "3. How to diagnose for malfunction" if the unit does not operate properly.

2. Test items

Test items	Symptom	Check
Indoor and outdoor units are installed securely.	Fall, vibration, noise	
Is the outdoor unit fully installed?	No operation or burn damage	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
Does the power supply voltage correspond to that shown on the name plate?	No operation or burn damage	
Only specified wires are used for all wiring, and all wires are connected correctly.	No operation or burn damage	
System is properly grounded.	Electrical leakage	
Is wiring size according to specifications?	No operation or burn damage	
Is something blocking the air outlet or inlet of either the indoor or outdoor units?	Incomplete cooling/heating function	
Are refrigerant piping length and additional refrigerant charge noted down?	The refrigerant charge in the system is not clear	
Pipes and wires are connected to the corresponding connection ports / terminal blocks for the connected unit.	No cooling/heating	
Stop valves are opened.	Incomplete cooling/heating function	
Check that the connector of the lead wires of the decoration panel is connected securely.	Louvers do not move	
Indoor unit properly receives wireless remote control commands.	No operation	

Items to be checked at time of delivery

Also review the "Precautions" on page 3

Test items	Check
Are the electrical wiring box cover, air filter, suction grille attached?	
Did you explain about operations while showing the operation manual to your customer?	
Did you hand the operation manual over to your customer?	

Points for explanation about operations

The items with \triangle WARNING and \triangle CAUTION marks in the operation manual are the items pertaining to possibilities for bodily injury and material damage in addition to the general usage of the product. Accordingly, it is necessary that you make a full explanation about the described contents and also ask your customers to read the operation manual.

Note to the installer

Be sure to instruct customers how to properly operate the unit (especially cleaning the filter, operating different functions, and adjusting the temperature) by having them carry out operations while looking at the manual.

3. How to diagnose for malfunction

 If the air conditioner does not operate normally after installing the air conditioner, a malfunction shown in the table below may happen.

Wired remote controller display	Description	
No display	Power outage, power voltage error or open-phase Incorrect wiring (between indoor and outdoor units) Indoor PC-board assembly failure Remote controller wiring not connected Remote controller failure Open fuse or tripped circuit breaker (outdoor unit)	
"Checking the connection. Please stand by." *	Indoor PC-board assembly failure Wrong wiring (between indoor and outdoor units)	

^{* &}quot;Checking the connection. Please stand by" will be displayed for up to 90 seconds following the application of power to the indoor unit. This is normal and does not indicate a malfunction.

■ Diagnose with the display on the liquid crystal display remote controller.

With the wired remote controller

When the operation stops due to a malfunction, operation lamp blinks, and the malfunction code is indicated on the liquid crystal display. In such a case, diagnose the fault contents by referring to Error History in the service settings menu.

In the case of group control, the unit No. is displayed so that the indoor unit with the trouble can be identified.

With the wireless remote controller

(Refer also to the operation manual attached to the wireless remote controller)


When the operation stops due to a malfunction the display on the indoor unit blinks. In such a case, diagnose the fault contents with the error code which can be found by following procedures.

- 1) Press the INSPECTION/TEST OPERATION button, "" is displayed and "0" blinks.
- 2) Press the TEMPERATURE SETTING button and find the unit No. which stopped due to trouble.

Number of beeps 3 short beeps Perform all the following operations 1 short beep Perform (3) and (6) 1 long beep No trouble

- 3) Press the OPERATION MODE SELECTOR button and upper figure of the error code blinks.
- 4) Continue pressing the TEMPERATURE SETTING button until it makes 2 short beeps and find the upper code.
- 5) Press the OPERATION MODE SELECTOR button and lower figure of the error code blinks.
- 6) Continue pressing the TEMPERATURE SETTING button until it makes a long beep and find the lower code.
 - · A long beep indicate the error code.

11.2 <BYFQ60B3W1> Decoration Panel





The English text is the original instruction. Other languages are translations of the original instructions.

Read this manual attentively before installation. Do not throw it away. Keep it in your files for future reference.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin that are specifically designed for the use with the equipment and have them installed by a professional.

If unsure of installation procedures or use, always contact your dealer for advice and information

Before installation

Leave the unit inside its packaging until you reach the installation site.



Rotary fan







Cut off the main power before opening the grille

Refer to the installation manual of the indoor unit for items not described in this manual

NOTE

To the installer



Be sure to instruct the customer how to properly operate the system showing him or her the operation manual of the indoor unit.

Accessories

Installation manual		Wire harness	
Screws (4x)	The state of the s	Temporary latch	17
Fibre glass tube		Tie wrap (7x)	/

Preparation before installation

For this unit, you are able to select air flow directions. To discharge air in 2 or 3 directions, it is necessary to purchase the optional blocking pad kit for sealing air discharge outlets.

Handling of the decoration panel

To prevent any damage to the decoration panel, take care of the

- Never place the decoration panel facing down.
- Never let the decoration panel lean against a wall.
- Never place the decoration panel on a sharp or projecting object.
- Never touch or put pressure on the swing flap in order to prevent malfunction of the swing flap.

Preparing the decoration panel for installation

- Remove the suction grille from the decoration panel.
 - Decoration panel
 - 2 Suction grille

 - Push the suction grille lever (3) inward and open the suction grille (2). (See figure 1)
 - Detach the suction grille from the decoration panel by lifting the suction grille up approximately 45 degrees (A) until the position is reached on which removal of the suction grille is possible (B). (See figure 2)

Installation of the decoration panel to the indoor unit

Refer to the installation manual of the indoor unit for details on installing the indoor unit.

Installation and wiring of the decoration panel.



Make sure to turn off the power supply before wiring!

For installation and wiring of the decoration panel see figure 6.

- Screws
- Α
- Tie wrap
- Latch
 - Socket X36 Socket X80

Tie wrap

В 2

- С
- Latch Tie wrap
- 2 Tie wrap
- Fibre glass tube 3
- Tie wrap
- Attach wire harness from panel accessory set to unit and to other wire harness by two tie wraps (1). (See figure 6-C)
- 2 Lead the wire harness through unit's groove and attach it by tie wrap (1) to the rest of wire harnesses. (See figure 6-B)
- 3 Open two latches (2) and insert the wire harness so it is in the same condition as other wire harnesses. (See figure 6-A
- 4 Insert wire harness into switch box using lower hole, insert two connectors into proper sockets (X36, X80) and secure the wire harness by tie wrap (1). (See figure 6-A)
- 5 Provisionally tighten the 2 supplied screws (1) approximately 5 mm (0.2 in) into the indoor unit as marked in figure. (See figure 6)

- 6 Attach latch (2) from panel accessory set to unit according to figure 3. Then turn this latch up. (See figure 3)
- 7 Slide the panel over the provisionally tightened screws matching the 2 attachment holes (⁽⁾₁).
- 8 Turn decoration panel lever (1) 90 degrees and then turn temporary latch (2) down to secure panel in temporary position. (See figure 3)
- 9 Attach remaining screws and tighten all 4 screws until the thickness of the sealing material between the decoration panel and the indoor unit reduces to 6-8 mm. (See figure 4)
 - Indoor unit
 - 2 Ceiling
 - 3 Sealing material
 - 4 Decoration panel
 - Air outlet
- 10 Pull the fibre glass tube (3) over decoration panel wire harness. Then connect both wire harnesses together and move the fibre glass tube over this connection. Secure the fiber glass tube by two tie wraps (2) according to figure 6-C. Then attach decoration panel wire harness to unit by tie wrap (4). (See figure 6-C.)



Make sure that the swing flap motor lead wire is not caught between the indoor unit and the decoration panel and inbetween the electric component box lid.

Precautions

- Improper tightening of the screws (See figure 5) may cause air to leak into the unit and between the ceiling and the decoration panel (1), resulting in formation of contamination (2) and dew (3).
- If there is a gap remaining between the ceiling and the decoration panel after tightening the screws, re-adjust the indoor unit body height. The indoor unit must be kept leveled and the drain piping kept unaffected.

Installation of the suction grille

Install the suction grille by reversing the procedure shown in "Preparing the decoration panel for installation" on page 1.


- The suction grille may be installed in 4 directions by simply turning it 90 degrees.
- Change the direction when adjusting the direction of the suction grille of multiple units or to comply with the demands of the customer.



Be careful not to get the swing flap motor lead wire get caught when installing the suction grille.

4P345302-1B

11.3 <BYFQ60C2W1W(S)> Decoration Panel





The English text is the original instruction. Other languages are translations of the original instructions.

Read this manual attentively before installation. Do not throw it away. Keep it in your files for future reference.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin that are specifically designed for the use with the equipment and have them installed by a professional.

If unsure of installation procedures or use, always contact your dealer for advice and information.

Before installation


 Leave the unit inside its packaging until you reach the installation site.



Rotary fan









 Refer to the installation manual of the indoor unit for items not described in this manual.

NOTE

To the installer



Accessories



Preparation before installation

For this unit, you are able to select air flow directions. To discharge air in 2 or 3 directions, it is necessary to purchase the optional blocking pad kit for sealing air discharge outlets.

Handling of the decoration panel

To prevent any damage to the decoration panel, take care of the following:

- Never place the decoration panel facing down.
- Never let the decoration panel lean against a wall.
- Never place the decoration panel on a sharp or projecting object.
- Never touch or put pressure on the swing flap in order to prevent malfunction of the swing flap.

Preparing the decoration panel for installation

- 1 Remove the suction grille from the decoration panel.
 - Decoration panel
 - 2 Suction grille
 - 3 Lever
 - Remove the transporting tape from the decoration panel suction grille and flaps.
 - Push the suction grille lever (3) inward and open the suction grille (2). (See figure 1)
 - Detach the suction grille from the decoration panel by lifting the suction grille up approximately 90 degrees (A) until the position is reached on which removal of the suction grille is possible (B). (See figure 2)

Installation of the decoration panel to the indoor unit

Refer to the installation manual of the indoor unit for details on installing the indoor unit.

- 1 Install the decoration panel (See figure 3)
 - 1 Temporary latch
 - 2 Hook
 - 3 Swing flap motor lead wire
 - 4 Piping area
 - 5 Piping side mark
 - Drain area
 - 7 Drain side mark
 - 1 Hold the decoration panel against the indoor unit by matching the piping side and drain side marks on the decoration panel with the position of the piping area and drain area of the indoor unit.
 - 2 Turn 2 panel temporary latches up into the hooks of the indoor unit so the decoration panel is temporarily fixed to the indoor unit. (See figure 3)
 - 3 Make sure that the swing flap motor lead wire isn't caught between the decoration panel and the indoor unit.
 - 4 Attach 4 supplied screws and check whether the decoration panel is properly aligned with the indoor unit and ceiling.
 - 5 Tighten all 4 screws until the thickness between of the sealing material between the decoration panel and the indoor unit reduces to 4-8 mm. (See figure 4)
 - 1 Indoor unit
 - 2 Ceiling
 - 3 Sealing material
 - 4 Decoration panel
 - 5 Air outlet

Precautions

- Improper tightening of the screws (See figure 5) may cause air to leak into the unit and between the ceiling and the decoration panel (1), resulting in formation of contamination (2) and dew (3).
- If there is a gap remaining between the ceiling and the decoration panel after tightening the screws, re-adjust the indoor unit body height. The indoor unit must be kept leveled and the drain piping kept unaffected.
- 2 Wiring of the decoration panel (See figure 6)



Make sure to turn off the power supply before wiring!

- 1 Screws (2)
- 2 Switch box
- 3 Swing flap motor lead wire
- Swing flap motor lead wire fixed by tie wrap to the rest of the wires (See detail in figure 6)
- 5 Connector of the indoor unit PCB (X36A)
- 6 Tie wrap
- 1 Remove the electric components box lid. Loosen 2 screws and slide the electric components box lid in the direction of the arrows.
- 2 Securely connect the connector of swing flap motor lead wire installed on the decoration panel. Attach the swing flap motor lead wire to the rest of the wires firmly by tie wrap (from indoor unit accessory set). (See figure 6)
- 3 Replace the electric components box lid reversing the procedure to remove it.



Make sure that the swing flap motor lead wire is not caught between the indoor unit and the decoration panel and inbetween the electric component box lid.

Installation of the suction grille to decoration panel

Install the suction grille (See figure 7)

- Decoration panel
- 2 Suction grille
- 3 Suction grille hinge (attached to decoration panel)
- Remove the transportation tape which is securing 2 suction grille hinges in place.
- 2 Attach the suction grille to hinges by pressing the hinge and inserting both ends of hinge to holes on the suction grille. (See figure 7)
- 3 Make sure that the suction grille is attached to the decoration panel properly by 2 hinges.
- 4 Close the suction grille by reversing the procedure shown in "Preparing the decoration panel for installation" on page 1.
- The suction grille may be installed in 4 directions by simply turning it 90 degrees.
- Change the direction when adjusting the direction of the suction grille of multiple units or to comply with the demands of the customer.

4P340850-1B

11.4 <BRC1E73> Wired Remote Controller

1. Safety Considerations

The original instructions are written in English. All other languages are translations of the original instructions.

All phases of the field-installation, including, but not limited to, electrical, piping, safety, etc. must be in accordance with manufacturer's instructions and must comply with national, state, provincial and local codes.

Read these SAFETY CONSIDERATIONS carefully before installing the remote controller.

After completing the installation, ensure that the remote controller operates properly during the startup operation.

Train the customer to operate and maintain the remote controller. Inform customers that they should store this Installation Manual with the Operation Manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in electrical shock, fire, or explosion.

Meanings of WARNING, CAUTION, and NOTE Symbols.

⚠ WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
⚠ CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
⚠ NOTE	Indicates situations that may result in equipment or property-damage accidents only.

↑ WARNING

Only qualified personnel must carry out the installation work.

Consult your Daikin dealer regarding relocation and reinstallation of the remote controller.

Improper installation work may result in electric shocks or fire.

Electrical work must be performed in accordance with relevant local and national regulations and with instructions in this installation manual.

Improper installation may cause electrical shocks or fire.

Use only specified accessories and parts for installation work.

Failure to use specified parts may result in electric shocks, fire, or the unit falling.

Do not disassemble, reconstruct, or repair.

Electric shock or fire may occur.

Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires.

Improper connections or installation may result in fire.

Before touching electrical parts, confirm the power-off to the unit.

↑ CAUTION

Keep water out of the remote controller.

To avoid electric shock due to entry of water or insects, fill the wiring through-hole with putty.

Do not wash the remote controller with water as it may result in electrical shocks or fire.

Do not touch the remote controller buttons with wet fingers.

Touching the buttons with wet fingers can cause an electric shock.

Do not install the remote controller in the following locations:

- (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate.
- (b) Where corrosive gas, such as sulfurous acid gas, is produced.
- (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to
- (d) Where flammable gas may leak, where there is carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- (e) High temperature area or direct flame.

malfunction.

- Overheating and/or fire can occur.
- (f) Moist area, where there is exposure to water. If water enters the inside of the remote controller, it may cause electric shock and electrical components may fail.

⚠ NOTE

Install the control wires for the indoor and the remote controller at least 3.5 feet (1 meter) away from televisions or radios to prevent image interference or noise. Depending on the radio waves, a distance of 3.5 feet (1 meter) may not be sufficient to eliminate the noise.

When remote controller's temperature sensor is used, select the installation location as per the following:

- A place where average temperature in the room can be detected.
- · A place where it is not exposed to direct sunlight.
- · A place where it is far away from any heat source.
- · A place where it is not affected directly by outside air.

2. Accessories


The following accessories are included.

Drywall screw	Drywall anchor	Wire tie	Operation manual	Installation manual	Wiring retainer
O _D	C. M. Hall	D Company			
(2 pcs.)	(2 pcs.)	(1 pc.)	(1 pc.)	(1 pc.)	(1 pc.)

3. Remote Controller Installation Procedure

- 3-1 Determine where to install the remote controller.

 Make sure to follow the Safety Considerations when determining the location.
- 3-2 If the control wire for the remote controller is to be routed from the rear, consider the location of the access hole in the lower case for making a hole in the wall.




3-3 Remove upper case.

Insert a screwdriver in the recess of lower case to remove the upper case (2 points).


Remote controller printed-circuit board is installed on the upper case. Be careful not to damage the printed-circuit board with the screwdriver.

Be careful not to let dust or moisture touch the printed-circuit board.




3-4 Determine the location where the wiring will enter the remote controller (back, left side, top left, top center).

3-4-1 Back outlet




Cut off resin area (notched area).

3-4-2 Left outlet




Cut the plastic at the notched area and remove any remaining burrs.

3-4-3 Top left outlet



Cut the plastic at the notched area and remove any remaining burrs.

3-4-4 Top center outlet



Cut the plastic at the notched area and remove any remaining burrs.

3-5 Install wiring.


MOTE -

- 1. Switch box and control wiring are filed supplied.
- 2. Do not touch the remote controller printed-circuit board.

Wiring Specifications

Wiring Type	Non-shielded, 2-conductor, stranded copper wire
Wiring Size	AWG-18
Wiring Length	Maximum 1640 feet (500 m)

Prepare the wiring for connection to the remote controller following these instructions:




Length of jacket to be removed:


- Approx. 6 inch (150 mm) for top left outlet
- Approx. 8 inch (200 mm) for top center outlet

Connect the terminals (P/P1, N/P2) of the remote controller to the terminals (P1, P2) of the indoor unit. (P1 and P2 are not polarity sensitive.)


3-5-1 Back outlet




3-5-2 Left outlet



3-5-3 Top left outlet



3-5-4 Top center outlet






 To prevent electrical noise and possible communication errors, avoid installing the remote controller wiring parallel to or in the vicinity of line voltage circuits.

3-6 Installation procedure for the lower case.

When wiring the remote controller through the top center or rear access points, attachment of the wire to the lower case is required before it is wall mounted. Closely follow the wiring procedures.


3-6-1 Wall installation

Secure by using furnished drywall anchors and screws (2 pcs.).



3-6-2 Switch box installation

Secure by using field supplied machine screws (2 pcs.).




MOTE

- . Install the control on a flat surface only.
- To prevent deformation of the lower case, avoid over-tightening the installation screws.


3-7 Install the upper case.

- Align the upper case with tabs of the lower case (6 points), insert and install the upper case.
 Install the wiring with care to prevent pinching.
- Peel off the protective membrane which overlays the upper case.



4. Functions and Menu Items of Remote Controller Buttons

4-1 Functions and menu items



- (1) Operation mode selector button Used to change the mode.
- (2) Fan speed control button Used to change the fan control.

(3) Menu/OK button

- Used to access the main menu. (For details of the main menu, see the operation manual.)
- Used to enter the item selected.

Main Menu

- *Airflow Direction
- *Individual Airflow Direction
- *Ventilation

Schedule

Off Timer

Celsius / Fahrenheit

Filter Auto Clean

Maintenance Information

Configuration

Current Settings

Clock & Calendar

Daylight Saving Time

Language

*Depending on connected model

(4) Up button ▲

- Used to raise the setpoint temperature.
- The previous menu items will be highlighted.

(The highlighted items will be scrolled continuously when the button is pressed continuously.)

· Used to change the selected item.

(5) Down button ▼

- Used to lower the setpoint temperature.
- Items below the currently selected item will be highlighted.

(The highlighted items will be scrolled continuously when the button is pressed continuously.)

Used to change the selected item.

(6) Right button ▶

- Used to highlight items to the right of the currently selected item.
- Display contents are changed to next screen per page.

(7) Left button ◀

- Used to highlight items to the left of the currently selected item.
- Display contents are changed to previous screen per page.

(8) On/Off button

Press once to operate, and press once again to stop.

(9) Operation lamp

Green lamp lights up during operation. The lamp will flash if a malfunction occurs.

(10) Cancel button

- Used to return to the previous screen.
- Press and hold this button for 4 seconds or longer to display service settings menu.

(11) LCD (with backlight)

The backlight will illuminate for approximately 30 seconds by pressing any operation button.

Service Settings menu

Test Operation Maintenance Contact Field Settings


- *Energy Saving Options Prohibit Function
- Min Setpoints Differential
- *Outdoor unit AirNet Address Error History
- *Indoor Unit Status
- *Outdoor Unit Status Forced Fan ON Switch Main Sub Controller
- Filter Indicator *Brush/Filter Ind.
- *Disable Filter Auto Clean

MOTE ⋅

- . Operate the button while the backlight is illuminated.
- When one indoor unit is controlled by two remote controllers (main / sub) only the first controller to be accessed by the user will illuminate it's backlight.

4-2 Button menu display descriptions

<Service settings menu screen>



^{*}Depending on connected model

5. Power-on

- · Check for completion of indoor/outdoor unit wiring.
- Ensure that covers have been replaced on electrical component boxes for both indoor and outdoor units prior to restoring power.


5-1 The following message is displayed after power-on. Checking the connection. Please stand by.

When the above message is displayed, the backlight will not be ON.

In the case that 1 indoor unit is controlled by 2 remote controllers:

Make sure to set the sub remote controller when the above message is displayed. Hold **Mode** button for 4 seconds or longer to set

When the display is changed from "Main RC" to "Sub RC" the setting is completed.




5-2 Basic screen is displayed.

NOTE -

If sub remote controller is not set at power-on in the case of one indoor unit controlled by two remote controllers, **Error Code: U5** is displayed in the connection checking screen.

Select the sub remote controller by pressing **Mode** button of either one of the remote controllers for 4 seconds or longer.

If the basic screen is not displayed in 2 minutes after the "Sub RC" is displayed, shut off the power supply and check the wiring.



NOTE

When selecting a different language, refer to Chapter 12. Language.

(See page 21.)

6. Field Settings


- 6-1 Press and hold Cancel button for 4 seconds or longer. Service settings menu is displayed.
- **6-2** Select **Field Settings** in the Service Settings menu, and press **Menu/OK** button. Field settings screen is displayed.
- 6-3 Highlight the mode, and select desired "Mode No." by using ▲▼ (Up/Down) button.
- 6-4 In the case of setting per indoor unit during group control (When Mode No. such as 20, 21, 22, 23, 25 are selected), highlight the unit No. and select "Indoor unit No." to be set by using ▲▼ (Up/Down) button. (In the case of group setting, this operation is not needed.)


In the case of individual setting per indoor unit, current settings are displayed. And, SECOND CODE NO. " - " means no function.

6-5 Highlight SECOND CODE NO. of the FIRST CODE NO. to be changed, and select desired "SECOND CODE NO." by using ▲▼ (Up/Down) button. Multiple identical mode number settings are available.

In the case of setting for all indoor units in the remote control group, available SECOND CODE NO. is displayed as " * " which means it can be changed.

When SECOND CODE NO. is displayed as " - ", there is no function.






<Service settings screen>


In the case of group total

In the case of individual





- 6-6 Press Menu/OK button. Setting confirmation screen is displayed.
- 6-7 Select Yes and press Menu/OK button. Setting details are determined and field settings screen returns.
- 6-8 In the case of multiple setting changes, repeat "6-3" to "6-7".
- 6-9 After all setting changes are completed, press Cancel button twice.
- **6-10** Backlight goes out, and [Checking the connection. Please stand by.] is displayed for initialization. After the initialization, the basic screen returns.



NOTE

- Installation of optional accessories on the indoor unit may require changes to field settings.
 See the manual of the optional accessory.
- For field setting details related to the indoor unit, see installation manual shipped with the indoor unit.

Mode No. (Note 1)	First Code No.	Description	Second Code No. (Note 2) (Items in bold are factory default settings)			
			01	02	03	04
10 (20)	2	Priority of thermistor sensors for space temperature control	The return air thermistor is primary and the remote controller thermistor is secondary.	The remote controller thermistor is not utilized. Only the return air thermistor will be utilized.	Only the remote controller thermistor will be utilized.	
	5	Room temperature value reported to multizone controllers	Return air thermistor	Thermistor designated by 10-2 above (Note 3)	-	7 <u></u> 1
12 (22)	2	Thermo-on/off deadband (Note 4)	2F (1C)	1F (0.5C)	. 	3 5 - 10 - 1 3
1c	1	Thermistor sensor for auto changeover and setback control by the remote controller	Utilize the return air thermistor	Utilize the remote controller thermistor		·
	3	Access permission level setting	Level 2	Level 3		A
1e	2	Setback availability	N/A	Heat only	Cool only	Cool/Heat

- Notes) 1. Field settings are normally applied to the entire remote control group, however if individual indoor units in the remote control group require specific settings or for confirmation that settings have been established, utilize the mode number in parenthesis.
 - 2. Any features not supported by the connected indoor unit will not be displayed.
 - When mode 10-2-01 is selected, only the return air temperature value is reported to the multizone controller.
 - 4. The actual default deadband value will depend upon the indoor unit model.


7. Test Operation

Also see installation manuals furnished with the indoor unit and the outdoor unit.


- Verify that the wiring of the indoor unit and the outdoor unit is completed.
- Ensure that covers have been replaced on electrical component boxes for both indoor and outdoor units prior to restoring power.
- After refrigerant piping, drain piping and electric wiring are completed, clean inside of the indoor unit and decorative panel.
- Perform the test operation according to following procedure.
- To protect the compressor, apply power to the outdoor unit at least 6 hours prior to test operation.
- Set the remote controller display mode to standard or detailed display mode. Refer to Operation Manual for the setting method.

Notes for backlight


- The backlight will be ON for 30 seconds by pressing any button.
- The initial push of the button will only turn on the backlight. While the backlight is turned on, the buttons assigned functionality will be available.
- 7-1 Set the operation mode to cooling by using the remote controller.
- 7-2 Press and hold Cancel button for 4 seconds or longer. Service settings menu is displayed.
- 7-3 Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and message "Test Operation" is displayed at the bottom.



<Service settings menu screen>



- 7-4 Press On/Off button within 10 seconds, and the test operation starts. Monitor the operation of the indoor unit for a minimum of 10 minutes. During test operation, the indoor unit will continue to cool regardless of the temperature setpoint and room temperature.
 - * Note) In the case of above-mentioned procedures 7-3 and 7-4 in reverse order, test operation can start as well.
- 7-5 Press Menu/OK button in the basic screen. Main menu is displayed.
- 7-6 In the case of a model having airflow direction function, select
 Airflow Direction in the main menu and check that airflow direction is actuated according to the setting. For operation of airflow direction setting, see the operation manual.
- 7-7 After the operation of airflow direction is confirmed, press Menu/OK button. Basic screen returns.
- 7-8 Press and hold Cancel button for 4 seconds or longer in the basic screen. Service settings menu is displayed.
- 7-9 Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and normal operation is conducted.
 * Note) The test operation will automatically finish in 30 minutes.
- 7-10 Check the functions according to the operation manual.
- 7-11 When the decorative panel is not installed, shut off the power supply after the test operation finishes.
- If construction activities are planned within the space following the test operation procedure, recommend to the customer that the indoor unit is not operated to prevent contamination from paints, drywall dust and other airborne materials.




MOTE


- If operation is not possible due to a malfunction, refer to following Failure diagnosis method
- After the test operation finishes, check whether the error code history is displayed on the maintenance information screen of the main menu according to the following procedure.
- 7-12 Press Menu/OK button in the basic screen. Main menu screen is displayed.
- 7-13 Select Maintenance Information in the main menu, and press Menu/OK button.
- 7-14 Maintenance information screen is displayed. Check whether the error code history is displayed on the screen.
 - * If no error code history is displayed following this procedure the system has normally completed the test operation mode.
- 7-15 If the error code history is displayed, conduct the failure diagnosis referring to <Error code list> in the installation manual of the indoor unit.
 After the failure diagnosis finishes, press and hold On/Off button for 4 seconds or longer in the maintenance information screen to erase the error code history.


Failure diagnosis method

- Whenever the remote controller display is blank or displays [Checking the connection. Please stand by.], troubleshoot the system with the items in the Description column of the following table.
- If an error occurs, CODE is displayed on the LCD as shown to the right.
 Conduct the failure analysis referring to <Error code list> in the installation manual of the indoor unit.
 When the unit No. which detected the error during group control is confirmed, refer to Chapter 8: Procedure

for Checking Error History.









Remote controller display	Description				
No display	Power outage, power voltage error or open-phase Incorrect wiring (between indoor and outdoor units) Indoor printed-circuit board assembly failure Remote controller wiring not connected Remote controller failure Open fuse or tripped circuit breaker (outdoor unit)				
Checking the connection. Please stand by. *	Indoor printed-circuit board assembly failure Wrong wiring (between indoor and outdoor units)				

^{* [}Checking the connection. Please stand by.] will be displayed for up to 90 seconds following the application of power to the indoor unit. This is normal and does not indicate a malfunction.

8. Procedure for Checking Error History

- 8-1 Press and hold Cancel button for 4 seconds or longer in the basic screen. Service settings menu is displayed.
- 8-2 Select Error History in the service settings menu, and press Menu/OK button. The error history menu screen is displayed.
- 8-3 Select RC Error History in the error history menu, and press Menu/OK button.
 Error codes and unit No. can be confirmed in the RC error history
- **8-4** In the error history, the 10 most recent items are displayed in order of occurrence.
- 8-5 Press Cancel button in the RC error history screen 3 times. The basic screen returns.

8-1 <Basic screen>


<Service settings menu screen>











9. Adding Maintenance Contact Information

- · Registration of the maintenance contact.
- 9-1 Press and hold Cancel button for 4 seconds or longer in the basic screen. Service settings menu is displayed.
- 9-2 Select Maintenance Contact in the service settings menu, and press Menu/OK button. Maintenance contact menu screen is displayed.
- **9-3** Select Maintenance Contact, and press Menu/OK button.
- 9-4 Enter the telephone number.

 Scroll through the numbers by using

 ▲▼ (Up/Down) buttons. Start from the left side. Blank digits should remain as
- 9-5 Press Menu/OK button. Setting confirmation screen is displayed.
- 9-6 Select Yes and press Menu/OK button.
 Setting details are saved and service settings menu screen returns.
- 9-7 Press Cancel button once.
 The basic screen returns.

9-1 <Basic screen>
<Service settings menu screen>















9-5 Maintenar



Press Menu/OK button.

<Setting confirmation screen>





4

<Service settings menu screen>


10. Confirming Registered Details

10-1 Press Menu/OK button in the basic screen.

Main menu is displayed.

Select Maintenance Information in the main menu, and press Menu/OK button.

10-2 Press Cancel button twice. The basic screen returns.



11. Clock & Calendar

11-1 Press Menu/OK button in the basic screen.


Main menu is displayed.

Select Clock & Calendar in the main menu, press Menu/OK button.

11-2 Press ▲▼ buttons to

select Date & Time on the clock & calendar screen.

* The date & time screen will appear when Menu/OK button is pressed.




11-3 Select year, month, day and time by using ◀► (Left/Right) button and set by using ▲▼ (Up/Down) button in the date & time screen. Press and hold the button for continuous change of the numeric value.

* Day of the week is set automatically.

11-4 Press Menu/OK button.
Setting confirmation screen is displayed.

11-5 Select Yes and press Menu/OK button. Setting details are saved and basic screen returns.

* If power outage exceeds 48 hours, reset is needed.




12. Language

12-1 Press Menu/OK button in the basic screen.

Main menu is displayed.
Select Language in the main menu, press Menu/OK button.


12-2 Press ▲▼ (Up/Down) buttons to select Language on the language screen. English/Français/Español Press Menu/OK button.



21

3P243521-7L

11.5 <BRC082A41W, BRC082A42W(S)> Wireless Remote Controller



Contents

Safety considerations	1
Before installation	1
Accessories	1
Note to the installer	1
Remote controller installation	2
Installing the wireless remote controller	2
Determination of address and MAIN/SUB remote controller	2
Setting procedure	2
Installation of the transmitter board	3
Installation of the decoration panel	3
Installation of the receiver in case of BRC082A41W	4
Installation of the receiver in case of BRC082A42W/S	4
Field setting	-



READ THIS MANUAL ATTENTIVELY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. KEEP IT IN YOUR FILES FOR FUTURE REFERENCE.

IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORTCIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.

IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DAIKIN DEALER FOR ADVICE AND INFORMATION.

The English text is the original instruction. Other languages are translations of the original instructions.

Safety considerations

Please read this "Safety considerations" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure at start up operation that the unit operates properly. Please instruct the customer how to operate the unit and how to perform maintenance.

Meaning of caution symbols



Failure to observe these instructions properly may result in property damage or personal injury.

Information classified as **NOTE** contains instructions to ensure proper use of the equipment.



- Refer also to the installation manual supplied with the indoor unit and the installation manual supplied with the decoration panel.
- There is only 1 possible installation position of this kit into the decoration panel. It is therefore recommended that installation orientation of the decoration panel is confirmed prior to installation of this kit
- Ensure that nothing interrupts operation of the wireless remote controller.
- Ensure that the signal from the remote controller can easily be transmitted.
- Ensure that the operation display lamp and other indicator lamps can easily be seen.
- Ensure that there is neither a source of light nor a fluorescent lamp near the receiver.
- Ensure that the receiver is not exposed to direct sunlight.

Before installation

Accessories

See figure 1. Check if the following accessories are included with your kit.

- 1 Receiver
- 2 Transmitter board
- 3 Wireless remote controller
- 4 Remote controller holder
- 5 Alkaline battery of type AAA.LR03
- 6 Unit number label
- 7 Screw for installing remote controller holder
- 8 Installation manual
- 9 Operation manual
- 10 Clamp
- 11 Plastic spacer
- 12 Plastic band
- 13 Sealing

Note to the installer

Be sure to instruct the customer how to properly operate the system showing him/her the supplied operation manual.

Remote controller installation

Installing the wireless remote controller


- Do not throw the remote controller or subject it to powerful shocks and do not store the remote controller where it may be exposed to moisture or direct sunlight.
- When operating, point the transmitting part of the remote controller in the direction of the receiver.
- The direct transmitting distance of the remote controller is approximately 23ft (7m).
- The signal cannot be transmitted if something such as curtains blocks the receiver and the remote controller.

Installing to a wall or a pillar

- 1 Turn on all the fluorescent lamps in the room, if any, and find a location where the remote controller signals are properly received by the indoor unit (within 23ft (7m)).
- 2 Fix the remote controller holder with the supplied screws.




3 Mount the remote controller on to the hook of the remote controller holder and then push it toward the wall.




How to insert the batteries

 Slide the back cover to take it off.



 Insert 2 dry batteries AAA. LR03 (alkaline).



3 Replace the back cover.

Determination of address and MAIN/SUB remote controller

- If setting multiple wireless remote controllers to operate in one room, perform address setting for the receiver and the wireless remote controller.
- If using both a wired remote controller and a wireless remote controller with one indoor unit, change the MAIN/ SUB switch of the transmitter board.

Setting procedure

Setting the transmitter board

Set the wireless address switch (SS2) on the transmitter board according to the table below.

	Unit No.				
	1	2	3		
Wireless address switch (SS2)	1 2 3	1 2 3	1 2 3		

When using both a wired and a wireless remote controller for 1 indoor unit, the wired controller should be set to MAIN. Therefore, set the MAIN/SUB switch (SS1) of the transmitter board to SUB.

	MAIN	SUB
MAIN/SUB switch (SS1)	■ ⊗	_ ≤ _ ≤

Setting the address of the wireless remote controller

(See figure 3)

- A Field Set mode
- B Address (is factory set to " ! ")
- C Display setting

Setting from the remote controller

- Hold down the 聞 button and the 祾/TEST button for at least 4 seconds to enter the Field Set mode. (Indicated in the display area in the figure.)
- 2 Press the PAN button and select an appropriate display setting (%/s). Each time the button is pressed the display switches between " β" and " b". Refer to "Display setting %/s" on page 3 for full comprehension of this feature.



Address can be set from 1 to 6, but set it to 1-3 and to same address as the receiver. (The receiver does not work with address 4-6.)

- 4 Press the RESERVE button to confirm the setting.
- 5 Press the \overline{\

Display setting 8/b

The wireless remote controller has 2 possible display settings.

The standard setting \Re permanently indicates all operational items whereas the multi system display setting b indicates operations for a limited period of time after execution of settings only.

In case the target indoor unit is simultaneously being controlled;

- by another unit in group control,
- by a wired remote controller,
- by a centralized remote controller.

the indoor unit sometimes does not respond to ON/OFF and temperature setting commands from the wireless remote controller.


In order not to confuse the customer with possible discrepancies between the wireless remote controller display and the actual operation state of the indoor unit, it is recommended to set the display on the wireless remote controller to ${\bf b}$ in such a control configuration.

Check what setting the customer prefers and adjust the display setting accordingly.

Display setting	Remote controller display	Result of the display setting in case the target indoor unit is simultaneously being controlled by more than 1 device
ጸ: standard	All operational items are permanently displayed.	In the operation mode changeover, temperature setting or the like are carried out from the wireless remote controller, the indoor unit rejects the instruction. (Signal receiving sound, 1 long beep or 3 short beeps) As a result, a display discrepancy between the operation state of the indoor unit and the indication on the wireless remote controller display occurs.
გ: multi system	Operations only remain displayed for a short time after execution of the commands.	Since the indications on the wireless remote controller are turned off, a discrepancy such as described above no longer occurs.

Affix the unit number label

Affix corresponding unit number labels onto both air outlet of the decoration panel and onto back of the wireless remote controller.



NOTE

Set the Unit No. of the receiver and the wireless remote controller to be equal. If the settings differ, the signal from the remote controller cannot be transmitted.

Installation of the transmitter board

(See figure 2)

- 1 Electrical wiring box cover
- 2 Transmitter board
- 3 Shorter wire harness
- 4 Longer wire harness
- 5 Clamp
- 6 Electrical wiring box
- 7 Plastic spacer
- 1 Cut off the power supply.
- Remove the electrical wiring box cover as described in the installation manual supplied with the indoor unit.
- 3 Attach four plastic spacers (7) to the transmitter board (2) and install it in the electrical wiring box (6).
- 4 Connect the shorter wire harness from the X2A connector on transmitter board (2) to X24A connector on the printed circuit board in the electrical wiring box of indoor unit. Lay down the shorter wire harness as shown in the figure 2.
- 5 When the receiver is installed bring the longer wire harness to the electrical wiring box of indoor unit and connect it to X1A connector on the transmitter board.
- 6 Clamp the wire harness by the clamp (5) as shown in the figure 2.

Installation of the decoration panel

Install the decoration panel as described in the installation manual supplied with the decoration panel.

NOTE


42

Make sure that the wire harness (longer one) from the transmitter board is not caught between the indoor unit and the decoration panel, and between the ceiling and the decoration panel.


The installation process of the receiver depends on used decoration panel.


Installation of the receiver in case of BRC082A41W

- Remove the suction grille as described in the installation manual supplied with the decoration panel.
- 2 Detach the brand name plate part of the decoration panel piece, before attaching the decoration panel. This part is not needed hereafter.
- 3 Remove the electrical wiring box cover as described in the installation manual supplied with the indoor unit. (Be sure to turn off power, before removing the electrical wiring box cover.)



4 Pass the wire harness from the receiver through the wiring hole of the decoration panel. Then attach the receiver to the decoration panel. Lead the wire harness to the electrical wiring box on the indoor unit and connect it to X1A connector on the transmitter board.






Remove the screw and input the plastic band. Then screw it back. The wire harness goes through the plastic band.


Clamp the wire harness from the receiver to other cables with the clamp.

Installation of the receiver in case of BRC082A42W/S


- Remove the suction grille as described in the installation manual supplied with the decoration panel.
- 2 The receiver (1) should be installed in the corner that is surrounded by 2 square marks on one side and 1 square mark on the other, as shown in the illustration. Then remove the plastic corner cover.





3 Break off the plastic cover from back side of the panel.



4 Pass the wire harness through the hole and insert the cover into its position and screw it.







Field setting

If optional accessories are mounted on the indoor unit, the indoor unit setting may have to be changed. Refer to the instruction manual (option handbook) for each optional accessory.

(See figure 4)

- A Mode No.
- B Field Set mode
- C First code No.
- D Second code No.

Procedure

- 1 When in normal mode, hold down the \overline{6}/TEST button for at least 4 seconds to enter the Field Set mode.
- 2 Select the desired Mode No. with the MODE button.
- 3 Press the button and select the First code No.
- 4 Press the [∇]_∞ button and select the Second code No.
- 5 Press the RESERVE button to confirm the settings.
- 6 Press the 祾/TEST button to quit the Field Set mode and to return to normal display again.

Example

If the time to clean air filter is set to "Filter Contamination-Heavy", set Mode No. to "", First code No. to "", and Second code No. to "02".

Mode	First	2 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7			Second	code No.		
No.	code No.	Description of setting		ı) (æ	03
10	a	Sets operation time until AIR FILTER CLEANING TIME INDICATOR lamp lights up. (When dirt and dust levels are high, change the setting to "Filter Contamination-Heavy".)	Long-life filter	Light	±2,500 hrs.	Heavy	±1,250 hrs.	E
	3	Changes AIR FILTER CLEANING TIME INDICATOR lamp on/off settings.	c	On	Off		ŧ	
	а	Setting air outlet velocity. This setting is to be changed in function height (H).	7075	7/8ft .7m)		≤9-13/16ft l≤3.0m)	9-13/16 <h≤11-1 2ft<br="">(3.0<h≤3.5m)< td=""></h≤3.5m)<></h≤11-1>	
13	ŧ	Selection of air flow direction. This setting is to be changed when blocking pad optional kit is used.		4-wa	y flow	3-wa	y flow	2-way flow
	ч	Airflow direction range setting. This setting is to be changed when rang flap movement needs to be changed.	Up	per	Med	dium	Lower	

NOTE

Factory settings of the Second code No. are marked in grey backgrounds.

Do not use any settings not listed in the table.

For group control with a wireless remote controller, initial settings for all the indoor units of the group are equal. (For group control, refer to the installation manual supplied with the indoor unit for group control.)

6

3P444567-1

11.6 **Outdoor Unit**

Contents

Safety Considerations	1
Accessories	3
Precautions for Selecting a Location	3
Precautions on Installation	4
Outdoor Unit Installation Diagram	4
Installation Space Requirements	5
Outdoor Unit Installation	Ę
Installing the outdoor unit	
2. Drain work	(
3. Flaring the pipe end	6

4. Refrigerant piping	6
5. Pressure test and evacuating system	7
Refilling refrigerant	8
7. Refrigerant piping work	8
Wiring	9
Facility Setting (cooling at low outdoor temperature) 1	11
Pump Down Operation 1	11
Trial Operation and Testing1	12
1. Trial operation and testing	12
2. Test items	12

Safety Considerations

Read these Safety Considerations for Installation carefully before installing an air conditioner or heat pump. After completing the installation, make sure that the unit operates properly during the startup operation.

Instruct the user on how to operate and maintain the unit. Inform users that they should store this installation manual with the operation manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electric shock, fire, or explosion.

Meanings of DANGER, WARNING, CAUTION, and NOTE

↑ DANGER Indicates an imminently hazardous

situation which, if not avoided, will result in death or serious injury.

↑ WARNING ……… Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

↑ CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTE Indicates situations that may result in equipment or property-damage accidents only.

A DANGER

- Refrigerant gas is heavier than air and replaces oxygen. A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death. Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.

- · If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.
- · After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- · Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.
- · Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.

/ WARNING -

- · Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- · When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency
- · Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling
- · Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.

- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- · Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a fuse, a circuit breaker, a disconnect or a GFCI.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may occur.

A CAUTION -

- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately
 after operation as the refrigerant pipes may be hot or
 cold, depending on the condition of the refrigerant flowing
 through the refrigerant piping, compressor, and other
 refrigerant cycle parts. Your hands may suffer burns or
 frostbite if you touch the refrigerant pipes. To avoid injury,
 give the pipes time to return to normal temperature or, if
 you must touch them, be sure to wear proper gloves.
- Install drain piping to proper drainage. Improper drain piping may result in water leakage and property damage.
- · Insulate piping to prevent condensation.
- Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R410A in the system must be kept clean, dry, and tight.
 - (a) Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.

- (b) Tight R410A does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection again harmful ultraviolet radiation. R410A can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation. Read the chapter Refrigerant Piping Work and follow the procedures.
- Since R410A is a blend, the required additional refrigerant must be charged in its liquid state. If the refrigerant is charged in a state of gas, its composition can change and the system will not work properly.
- The indoor unit is for R410A. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit far away from fluorescent lamps as much as possible.
- Indoor units are for indoor installation only. Outdoor units can be installed either outdoors or indoors. This unit is for indoor use.
- Do not install the air conditioner or heat pump in the following locations:
- (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate and fall off or result in water leakage.
- (b) Where corrosive gas, such as sulfurous acid gas, is produced.
 Corroding copper pipes or soldered parts may result
 - Corroding copper pipes or soldered parts may result in refrigerant leakage.
- (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
- (d) Where flammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.

MOTE -

- The outdoor unit should be positioned where the unit and power supply wires (breaker panel to outdoor unit) are at least 10ft (3m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 10ft (3m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with conventional refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R410A, the refrigerant may deteriorate.
- This air conditioner or heat pump is an appliance that should not be accessible to the general public.
- As design pressure is 604 psi, the wall thickness of fieldinstalled pipes should be selected in accordance with the relevant local, state, and national regulations.

Accessories

(A) Installation manual		1	B Drain socket This is at the bottom of the packaging.		1
© Drain cap (1)	09/12 class	4	D Drain cap (2)	09/12 class	2
	15/18 class	6		15/18 class	3
© Warranty	'	1		,	

Precautions for Selecting a Location

- 1) Choose a place solid enough to bear the weight and vibration of the unit, where the operating sound will not be amplified.
- Choose a location where the hot air discharged from the unit or the operating sound will not cause a nuisance to the neighbors of the user.
- 3) Avoid locations, such as near bedrooms, where the operating sound may cause disturbance.
- 4) There must be sufficient space to carry the unit into and out of the site.
- 5) There must be sufficient space for air passage and no obstructions around the air inlet and the air outlet.
- 6) The site must not be prone to flammable gas leaks in the surrounding area.
- 7) In coastal areas or other places with a salty atmosphere or one containing sulfate gas, corrosion may shorten the life of the air conditioner.
- 8) Since water will flow from the drain of the outdoor unit, do not place under the unit anything which must be kept away from moisture.

NOTE

Cannot be installed suspended from a ceiling or stacked.

⚠ CAUTION -

When operating the air conditioner in a low outdoor ambient temperature, be sure to follow the instructions described below.


- To prevent exposure to wind, install the outdoor unit with its suction side facing the wall.
- Never install the outdoor unit at a site where the suction side may be exposed directly to wind.
- To prevent exposure to wind, it is recommended to install a baffle plate on the air discharge side of the outdoor unit.
- In heavy snow areas, select an installation site where the snow will not affect the unit.
- Construct a large canopy.
- Construct a pedestal




Install the unit high enough off the ground to prevent burying

Precautions on Installation

- Check the strength and level of the installation surface so that the unit does not cause any operating vibrations or noise after installation.
- Fix the unit in place securely using foundation bolts, as in the figure. (Prepare 4 sets of 5/16 inch (M8) or 3/8 inch (M10) foundation bolts, nuts and washers; all separately available.)
- It is best to screw in the foundation bolts until their ends are 3/4 inch (20mm) from the foundation surface.




Outdoor Unit Installation Diagram



Installation Space Requirements

- Where a wall or other obstacle is in the path of the outdoor unit's intake or exhaust airflow, follow the installation space requirements below.
- For any of the below installation patterns, the wall height on the outlet side should be 47-1/4 inch (1200mm) or less.



Outdoor Unit Installation

1. Installing the outdoor unit

- 1) When installing the outdoor unit, refer to "Precautions for Selecting a Location" and the "Outdoor Unit Installation Diagram".
- 2) If drain work is necessary, follow the procedures on the next page.


09/12 class

2. Drain work

- If the drain port is covered by a mounting base or floor surface, place additional foot bases of at least 1-1/4 inch (30mm) in height under the outdoor unit's feet.
- In cold areas, do not use a drain socket, drain caps (1,2) and a drain hose with the outdoor unit. (Drain water may freeze, impairing heating performance.)
- 1) Attach © drain cap (1) and ® drain cap (2).
- 2) Attach ® drain socket.

3. Flaring the pipe end

- 1) Cut the pipe end with a pipe cutter.
- Remove burrs with the cut surface facing downward, so that the filings do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring has been done correctly.



15/18 class

A	N	Flare tool for R410A	Convent	ional flare tool
ATT IN		Clutch-type	Clutch-type (Rigid-type)	Wing-nut type (Imperial-type
4 Z/Die	A	0-0.020 inch (0-0.5mm)	0.039-0.059 inch (1.0-1.5mm)	0.059-0.079 inch (1.5-2.0mm)

MARNING

- · Do not apply mineral oil to the flare.
- Prevent mineral oil from getting into the system as this would reduce the service life of the units.
- · Never use piping which has been used for previous installations. Only use parts which are delivered with this unit.
- · Never install a dryer to this R410A unit in order to guarantee its service life.
- The drying material may dissolve and damage the system.
- · Incomplete flaring may result in refrigerant gas leakage.

4. Refrigerant piping

⚠ CAUTION


- · Use the flare nut fixed to the main unit. (This is to prevent the flare nut from cracking as a result of deterioration over time.)
- To prevent gas leakage, apply refrigeration oil only to the inner surface of the flare. (Use refrigeration oil for R410A.)
- . Use a torque wrench when tightening the flare nuts to prevent damage to the flare nuts and gas leakage.
- Align the centers of both flares and tighten the flare nuts 3 or 4 turns by hand, then tighten them fully with a spanner and a
 torque wrench.

	Gas side					iquid side
3/8 inch (9.	24-1/8-29-1/2lbf • ft 36		1/2 inch(12.7mm) 36-1/2-44-1/2lbf • ft (49.5-60.3N • m)		1/4 inch (6.4mm) 10-1/2-12-3/4lbf • ft (14.2-17.2 N • m)	
Width across flats	11/16 inch(1	7mm)	3/4 inch(19mm)	7/8 inch	n(22mm)	1-1/16 inch(27mm)

Flare nut tightening torque

Consider post can tightening torque							
				35-3/8-44-1/8lbf • ft (48-59.8N • m)			
width across flats	11/16 incn(1/mm)	3/4 inch(19mm)	7/8 incn(22mm)	1-1/16 Inch(2/mm)			

Service port cap tightening torque	
8-10-7/8lbf • ft (10.8-14.7N • m)	




Outdoor Unit Installation

5. Pressure test and evacuating system

↑ WARNING

- . Make sure that air or any matter other than refrigerant (R410A) does not get into the refrigeration cycle.
- . If refrigerant gas leaks should occur, ventilate the room as soon and as much as possible.
- · R410A, as well as other refrigerants, should always be recovered and never be released directly into the environment.
- Use a vacuum pump for R410A exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
- When piping work is complete, it is necessary to perform a pressure test and evacuate system with a vacuum pump.
- If using additional refrigerant, purge the air from the refrigerant pipes and indoor unit using a vacuum pump, then charge additional refrigerant.
- Use a hexagonal wrench (3/16 inch (4mm)) to operate the stop valve rod.
- All refrigerant pipe joints should be tightened with a torque wrench to the specified tightening torque.



- Pressurize the liquid pipe and gas pipe from the service ports of each stop valve to 550psi (3.8MPa) (do not pressurize more than 550psi (3.8MPa)) for 1 hour minimum, 24 hours recommended. If there is a pressure drop, check for leaks, make repairs and perform the pressure test again.
- 2) Connect the gauge manifold's charging hose to the gas stop valve's service port.
- Fully open the gauge manifold's low-pressure valve (Lo) and completely close its high-pressure valve (Hi). (High-pressure valve will require no further operation.)
- 4) Evacuate system using vacuum pump to below 500 microns for 1 hour minimum.
- 5) Close the gauge manifold's low-pressure valve (Lo) and stop vacuum pump. (Maintain this condition for a few minutes to make sure that the compound pressure gauge pointer does not swing back.)*1
- 6) Remove the valve caps from the liquid stop valve and gas stop valve.
- 7) Turn the liquid stop valve's rod 90° counter-clockwise with a hexagonal wrench to open the valve.
 - Close it after 5 seconds, and check for gas leakage.
 - Using soapy water, check for gas leakage from the indoor unit's flare and outdoor unit's flare and valve rods. After the check is complete, wipe all soapy water off.
- 8) Disconnect the charging hose from the gas stop valve's service port, then fully open the liquid and gas stop valves. (Do not attempt to turn the valve rod further than it can go.)
- Tighten the valve caps and service port caps for the liquid and gas stop valves with a torque wrench to the specified torques.
 - Refer to "4. Refrigerant piping" on page 6 for details.
- *1 If the compound pressure gauge pointer swings back, the refrigerant may have water content or there may be a loose pipe joint.
 - Check all pipe joints and retighten nuts as needed, then repeat steps 3) through 5).

6. Refilling refrigerant

Check the type of refrigerant to be used on the machine nameplate.

Precautions when adding R410A

Fill from the liquid pipe in liquid form.

R410A is a mixed refrigerant, so adding it in gas form may cause the refrigerant composition to change, preventing normal operation.

1) Before filling, check whether the cylinder has a siphon attached or not. (It should have something like "liquid filling siphon attached" displayed on it.)

Filling a cylinder with an attached siphon

Stand the cylinder upright when filling.

There is a siphon pipe inside, so the cylinder need not be upside-down to fill with liquid.

Filling other cylinders

Turn the cylinder upside-down when filling.

· Be sure to use the R410A tools to ensure pressure and to prevent foreign objects entering.

7. Refrigerant piping work

7-1. Cautions on pipe handling

- · Protect the open end of the pipe from dust and moisture.
- All pipe bends should be as gentle as possible. Use a pipe bender for bending.

7-2. Selection of copper and heat insulation materials

When using commercial copper pipes and fittings, observe the following:

Insulation material: Polyethylene foam


Heat transfer rate: 0.041 to 0.052W/mK (0.024 to 0.030Btu/fth°F (0.035 to 0.045kcal/mh°C))

Be sure to use insulation that is designed for use with HVAC Systems.

- · ACR Copper only.
- Be sure to insulate both the gas and liquid piping and observe the insulation dimensions as below.

	Piping size	Minimum bend radius	Piping thickness	Thermal insulation size	Thermal insulation thickness	
Gas side -	O.D. 3/8 inch (9.5mm)	1-3/16 inch (30mm) or more	0.031 inch (0.8mm)	I.D. 15/32-19/32 inch (12-15mm)		
	O.D. 1/2 inch (12.7mm)	1-9/16 inch (40mm) or more	(C1220T-O)	I.D. 9/16-5/8 inch (14-16mm)	13/32 inch (10mm) Min.	
Liquid side	O.D. 1/4 inch (6.4mm)	1-3/16 inch (30mm) or more	0.031 inch (0.8mm) (C1220T-O)	I.D. 5/16-13/32 inch (8-10mm)		

Use separate thermal insulation pipes for gas and liquid refrigerant pipes.






Wiring

↑ WARNING


- . Do not use tapped wires, extension cords, or starburst connections, as they may cause overheating, electric shock, or fire.
- Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a fuse, a circuit breaker, a disconnect or a GFCI.
- . Use an all-pole disconnection type circuit breaker with at least 1/8 inch (3mm) between the contact point gaps.
- . When carrying out wiring, take care not to pull at the conduit.
- . Do not connect the power wire to the indoor unit. Doing so may cause electric shock or fire.
- . Do not turn on the circuit breaker until all work is completed.
 - 1) Strip the insulation from the wire (3/4 inch (20mm)).
 - 2) Connect the inter-unit wires between the indoor and outdoor units so that the terminal numbers match. Tighten the terminal screws securely. It is recommended that a slot-head screwdriver be used to tighten the screws. The screws are packed with the terminal block.



09/12 class

[Method of mounting conduit]


- · A protection plate is fixed for protection from the high-voltage section.
- 1) Dismount the stop valve cover by removing the screw.
- Dismount the protection plate by removing the 2 screws.
- 3) Dismount the conduit mounting cover by removing the 2 screws.
- 4) Pass wires through the conduit and secure them with a lock nut.
- After completing the work, reattach the stop valve cover, the conduit mounting cover, and the protection plate to its original position.



15/18 class

[Method of mounting conduit]


- 1) Dismount the service lid by removing the 2 screws.
- 2) Pass wires through the conduit and secure them with a lock nut.
- 3) After completing the work, reattach the service lid to its original position.



⚠ CAUTION

Precautions to be taken for power supply wiring


 When using stranded wires, make sure to use the round crimp-style terminal for connection to the power supply terminal block.



Round crimp-style

terminal

When connecting the inter-unit wires to the terminal block using a single core wire, be sure to curl the end of the lead.
 Improper work may cause heat and fires.



Facility Setting (cooling at low outdoor temperature)

This function is limited only for facilities (the target of air conditioning is equipment (such as computer)). Never use it in a residence or office (the space where there is a human).

- Cutting jumper 6 (J6) on the circuit board will extend the operation range to 14°F (-10°C). Installing an air direction adjustment grille (sold separately) will further extend the operation range to -4°F (-20°C). In these cases, the unit will stop operating if the outdoor temperature falls below -4°F (-20°C), restarting once the temperature rises above this level.
 - 1) Remove the top plate of the outdoor unit. (09/12 class: 3 screws, 15/18 class: 6 screws)
- 2) Remove the front plate. (09/12 class: 4 screws, 15/18 class: 8 screws)
- 3) Cut the jumper (J6) of the PCB inside.


↑ CAUTION

- · If the outdoor unit is installed where the heat exchanger of the unit is exposed to direct wind, provide a windbreak wall.
- · Intermittent noises may be produced by the indoor unit due to the outdoor fan turning on and off when using facility settings.
- Do not place humidifiers or other items which might raise the humidity in rooms where facility settings are being used.
 A humidifier might cause dew jumping from the indoor unit outlet vent.
- . Cutting jumper 6 (J6) sets the indoor fan tap to the highest position. Notify the user about this.

Pump Down Operation

In order to protect the environment, be sure to pump down when relocating or disposing of the unit.

- 1) Remove the valve cap from the liquid stop valve and gas stop valve.
- 2) Carry out forced cooling operation.
- 3) After 5 to 10 minutes, close the liquid stop valve with a hexagonal wrench.
- 4) After 2 to 3 minutes, close the gas stop valve and stop forced cooling operation.




Forced cooling operation

■Using the indoor unit's remote controller

[For wired remote controller]

- 1) Set to COOL operation using the remote controller.
- Press and hold the Cancel button for 4 seconds or longer. Service settings menu is displayed.
- Select Test Operation in the service settings menu, and press the Menu/OK button. Basic screen returns and "Test Operation" is displayed at the bottom.
- Press the On/Off button within 10 seconds, and the forced cooling operation starts.
 - Forced cooling operation will stop automatically after about 15 minutes. To stop the operation, press the On/Off button.



[For wireless remote controller]


1) Press and select the COOL operation.

2) Press twice. "Test" is displayed.

3) Press within 10 seconds, and the forced cooling operation starts.

• Forced cooling operation will stop automatically after about 15 minutes.

**To stop the operation, press (III) .



Trial Operation and Testing

1. Trial operation and testing

Refer to the installation manual for the indoor unit.

2. Test items

Test items	Symptom	Check
Indoor and outdoor units are installed properly on solid bases.	Fall, vibration, noise	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
System is properly grounded.	Electrical leakage	
The specified wires are used for inter-unit wiring.	No operation or burn damage	
Indoor or outdoor unit's air inlet or air outlet are unobstructed.	Incomplete cooling/heating function	
Stop valves are opened.	Incomplete cooling/heating function	
Check that the connector of the lead wires of the decoration panel is connected securely.	Louvers do not move	
Indoor unit properly receives wireless remote control commands.	No operation	

EDUS091617 Operation Manual

12. Operation Manual

Contents

■ Read Before Operation	
Safety Considerations	1
Names of Parts	4
■ Care	
Care and Cleaning	5

Safety Considerations

Read these **Safety Considerations for Operations** carefully before operating an air conditioner or heat pump. Make sure that the unit operates properly during the startup operation. Instruct the user on how to operate and maintain the unit.

Inform users that they should store this operation manual with the installation manual for future reference.

Meanings of DANGER, WARNING, CAUTION, and NOTE Symbols:

⚠ DANGER Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTEIndicates situations that may result in equipment or property-damage accidents only.

- Do not install the unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.
- Any abnormalities in the operation of the air conditioner or heat pump, such as smoke or fire, could result in severe injury or death. Turn off the power and contact your dealer immediately.
- Refrigerant gas may produce toxic gas if it comes into contact with fire, such as from a fan heater, stove, or cooking device. Exposure to this gas could cause severe injury or death.
- For refrigerant leakage, consult your dealer.
 Refrigerant gas is heavier than air and replaces oxygen.
 A massive leak could lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- If equipment utilizing a burner is used in the same room as the air conditioner or heat pump, there is the danger of oxygen deficiency which could lead to an asphyxiation hazard resulting in serious injury or death. Be sure to ventilate the room sufficiently to avoid this hazard.
- Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.

Operation Manual EDUS091617

 Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face the danger of death by suffocation.

- Contact your dealer for repair and maintenance.
 Improper repair and maintenance may result in water leakage, electric shock, and fire. Only use accessories made by Daikin that are specifically designed for use with the equipment and have them installed by a professional.
- Contact your dealer to move and reinstall the air conditioner or heat pump. Incomplete installation may result in water leakage, electric shock, and fire.
- Never let the indoor unit or the remote controller get wet.
 Water can cause an electric shock or a fire.
- Never use flammable spray such as hair spray, lacquer, or paint near the unit. Flammable spray may cause a fire.
- When a fuse blows out, never replace it with one of incorrect ampere ratings or different wires. Always replace any blown fuse with a fuse of the same specification.
- Never inspect or service the unit by yourself. Contact a qualified service person to perform this work.
- Turn off all electrical power before doing any maintenance to avoid the risk of serious electric shock; never sprinkle or spill water or liquids on the unit.
- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not put a finger or other objects into the air inlet or air outlet. The fan is rotating at high speed and will cause injury.
- Check the unit foundation for damage on a continuous basis, especially if it has been in use for a long time. If left in a damaged condition the unit may fall and cause injury.
- Never touch the internal parts of the controller. To check and adjust internal parts, contact your dealer.
- Be sure to establish a ground.
 Do not ground the unit to a utility pipe, arrester, or
 telephone ground. Incomplete grounding may cause
 electrical shock, or fire. A high surge current from
 lightning or other sources may cause damage to the air
 conditioner.
- Be sure to install a ground fault circuit interrupter.
 Failure to install a ground fault circuit interrupter may result in electric shock or fire.

— CAUTION -

- Do not use the air conditioner or heat pump for any other purposes other than comfort cooling or heating.
 Do not use the unit for cooling precision instruments, food, plants, animals or works of art.
- Do not place items under the indoor unit as they may be damaged by condensates that may form if the humidity is above 80% or if the drain outlet gets blocked.
- Before cleaning, stop the operation of the unit by turning the power off or by pulling the supply cord out from its receptacle. Otherwise, an electric shock and injury may result.
- Do not wash the air conditioner or heat pump with excessive water. An electric shock or fire may result.
- Avoid placing the controller in a spot splashed with water.
 Water entering the controller may cause an electric shock or damage the internal electronic parts.
- Do not operate the air conditioner or heat pump when using a room-fumigation type of insecticide.
 Failure to observe this could cause the chemicals to be deposited in the unit and can endanger the health of those who are hypersensitive to chemicals.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may
- The appliance is not intended for use by young children or infirm persons without supervision.
- The remote controller should be kept away from children so they cannot play with it.
- · Consult with the installation contractor for cleaning.
- Incorrect cleaning of the inside of the air conditioner or heat pump could make the plastics parts break and cause water leakage or electric shock.
- Do not touch the air inlet or aluminum fin of the air conditioner or heat pump as they can cut and cause injury.
- Do not place objects in direct proximity of the outdoor unit. Do not let leaves and other debris accumulate around the unit. Leaves are a hotbed for small animals which can enter the unit. Once inside the unit, animals can cause the unit to malfunction, and cause smoke or fire when they make contact with electrical parts.
- · For care and cleaning, call service personnel.

EDUS091617 Operation Manual

Safety Considerations


— ∧ NOTE -

- Never press the button of the remote controller with a hard, pointed object. The remote controller may be damaged.
- Never pull or twist the electric wire of the remote controller. It may cause the unit to malfunction.
- Do not place appliances that produce open flames in places that are exposed to the airflow of the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not expose the controller to direct sunlight. The LCD display can become discolored and may fail to display the data.
- Do not wipe the controller operation panel with benzene, thinner, chemical dust cloth, etc. The panel may get discolored or the coating can peel off. If it is heavily dirty, soak a cloth in a water-diluted neutral detergent, squeeze it well and wipe the panel clean. Then wipe it with another dry cloth.
- Dismantling of the unit, disposal of the refrigerant, oil, and additional parts, should be done in accordance with the relevant local, state, and national regulations.
- Operate the air conditioner or heat pump in a sufficiently ventilated area and not surrounded by obstacles. Do not use the air conditioner or heat pump in the following places.
 - a. Places with a mist of mineral oil, such as cutting oil.
 - b. Locations such as coastal areas where there is a lot of salt in the air.
 - Locations such as hot springs where there is a lot of sulfur in the air.
 - d. Locations such as factories where the power voltage varies a lot.
 - e. In cars, boats, and other vehicles.
 - Locations such as kitchens where oil may splatter or where there is steam in the air.
 - g. Locations where equipment produces electromagnetic waves.
 - h. Places with an acid or alkaline mist.
 - Places where fallen leaves can accumulate or where weeds can grow.
- Take snow protection measures. Contact your dealer for the details of snow protection measures, such as the use of a snow protection hood.
- Do not attempt to do electrical work or grounding work unless you are licensed to do so. Consult with your dealer for electrical work and grounding work.

- Pay attention to operating sound. Be sure to use the following places:
 - Places that can sufficiently withstand the weight of the air conditioner or heat pump yet can suppress the operating sound and vibration.
 - Places where warm air from the air outlet of the outdoor unit or the operating sound of the outdoor unit does not annoy neighbors.
- Make sure that there are no obstacles close to the outdoor unit. Obstacles close to the outdoor unit may drop the performance of the outdoor unit or increase the operating sound of the outdoor unit.
- Consult your dealer if the air conditioner or heat pump in operation generates unusual noise.
- Make sure that the drainpipe is installed properly to drain water. If no water is discharged from the drainpipe while the air conditioner or heat pump is in the cooling mode, the drainpipe may be clogged with dust or dirt and water leakage from the indoor unit may occur. Stop operating the air conditioner or heat pump and contact your dealer.

This is an appliance that is not accessible to the general public.

Operation Manual EDUS091617



EDUS091617 **Operation Manual**

Care

Care and Cleaning

NARNING

- Only a qualified service person is allowed to perform maintenance.
- · Before cleaning, be sure to stop unit operation and turn off the circuit breaker. Otherwise, an electric shock and injury may result.
- · Contact a qualified person regarding the attachment of accessories and be sure to use only accessories specified by the manufacturer. If an accessory is attached incorrectly, water leakage, an electric shock, or fire may result.

CAUTION

- When cleaning, use a sturdy and stable stand and watch your step.
- . Make sure to firmly support the suction grille with your hand while performing maintenance tasks to prevent it from falling out.

■ Quick reference

Cleaning parts

Outside panel and flaps

- · Wipe the parts with a soft cloth.
- · When it is difficult to remove stains, use water or a neutral detergent.
- · If the flaps are stained severely, contact your dealer and have the flaps replaced.

If dirty

Air filter

· Vacuum dust or wash the filter.

When the air filter cleaning time indicator lamp on the decoration panel lights up or when "Time to clean filter" displays on the wired remote controller

▶Page 6

Remote controller

· Wipe them with a soft cloth.

If dirty

Suction grille · Wipe it with a soft damp cloth.

If dirty Page 7.8

Notes on cleaning

For cleaning, do not use any of the following:

- Water hotter than 104°F (40°C)
- · Volatile liquid such as benzene, gasoline and thinner
- · Polishing compounds or liquid insecticide
- · Rough materials such as a scrubbing brush



Operation Manual EDUS091617

Care


■ Cleaning the air filter

Clean the air filter when the air filter cleaning time indicator lamp on the decoration panel lights up or when "Time to clean filter" displays on the wired remote controller.

- If the unit is installed in a room where the impurity content of the air is high, clean the filter more frequently.
- If the filter has become difficult to clean, replace the air filter.
 (Additional air filter sold separately.)

1. Open the suction grille.

 Push the 2 catches away from you and slowly open the suction grille. (To close, perform the steps in reverse.)




2. Remove the air filter.

 Pull the knobs of the air filter downward to disconnect the hooks, and remove the air filter.



Clean the air filter with a vacuum cleaner or wash it with water.



If the dust does not come off easily

 Wash the air filter using a soft brush and a neutral detergent, then let it dry in the shade.



4. Reattach the air filter.

- 4-1 Hook one side of the air filter on to the protrusions on the suction grille.
- 4-2 Push the other side of the air filter into place.



5. Close the suction grille.

- Refer to STEP 1.
- 6. After turning on the power, reset the filter sign in accordance with the instructions in the operation manual for the wired remote controller or wireless remote controller.
 - The air filter cleaning time indicator lamp on the decoration panel turns off or "Time to clean filter" disappears from the display on the wired remote controller.

EDUS091617 Operation Manual

Care

Care and Cleaning

■ Cleaning the suction grille (for type A)

1. Open the suction grille.

 Push the 2 catches away from you and slowly open the suction grille. (To close, perform the steps in reverse.)



2. Remove the suction grille.

 Open the suction grille until it is 45 degrees to the ceiling and then lift it upward.



3. Remove the air filter.

4. Clean the suction grille.

Wash with a soft bristle brush and a neutral detergent or water, and dry thoroughly.



When very dirty
 Directly apply the type of detergent used for cleaning ventilation fans or ovens, wait for about 10 minutes, and then rinse with water.


5. Reattach the air filter.



- 6. Reattach the suction grille.
 - · Refer to STEP 2.
- 7. Close the suction grille.
 - Refer to STEP 1.
- Cleaning the suction grille (for type B)


1. Open the suction grille.

 Push the 2 catches away from you and slowly open the suction grille. (To close, perform the steps in reverse.)



2. Remove the suction grille.

- Open the suction grille so that it hangs by the hinges at 90 degrees to the ceiling.
- Pinch the wire catches inward as shown in the figure.



3. Remove the air filter.

Operation Manual EDUS091617

Care

4. Clean the suction grille.

Wash with a soft bristle brush and a neutral detergent or water, and dry thoroughly.



When very dirty
 Directly apply the type of detergent used for cleaning ventilation fans or ovens, wait for about 10 minutes, and then rinse with water.

- 5. Reattach the air filter.
- ▶Page 6
- 6. Reattach the suction grille.
 - Refer to STEP 2.
- 7. Close the suction grille.
 - Refer to STEP 1.

- Prior to a long period of non-use
 - Operate the FAN mode for several hours to dry out the inside.
 - To start the operation, refer to the operation manual for the remote controller.
 - After operation stops, turn off the circuit breaker for the room air conditioner.
 - 3. Clean the air filter and reattach it.
 - To prevent battery leakage, take out the batteries from the remote controller. (Only for the wireless remote controller)
- We recommend periodical maintenance
 - In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a qualified contractor.
 - For qualified contractor maintenance, please contact the dealer where you bought the air conditioner.

8

3P436084-1

EDUS091617 Operation Manual

12.1 With <BRC1E73> Wired Remote Controller

Safety Considerations

The original instructions are written in English. All other languages are translation of the original instructions.

Read these SAFETY CONSIDERATIONS carefully before operating the remote controller.

Train the customer to operate and maintain the remote controller.

Inform customers that they should store this Operations Manual with the Installation Manual for future reference.

Meanings of WARNING and CAUTION Symbols:

<u>∧</u>WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
⚠CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
⚠NOTE	Indicates situations that may result in equipment or property-damage accidents only.

• The following pictograms are used in this manual.

0	Never do.	0	Always follow the instructions given.
8	Keep water and moisture away.	8	Keep wet hands away.

	<u></u> MARNING		
0	Do not modify or repair the remote controller. Consult your Daikin dealer for any modification or for repairs.		
0	Do not relocate or reinstall the remote controller by yourself. Improper installation may result in electric shocks or fire. Consult your Daikin dealer to relocate or for any reinstallation.		
0	Do not use flammable materials (e.g., hairspray or insecticide) near the remote controller. Do not clean the product with organic solvents such as paint thinner. The use of organic solvents may cause cracking, damaging the product, causing electric shocks, or fire.		
0	Consult the dealer if the remote controller was submerged under water due to a natural disaster, such as a flood or hurricane. Do not operate the remote controller at this time or a malfunction, electric shock, or fire can occur.		

Operation Manual EDUS091617

——Items to be Strictly Observed—

CAUTION



 Do not allow children to play with the remote controller to avoid causing damage to the product.



• Never disassemble the remote controller.

Touching the interior parts may result in electric shocks or fire.

Consult your Daikin dealer for internal inspections and adjustments.



Do not touch the remote controller buttons with wet fingers.
 Touching the buttons with wet fingers can cause an electric shock.



Do not wash the remote controller.

Doing so may cause electric leakage and result in electric shocks or fire.



Never let the remote controller to get wet.

Water can cause damage to the remote controller, and may cause an electric shock or fire.

NOTE



 Never press the button of the remote controller with a hard and pointed object.

The remote controller may be damaged.



Never pull or twist the electric wire of the remote controller.
 It may cause the unit to malfunction.




 Do not wipe the remote controller with benzine, thinner, chemical dustcloth, etc.

The remote controller may get discolored or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the remote controller clean. And wipe it with another dry cloth.

EDUS091617 Operation Manual

Button Locations and Descriptions



Functions other than basic operation items (i.e., On/Off, Operation Mode, Fan Speed, and Setpoint) are set from the menu screen.

NOTE

- Do not install the remote controller in places exposed to direct sunlight, the LCD will be damaged.
- Do not pull or twist the remote controller cord, the remote controller may be damaged.
- Do not use objects with sharp ends to press the buttons on the remote controller, damage may result.

Operation Manual EDUS091617

1. Operation mode selector button

 Press this button to select the operation mode of your preference. (See page 10.)
 *Available modes vary with the indoor unit model.

2. Fan speed control button

- Press this button to select the fan speed of your preference. (See page 11.)
- *Available fan speeds vary with the indoor unit model.

3. Menu/OK button

- Used to enter the main menu.
 (See page 20 for the menu items.)
- Used to enter the selected item.

4. Up button ▲

- · Used to raise the setpoint.
- The item above the current selection will be highlighted.
- (The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

5. Down button ▼

- Used to lower the setpoint.
- The item below the current selection will be highlighted.
- (The highlighted items will be scrolled continuously when the button is continuously pressed.)
- · Used to change the selected item.

6. Right button ▶

- Used to highlight the next items on the right-hand side.
- Each screen is scrolled in the right-hand direction.

Left button ◀

- Used to highlight the next items on the left-hand side.
- Each screen is scrolled in the left-hand direction.

8. On/Off button

- · Press this button and system will start.
- · Press this button again to stop the system.

9. Operation lamp

- This lamp illuminates solid green during normal operation.
- . This lamp flashes if an error occurs.

10.Cancel button

• Used to return to the previous screen.

11.LCD (with backlight)


- The backlight will be illuminated for approximately 30 seconds by pressing any button.
- If two remote controllers are used to control a single indoor unit, only the controller accessed first will have backlight functionality.

Names and Functions

Liquid Crystal Display


- Three types of display mode (Standard, Detailed and Simple) are available.
- · Standard display is set by default.
- Detailed and Simple displays can be selected in the main menu. (See page 40.)

Standard display




Detailed display


■ The airflow direction, clock, and selectable item appear on Detailed display screen in addition to the items appearing on Standard display.



<Detailed display example 1>



Simple display



Note for all display modes

• Depending on the field settings, while the indoor unit is stopped, OFF may be displayed instead of the operation mode and/or the setpoint may not be displayed.

Names and Functions

1. Operation mode

- Used to display the current operation mode: Cool, Heat, Vent, Fan, Dry or Auto.
- In Auto mode, the actual operation mode (Cool or Heat) will be also displayed.
- Operation mode cannot be changed when OFF is displayed.
 - Operation mode can be changed after starting operation.

2. Fan Speed

- Used to display the fan speed that is set for the indoor unit.
- The fan speed will not be displayed if the connected model does not have fan speed control functionality.

3. Setpoint

- Used to display the setpoint for the indoor unit
- Use the Celsius/Fahrenheit item in the main menu to select the temperature unit (Celsius or Fahrenheit).

4. Stand by for Defrost/Hot start

" STANDBY " (See page 12.)

If ventilation icon is displayed in this field:

 Indicates that an energy recovery ventilator (ERV) is connected.

For details, refer to the Operation Manual of the ERV.

5. Message

The following messages may be displayed.

- "This function is not available"
- Displayed for a few seconds when an Operation button is pressed and the indoor unit does not provide the corresponding function.
- In a remote control group, the message will not appear if at least one of the indoor units provides the corresponding function.

"Error: Push Menu button"

"Warning: Push Menu button"

- Displayed if an error or warning is detected (see page 50).
- "Time to clean filter"
- "Time to clean element"
- "Time to clean filter & element"
- Displayed as a reminder when it is time to clean the filter and/or element (see page 48).

6. Ventilation

- Displayed when an energy recovery ventilator is connected.
- Ventilation Mode icon." AND ERV BYPASS"
 These icons indicate the current ventilation mode (ERV only) (AUTO, ERV, BYPASS).
- Air Purify ICON " AIR FIFY"
 This icon indicates that the air purifying unit (Optional) is in operation.

7. Key Lock (See page 19.)

. Displayed when the key lock is set.

8. Scheduled (See page 30.)

 Displayed if the Schedule or Off timer is enabled.

9. Under Centralized control " CONTRAL "

 Displayed if the system is under the management of a multi-zone controller (Optional) and the operation of the system through the remote controller is limited.

(VRV only)

 Displayed when another indoor unit on the system has the authority to change the operation mode between cool and heat.

11. Setback " SETBACK " (See page 14.)

 The setback icon flashes when the unit is turned on by the setback control.

12.Airflow Direction "." "

- Displayed when the airflow direction and swing are set (see page 23).
- If the connected indoor unit model does not include oscillating louvers this item will not be displayed.

13.Current Day/Time (12/24 hour time display)

- Displayed if the clock is set (see page 42).
- If the clock is not set, " -- : -- " will be displayed.
- 12 hour time format is displayed by default.
- Select 12/24 hour time display option in the main menu under "Clock & Calendar".

14. Selectable Display Item


- · Room temperature is selected by default.
- For other choices see page 41.

15. X Unable to schedule

- Displayed when the clock needs to be set.
- The schedule function will not work unless the clock is set.

Basic Operation

Cool/Heat/Auto/Fan Operation (SkyAir and VRV)




Preparation

Cool

 For mechanical protection purposes, apply power to the outdoor units at least six hours before starting the operation of the system.

Operation






74₅

 Press Mode button several times until the desired mode Cool, Heat, Fan, or Auto mode is selected.



*Unavailable operation modes are not displayed.

Note





Press On/Off button.

The Operation lamp will illuminate solid green and the system will start operating.



3




 The setpoint will increase by 1°F (or 1°C) when ▲ button is pressed and decrease by 1°F (or 1°C) when ▼ button is pressed.




*Setpoint is not available in fan or dry mode.







three fan speeds



To change the fan speed, press Fan
 Speed button and select the fan speed from;



- Low/High/Auto for two-speed
- Low/Medium/High/Auto for three-speed
- Low/Med Low/Medium/Med High/High/Auto for five-speed

depending on the indoor unit model.

- *Auto cannot be selected if the indoor unit does not have Auto Fan speed function.
- *The system may change the fan speed automatically for equipment protection purposes.
- *The system may turn off the fan when the room temperature is satisfied.
- *It is normal for a delay to occur when changing the fan speed.
- *If the Auto is selected for the fan speed, the fan speed varies automatically based on the difference between setpoint and room temperature.

Basic Operation

5

- Adjust Airflow Direction from the main menu (see page 23).
 - * If the connected indoor unit does not have oscillating louvers, this function will not be available.



 When On/Off button is pressed again, the system will stop operating and the Operation lamp will turn off.



*When the system is stopped while in the heating mode, the fan will continue to operate for approximately one minute to remove residual heat from the indoor unit.

Note

 To prevent condensation water damage or system failure, do not shut off the power supply to the indoor unit immediately after operation. Wait at least five minutes for the condensate pump to finish draining residual water from the indoor unit.

Characteristics of Heat Mode

The system automatically controls the following operating modes to prevent the reduction of heating capacity and space comfort.

Defrost operation

- The system will automatically go into defrost operation to prevent frost accumulation at the outdoor unit and subsequent loss of heating capacity
- The indoor unit fan will stop, and "STANDBY" will be displayed on the remote controller.
- The system will finish the Defrost operation and return to normal usually within six to eight minutes. It won't last for more than ten minutes.

Hot start

When the system starts heating operation, the indoor unit fan will
operate with a delay in order to prevent a cold draft.
 (In that case, "STANDBY]" will be displayed on the remote controller.)


Dry Mode

Preparation

- For equipment protection purposes, apply power to the outdoor units at least six hours before starting the operation of the system.
- The dry mode may not be selected if the remote controller is master controlled and the system is not already in the cooling mode of operation. (see page 18 for details)

Operation

1



 Press Mode button several times until the Dry mode is selected.




*The dry mode may not be available depending on the type of indoor unit.

2



Press On/Off button.





*In Dry mode, the system maintains automatic temperature and fan speed control. Therefore, temperature setpoint or fan speed settings are not available while the indoor unit is in the Dry mode.

- Adjust Airflow Direction from the main menu (see page 23).
 - * If the connected indoor unit does not have oscillating louvers, this function will not be available.

Basic Operation



 When On/Off button is pressed again, the system will stop operating and the Operation lamp will turn off.



Note

 To prevent condensation water damage or system failure, do not shut off the power supply to the indoor unit immediately after operation. Wait at least five minutes for the condensate pump to finish draining residual water from the indoor unit.

Characteristic of Dry mode

The Dry mode dehumidifies the space at reduced cooling capacity to prevent the room temperature from dropping to an uncomfortable level.



Setback


The Setback function can be used to maintain the space temperature in an assigned range for an unoccupied period.

Note

- When enabled, the Setback mode becomes active when the indoor unit is turned off by either the user, a schedule event or an off timer.
- This function is not available by default. It can be enabled by the system installer.

Operation

1



Setback Cool 84_F The setback icon flashes when the unit is turned on by the setback control.

Ventilation Mode When the Indoor Unit is Interlocked with Energy Recovery Ventilator

Preparation

Cool

 For equipment protection purposes, apply power to the outdoor units at least six hours before starting the operation of the system.

Operation

1



 When operating the energy recovery ventilator (ERV) between seasons without the indoor unit, set the control to ventilation mode.



2

 Changes to the ventilation mode are made from the main menu.

*Ventilation Mode: Auto, ERV, and Bypass

3

 Changes to the ventilation rate are made from the main menu.

*Ventilation Rate: Low or High

Basic Operation



 Press On/Off button. The Operation lamp will illuminate solid green and the system will start operating.



On/Off

 When On/Off button is pressed again, the system will stop operating and the Operation lamp will turn off.




Setting the Cool / Heat Changeover Master

(VRV only)


Setting Changes See page 18 for an explanation of the cool/heat changeover master indoor unit.






 Press Mode button on the remote controller of the changeover master indoor unit for at least four seconds while the backlight is illuminated.





- The "MASSER" icon on each remote controller for the indoor units connected to the same outdoor unit or Branch Selector unit will start flashing.
 - *Vent mode setting changes are possible regardless of the cool/ heat changeover master indoor unit.
 - * If the outdoor unit is configured as cool/heat changeover master, all remote controllers serving the associated indoor units will display its "CONTROLLED" icon.
- Set the cool/heat changeover master indoor unit as outlined below.



2



 Press Mode button on the remote controller of the indoor unit which is to serve as the cool/heat changeover master.




Cool Set to 74F

The remote controller for the changeover master indoor unit is established and the icon is no longer displayed.

Other remote controllers in the system (indoor units served by the same outdoor unit or indoor units served by the same branch selector unit) will now display the icon.

3



- Press Mode button on the remote controller of the indoor unit designated as the cool/heat changeover master (the remote controller not displaying the icon) repeatedly until the desired mode is selected. The display will change to Fan, Dry, Auto, Cool, Heat each time the button is pressed.
- Simultaneously, the other indoor units on the system will follow suit and change modes to reflect the new mode selected at the changeover master remote controller.



Basic Operation

Cool / Heat Mode Selection Availability


 "Cool", "Heat", and "Auto" are all only available for selection on the cool/heat changeover master indoor unit. The following table indicates the available operating modes of the other indoor units on the system based upon the selected mode of the master indoor unit.

When the master indoor unit is set to	The other indoor units in the system can be set to			
	Cool	Dry	Heat	Fan
Cool mode	1	1		1
Dry mode	1	1		1
Heat mode			/	1
Fan mode				1
Auto mode (Cooling operation)	/	/		1
Auto mode (Heating operation)			/	1

Precautions for Selecting the Cool / Heat Changeover Master Indoor Unit

• The cool/heat changeover master must be set for a single indoor unit in the following applications


(2-Pipe Heat Pump System)



A number of indoor units are connected to a single outdoor unit.

Set any one of the indoor units as the cool/heat changeover master.

(3-Pipe Heat Recovery System)




A number of indoor units are connected to a single Branch Selector unit.

Set any one of the indoor units as the cool/heat changeover master.

Key Lock

Operation Confirm and cancel Key Lock settings in the basic display screen.

1




Basic screen

 Press Menu/OK button for at least four seconds while the backlight is illuminated.



_



- "-o" is displayed.
 All buttons are disabled when the keys are locked.
- To cancel the key lock mode, continue pressing Menu/OK button for at least four seconds while the backlight is illuminated.

Quick Reference

■The main menu has the following items.

Menu item		Description	Reference page	
Airflow Direction		Used to configure airflow direction settings. • The airflow direction louver is automatically operated up and down (left and right). • The fixed airflow directions are configurable for five positions. * This function is not available on all indoor unit models.	23	
Individual	Louver Setting	Set the airflow direction individually for each of the 4 louvers. • Maximum 16 units (unit 0 till 15).	25	
Airflow Direction (depends on	Louver Setting List	Setting table for louver.	26	
indoor unit model)	Reset All Louvers Position	Reset all louvers to factory default setting.	27	
Ventilation (Ventilation	Ventilation Rate	Used to set "Low" or "High"	28	
operation settings for energy recovery ventilator	Ventilation Mode	Used to set Auto, ERV, or Bypass.	29	
Schedule	Daily Patterns	Day settings are selected from four patterns, i.e., "7Days", "Weekday/Sat/Sun", "Weekday/Weekend", and "Everyday".	31	
	Settings	Set the startup time and operation stop time. ON: Startup time, cooling and heating temperature setpoints can be configured. OFF: Operation stop time, cooling and heating setback temperature setpoints can be configured. (—: Indicates that the setback function is disabled for this time period.) Indicates that the temperature setpoint and setback temperature setpoint for this time period is not specified. The last active setpoint will be utilized. Up to five actions can be set for each day.	32	
Off Timer		Used to set the run-time for the indoor unit using this controller. • Possible to set in 10 minute increments from 30 to 180 minutes.	35	
Celsius / Fahr	enheit	Used to select whether temperature values will be displayed in Celsius or Fahrenheit.	_	

M	enu item	Description	Reference page
Filter Auto Cle	ean	Set the time when the filter needs to be automatically cleaned. For the detailed operation refer to the Operation Manual of the self cleaning decoration panel.	1
Maintenance I	nformation	Used to display the maintenance information.	37
Configuration	Draft Prevention (Only available with Occ. sensor installed indoor unit model)	The draft prevention function can be enabled or disabled. When enabled, the Occ. sensor will adjust the louver's position to prevent air blowing directly on occupant.	38
	Contrast Adjustment	Used to make LCD contrast adjustment.	39
	Display	Used to set the display mode. Display mode Standard, Detailed, or Simple display Detailed and Simple displays provide the selectable display item among Room Temp, System, None or Outside Air Temp.	40
Current Settin	gs	Used to display a list of current settings for available items.	42
Clock & Date & Time Calendar		Used to configure date and time settings and corrections. The default time display is 12H. The clock will maintain accuracy to within ±30 seconds per month. If there is a power failure for a period not exceeding 48 hours, the clock will continue working with the built-in backup power supply.	42
	12H/24H Clock	The time can be displayed in either a 12 hour or a 24 hour time format.	45
Daylight Savir	ng Time	Used to adjust the clock in observance of daylight saving time.	45
Language		The display language can be selected between English, Francais, or Espanol.	48

Note: Available setting items vary with the indoor unit model.

Sub Remote Controller Menu Items If two remote controllers are connected to a single indoor unit, the following menu items are not set in the sub remote controller. In this case, the following items should be configured in the main remote controller. Individual Airflow Direction Schedule Outdoor unit Two remote controllers in control

Menu Options

Navigating the Main Menu Screen

■Display Method for Main Menu

Operation



Basic screen

Press Menu/OK button.





Main menu screen

The main menu screen is displayed.

Instructions for navigating the main menu will appear.

- Selecting items from the main menu.
 - 1. Press ▼▲ buttons to select the desired item to be set.
 - 2. Press Menu/OK button to display the details for the selected item.





 To go back to the basic screen from the main menu, press Cancel button.



Note

• If a button is not pressed for 5 minutes during configuration, the controller will automatically revert to the basic screen.

Airflow Direction

■Configuring Airflow direction

Operation





- Display the main menu screen. (See page 22.)
- Press ▼▲ buttons to select Airflow Direction and press Menu/OK button.





124



(1) Adjusting method when there is single airflow direction.



Select the desired airflow direction

from Position 0, Position 1 Position 2 , Position 3 , Position 4






Airflow direction setting (up/down)




Airflow direction setting (left/right)

▼▲ buttons. Press Menu/OK button to confirm the settings and to return to the basic

screen.






Up/down direction

Left/right direction 4 : Position 4

Notice -

These operation and screen are example of single airflow direction type indoor unit. It is different from Single flow cassette model.

Menu Options




(2) Adjusting method for selecting dual airflow directions.



 Press ◀▶ buttons, to select front/back or left/right direction setting.


When front/back direction is selected




When left/right direction is selected

Notice -

These operation and screen are example of dual airflow directions type indoor unit (Single flow cassette model).



 Select the desired airflow direction from Position 0, Position 1, Position 2




using VA buttons.



- Selecting Swing will cause the airflow direction louver to swing position 0 to 4.
- Setting Auto is not available when left/ right direction is selected.
- Press Menu/OK button to confirm the settings and return to the basic screen.







Basic screen (Detailed display)

• If dual airflow directions are set, then the dual airflow direction icons are displayed in the basic screen.

Individual Airflow Direction

■Louver Setting

Operation

1



- Display the main menu screen.
 (See page 22.)
- Select Individual Airflow Direction and press Menu/OK button.





2



 Select Louver Setting and press Menu/OK button.




3



 Use ▼▲ buttons to select the unit and outlet mark.



 Maximum 16 units for each group (unit 0 till 15) can be selected.



Note

In case of four outlets (cassette type), you can control each one of the four louvers individually (the following marks are beside each air outlet: 🔾 , 🖂 , 🖂 , 🖂 , 🖂).

Menu Options






 Press ◀▶ button to select the airflow direction.



 Use ▼▲ buttons to change the airflow direction to the following:






Swing or Blocked .

No Ind Set : No Individual Louver Setting.

Blocked: Individual airflow is blocked.

 Press Menu/OK button to confirm the settings and to return to the basic screen.

5



Basic screen (Detailed display) If individual airflow direction is set, then the individual airflow direction icon is displayed in the basic screen.

■Louver Setting List

Operation

1



- Display the individual airflow direction screen. (See page 25.)
- Press ▼▲ buttons to select
 Louver Setting List and press
 Menu/OK button.





2

Unit 0				
Direction	Indiv			
Position 0	OFF			
Position 0	OFF			
Position 0	OFF			
Position 0	OFF			
	Position 0 Position 0 Position 0			

- A table shows the current settings.
 Press ▼▲ buttons to go to the next unit.
- Press Cancel button to return to the previous menu.



■ Reset All Louvers Position

Operation




 Display the individual airflow direction screen.



(See page 25.)

 Press ▼▲ buttons to select Reset All Louvers Position and press Menu/OK button.





- Press ◀▶ buttons to select Yes .
- Press Menu/OK button to confirm the reset and to return to the basic screen.





Operational Details and Functions


There are two types of airflow direction settings.


(Airflow direction swing)

The louvers automatically oscillate up and down.

Airflow direction You can select from one of five fixed

directions. (This has no relation to the angle of the louvers.)





Movement of airflow direction louver

Under the operating conditions shown next, airflow direction is controlled automatically. Actual operation may be different than what is displayed on the remote controller.

Menu Options

Operating condition

- Room temperature is higher than the remote controller's setpoint (in heating operation).
- When defrosting (in heating operation).
 (The airflow discharges horizontally to avoid creating a draft for the room occupants.)
- Under continuous operation with the airflow discharging horizontally.

Ventilation

■Ventilation screen display properties

Operation

1





Display the main menu screen.
 (See page 22.)

Press ▼▲ buttons to select Ventilation on the main menu screen.
 (For models with no ventilation function, Ventilation will not be displayed on the main menu screen.)






■Changing the ventilation rate

Operation





- Navigate to the ventilation screen (see above).
- ◆ Press ▼▲ buttons to select
 Ventilation Rate on the ventilation screen.





2



 Press ▼▲ buttons to toggle between the Low and High settings.



*Only modes that can be set are displayed.

3

 Selecting and confirming the desired ventilation rate will take you back to the basic screen.



(Pressing Cancel button takes you back to the previous screen without changing the ventilation rate.)


■Changing the ventilation mode

Operation





- Display the ventilation screen. (See page 28.)
- Press ▼▲ buttons to select
 Ventilation Mode on the ventilation screen.





2



 Pressing ▼▲ buttons cycles through the settings in the order shown below.




Auto DERV Dypass

*Only modes that can be set are displayed.

Menu Options

3



 Selecting and confirming the desired ventilation mode will take you back to the basic screen.



(Pressing Cancel button takes you back to the previous screen without changing the ventilation mode.)

Ventilation Mode

Auto mode Using information from the indoor unit (cool, heat, fan, and

setpoint) and the energy recovery ventilator unit (indoor and outdoor temperatures), the ventilation mode is automatically

changed between ERV and Bypass.

ERV mode Outside air is passed through the ERV core and is supplied to the

conditioned space.

Bypass mode Outside air is supplied to the conditioned space without passing

through the ERV core.

Schedule

■Setting the schedule

Operation The schedule will disappear when a multizone controller is connected, but can be re-enabled by the system installer.





• Display the main menu screen. (See page 22.)



 Press ▼▲ buttons to select Schedule Press Menu/OK button to display the schedule screen.





 Before setting the schedule, the clock must be set.



 If the clock has not been set, a screen like the one on the left will appear.
 Press ◀▶ buttons to select Yes and press Menu/OK button.



- The date & time screen will appear.
- Set the current year, month, day, and time. (See clock settings on page 42.)



Day Thursday



 Press ▼▲ buttons to select the desired function on the schedule screen and press Menu/OK button.






■ Daily Patterns

Operation





- The schedule screen will appear.
- ◆ Press ▼▲ buttons to select Daily Patterns on the schedule screen.





2



 Press ▼▲ buttons to select 7 Days , Weekday/Sat/Sun , Weekday/Weekend or Everyday on the daily patterns screen.




The confirmation screen will appear when **Menu/OK** button is pressed.

Menu Options

3



 Press ◀► buttons to select Yes on the confirmation screen.







■Settings

Operation

1



• The schedule screen will appear.

Press ▼▲ buttons to select Settings on the schedule screen.
 The settings screen will appear when Menu/OK button is pressed.





2



 Press ▼▲ buttons to select the day to be set.

*It cannot be selected in the case of EVDY .



3



| Schedule | Time | Act | Cool | Heat | Mon | 6 | 00 | Act | Cool | Heat | Act | Act

- Input the time for the selected day.
- Press ◀▶ buttons to move the highlighted item and press ▼▲ buttons to input the desired operation start time. Each press of ▼▲ buttons moves the numbers by 1 hour or 1 minute.









Press ◀► buttons to move the highlighted item and press ▼▲ buttons to configure ON/OFF/-- settings.
 --, ON, or OFF changes in sequence

when ▼▲ buttons are pressed.







ON: The temperature setpoints can be configured.
OFF: The setback temperature setpoints can be configured.

 - -: The temperature setpoints and setback temperature setpoints become disabled.



- The cooling and heating temperature setpoints for both ON and OFF (Setback) are configured.
 - _: Indicates that the temperature setpoint and setback temperature setpoint for this time period is not specified. The last active setpoint will be utilized.
 - --: Indicates that the setback function is disabled for this time period.





A maximum of five actions per day can be set.



 Press Menu/OK button when settings for each day are completed. The confirmation screen will appear.



To copy the settings for the previous day, press **Mode** button so that the existing settings will be copied.


Example: The contents for Monday are copied by pressing **Mode** button after selecting Tuesday.







Menu Options



 Press ◀► buttons to select Yes on the confirmation screen.



Pressing **Menu/OK** button confirms the settings for each day and takes you back to the basic screen.






Enabling or disabling the schedule

Operation

1



- Display the schedule screen. (See page 30.)
- Press ▼▲ buttons to select
 Enable / Disable on the schedule screen.






2



 Press ▼▲ buttons to select Enable or Disable on the enable/disable screen.





3



 Press ◀► buttons to select Yes on the confirmation screen.



Pressing **Menu/OK** button confirms the enable/disable setting for the schedule and takes you back to the basic screen.

Off Timer

■Configuring and Confirming the Off Timer settings

Operation

1



- Display the main menu screen.
 (See page 22.)
- Press buttons to select the
 Off Timer on the main menu screen.
 Press Menu/OK button to display the off timer screen.





2



Press ▼▲ buttons to select
 Settings on the off timer screen.
 Press Menu/OK button to display the configuration screen.



3



 Use ▼▲ buttons to set the time from operation start until the unit automatically stops.
 Selections can be made in increments of



Selections can be made in increments 10 minutes from 30 to 180 minutes. Holding down the button causes the number to change continuously.

 Select the desired time and press Menu/ OK button.

The confirmation screen will appear.





 Press ◀► button to select Yes on the confirmation screen.



Pressing **Menu/OK** button confirms the off timer and takes you back to the basic screen.

Menu Options



Ö-Enabling or disabling the off timer

Operation





- Navigate to the off timer screen.
 (See page 35.)
- Press ▼▲ buttons to select
 Enable/Disable on the off timer screen.
 Press Menu/OK button to display the enable/disable screen.



2



 Press ▼▲ buttons to select Enable or Disable on the enable/disable screen.
 Press Menu/OK button after selecting the item. Then the confirmation screen is displayed.






3



 Press ◀► button to select Yes on the confirmation screen.







Maintenance Information

■ Displaying the service contact and model information

Operation






Display the main menu screen.
 (See page 22.)



 Press ▼▲ buttons to select
 Maintenance Information on the main menu screen and press Menu/OK button.



2



- The phone number for the contact is displayed at the top of the screen.
 (If it has not yet been entered, it will not be displayed.)
- The model information of the indoor and outdoor units for your product will be displayed on the bottom of the screen.
 (For some models the product code may be displayed.)
 - *The model name will not be displayed if the indoor unit PCB has been replaced.
 - *The error code history may also be displayed. If the Operation lamp is not flashing, the unit is working properly.



The error code history is no longer displayed if you press **On/Off** button for more than 4 seconds.

Menu Options

Configuration

■Draft Prevention

Operation



- Display the main menu screen. (See page 22.)
- Press ▼▲ buttons to select Configuration and press Menu/OK button.







 Press ▼▲ buttons to select Draft Prevention and press Menu/OK button.






- Press ▼▲ buttons to select Enable or Disable .
- The confirmation screen will appear when Menu/OK button is pressed.







- Press ◀▶ buttons to select Yes .
- Press Menu/OK button to confirm the settings and to return to the basic screen.





■Contrast Adjustment

Operation





 Navigate to the configuration screen. (See page 38.)

Press ▼▲ buttons to select
 Contrast Adjustment on the configuration screen.
 Press Menu/OK button to display the contrast adjustment screen.



2



On the contrast adjustment screen press ○
 V▲ buttons until you reach the desired contrast.



After setting, press **Menu/OK** button and return to the basic screen.

Menu Options

■Display Display Mode

Operation

1



- Navigate to the configuration screen. (See page 38.)
- Press ▼▲ buttons to select
 Display on the configuration screen.
 Press Menu/OK button to display the display screen.



2



Press buttons to select
 Display Mode on the display screen.
 Press Menu/OK button to display the display mode screen.



3



Press ▼▲ buttons to select Standard
 Detailed or Simple on the display screen.



- Press Menu/OK button to confirm the settings and return to the basic screen.
 - *Refer to **Display Item** to change the selectable display item for Detailed and Simple display modes. (See page 41.)

Display Item

Operation

1



- Navigate to the display screen. (See page 40.)
- Press ▼▲ buttons to select
 Display Item on the display screen.
 Press Menu/OK button to display the display item screen.



2



Pressing ▼▲ buttons displays the following.





- *Some models may not display these items even if they are selected.
- Be sure to read the following notes regarding display of room temperature and outside air temperature.

Room Temp

.......... The temperature at the remote controller.

The temperature that is detected may be affected by the location of the remote controller.

Outside Air Temp

....... The temperature at the outdoor unit.

The temperature that is detected may be affected by factors such as the location of the unit (for example, if it is in direct sunlight) and unit operation during defrosting.

 After setting, press Menu/OK button to confirm settings and return to the basic screen.



Menu Options

Current Settings

■Confirming the current settings

Operation

1



Display the main menu screen.
 (See page 22.)




Press ▼▲ buttons to select

Current Settings on the main menu screen and press **Menu/OK** button.



2



 A list showing the current setting status will appear.



Press ◀▶ buttons to go to the next item.



 Pressing Cancel button takes you back to the main menu screen.

Off Timer
Display Mode
Display Item
Filter Auto Clean

^{*} Display items may differ depending on the model. Only the items that can be set are displayed.

Clock & Calendar


■ Date & Time

Operation





- Display the main menu screen. (See page 22.)
- Press ▼▲ buttons to select






Press **Menu/OK** button to display the clock & calendar screen.

Operation Manual EDUS091617

2



 Press ▼▲ buttons to select Date & Time on the clock & calendar screen.
 Press Menu/OK button to display the date & time screen.



3



Select Year with ◀▶ buttons.
 Change the year with ▼▲ buttons.
 Holding down the button causes the number to change continuously.



4



Select Month with ◀▶ buttons.
 Change the month with ▼▲ buttons.
 Holding down the button causes the number to change continuously.



5



Select Day with ◀▶ buttons.
 Change the day with ▼▲ buttons.
 Holding down the button causes the number to change continuously.
 Days of the week change automatically.







Select Hour with ◀► buttons.
 Change the hour with ▼▲ buttons.
 Holding down the button causes the number to change continuously.




Menu Options

7



Select Minute with ◀▶ buttons.
 Change the minute with ▼▲ buttons.
 Holding down the button causes the number to change continuously.



The confirmation screen will appear.






Note:

The date can be set between January 1, 2015 and December 31, 2099.





 Press ◀▶ button to select Yes on the confirmation screen.





*When setting the schedule, the display returns to the settings screen.

Operation Manual EDUS091617

■12H/24H CLOCK

Operation



 Display the clock & calendar screen. (See page 42.)



 Press ▼▲ buttons to select 12H/24H Clock on the clock & calendar screen.

The 12H/24H clock screen will appear

when Menu/OK button is pressed.






By default, the time display is set to the 12H format.



 Press ▼▲ buttons to select 12H 24H on the 12H/24H clock screen.



 The confirmation screen will appear when Menu/OK button is pressed.



 Press ◀▶ buttons to select Yes on the confirmation screen.



Pressing Menu/OK button confirms the 12H or 24H and takes you back to the basic screen.



Daylight Saving Time


■How to display Daylight Saving Time

Operation





- Display the main menu screen. (See page 22.)
- Press ▼▲ buttons to select Daylight Saving Time on the main menu screen. Press Menu/OK button to display the daylight saving time screen.



Menu Options

Enabling or disabling Daylight Saving Time

Operation





- Display the daylight saving time screen.
 (See page 45.)
- Press ▼▲ buttons to select Enable/Disable on the daylight saving time screen.

Press **Menu/OK** button to display the enable/disable screen.





2




- Press ▼▲ buttons to select Enable or Disable on the enable/disable screen.
- Press Menu/OK button to display the setting confirmation screen.



3



 Press ◀▶ buttons to select Yes on the setting confirmation screen.








Setting the date

Operation






- Display the daylight saving time screen.
 (See page 45.)
- ◆ Press ▼▲ buttons to select
 DST Dates on the daylight saving time screen. Press Menu/OK button to display the duration setting screen.






Daylight Saving Time













· After setting the Start and End dates, press Menu/OK button to display the setting confirmation screen.







 Press ◀▶ buttons to select Yes on the setting confirmation screen. Pressing Menu/OK button confirms the Daylight Saving Time settings and takes you back to the basic screen.





When Daylight Saving Time is enabled

When the time in the remote controller reaches 2:00 a.m. on the specified start date, the clock is automatically set forward by one hour. When the time in the remote controller reaches 2:00 a.m. on the end date, the clock is automatically set back by one hour.

Menu Options

Language

■ Selectable Languages

Operation

1



- Display the main menu screen. (See page 22.)
- Press ▼▲ buttons to select
 Language on the main menu screen and press Menu/OK button.





2



 Press ▼▲ buttons to select the preferred language on the language screen.
 English/Français/Español are available.



 Press Menu/OK button to confirm the settings and return to the basic screen.



Maintenance

Reset Filter Indicator

Operation

1



 When it is time to clean or replace the filter, one of the following messages will be displayed on the bottom of the basic screen.

Time to clean filter

Time to clean filter & element

Time to clean element

- *This is not displayed when Simple display is set.
- Wash, clean, or replace the filter or element.

For details, refer to the operation manual supplied with the indoor unit.

Operation Manual EDUS091617

2

 Reset the filter indicator when the filter or element is cleaned or replaced.

Press Menu/OK button.
 The main menu screen will be displayed.




3



 Press ▼▲ buttons to select
 Reset Filter Indicator on the main menu screen and press Menu/OK button.





 The displayed message "Time to clean filter" is no longer displayed on the basic screen when the filter sign is reset.

Maintaining the Unit and LCD Display

- . Wipe the LCD and surface of the remote controller with a dry cloth when they become dirty.
- If the dirt on the surface cannot be removed, soak the cloth in neutral detergent diluted with water, squeeze the cloth tightly, and clean the surface. Wipe the surface with a dry cloth.

Note

Do not use any paint thinner, organic solvent, or strong acid.

Reference Information

Error Code Display

■Contact your Daikin dealer in the following cases

Operation

1



 If an error occurs, either one of the following items will flash in the basic screen.

Error: Push Menu button

- *The Operation lamp will flash.
- *For Simple display, the message is not displayed, and only the Operation lamp flashes.

Warning: Push Menu button

- *The Operation lamp will not flash.
- *For Simple display, the message is not displayed, and the Operation lamp does not flash, either.



Press Menu/OK button.

2



- The error code will flash and the service contact and model name or code may be displayed.
- Notify your Daikin dealer of the Error code and model name or code.

Operation Manual EDUS091617

After-sale Service



♠ Warning

• Do not relocate or reinstall the remote controller by yourself. Improper installation may result in electric shocks or fire. Consult your Daikin dealer.



■Advise your Daikin Dealer of the following items

- Model name
- Date of installation
- Failure conditions: As precise as possible.
- · Your address, name, and telephone number

■Repairs after Warranty Period

Consult your Daikin dealer.


■Inquiry about After-sale Service

Contact your Daikin dealer.

51

3P243520-7Q

12.2 With <BRC082A41W, BRC082A42W(S)> Wireless Remote Controller



Operation Manual EDUS091617

Contents

Safety considerations	1
Names and functions of the operating	
section	2
Handling for wireless remote controller	3
Precautions in handling remote controller	3
Installation site	3
Placing the remote controller in the remote controller holder	3
How to put the batteries	3
When to change batteries	3
In case of a centralized control system	3
Operation range	4
Operation procedure	4
COOLING, HEATING, AUTOMATIC, FAN and DRY operation	4
Adjustment	5
Program timer operation	6
Emergency operation	6
Precautions for group control system or two remote control system	6
Troubleshooting	7
Emergency stop	7
In case besides emergency stop	7
When you think there is something wrong	8



Thank you for purchasing this Daikin remote controller. Carefully read this operation manual before using the air conditioner. It will tell you how to use the unit properly and help you if any trouble occurs. After reading the manual, file it away for future reference.

The English text is the original instruction. Other languages are translations of the original instructions.

Safety considerations

To gain full advantage of the air conditioner's functions and to avoid malfunction due to mishandling, we recommend that you read this instruction manual carefully before use. The precautions described herein are classified as WARNING and CAUTION. They both contain important information regarding safety. Be sure to observe all precautions without fail.



WARNING

Failure to follow these instructions properly may result in personal injury or loss of life.

CAUTION

Failure to observe these instructions properly may result in property damage or personal injury, which may be serious depending on the circumstances.

Information classified as **NOTE** contains instructions to ensure proper use of the equipment.

After reading, keep this manual in a convenient place so that you can refer to it whenever necessary. If the equipment is transferred to a new user, be sure also to hand over the manual.



WARNING

- Be aware that prolonged, direct exposure to cool or warm air from the air conditioner, or to air that is too cool or too warm can be harmful to your physical condition and health.
- When the air conditioner is malfunctioning (giving off a burning odor, etc.) turn off power to the unit and contact your local dealer. Continued operation under such circumstances may result in a failure, electric shock or fire bazards.
- Do not attempt to install or repair the air conditioner yourself. Improper workmanship may result in water leakage, electric shock or fire hazards. Please contact your local dealer or qualified personnel for installation and maintenance work.
- Ask your dealer to perform servicing or repairs whenever necessary.
 - Improper servicing or repairs may result in water leaks, electric shock or fire.
- Do not place objects, including rods, your fingers, etc., in the air inlet or outlet. Injury may result due to contact with the air conditioner's highspeed fan blades.
- Consult your local dealer regarding relocation and reinstallation of the air conditioner. Improper installation work may result in leakage, electric shock or fire hazards.



CAUTION

- Do not use the air conditioner for purposes other than those for which it is intended. Do not use the air conditioner for cooling precision instruments, food, plants, animals or works of art as this may adversely affect the performance, quality and/or longevity of the object concerned.
- To avoid oxygen depletion, ensure that the room is adequately ventilated if equipment such as a burner is used together with the air conditioner.
- Do not expose plants or animals directly to air flow from the unit as this may cause adverse effects.
- To avoid electric shock, do not operate with wet hands.
- Do not place burners or heaters in places exposed to the air flow from the unit as this may impair combustion of the burner or heater.
- Do not place flammable sprays or operate spray containers near the unit as this may result in fire.

Names and functions of the operating section

See figure 1, (figure 1B shows the remote controller with front cover opened)

This display shows the current OPERATION MODE.

- 3 DISPLAY "H·M·L", " SG → " (SET TEMPERATURE)
 This display shows the set temperature.
- 4 DISPLAY "hr. ② ·O hr. ② · I " (PROGRAMMED TIME)
 This display shows PROGRAMMED TIME of the system start or stop.
- 5 DISPLAY " •√□ " (SWING FLAP)
 Refer to "AIR FLOW DIRECTION ADJUST" on page 5.
- 6 DISPLAY " * " " * " " (FAN SPEED)
 The display shows the set fan speed.
- 7 DISPLAY "STEST" (INSPECTION/TEST OPERATION) When the INSPECTION/TEST OPERATION BUTTON is pressed, the display shows the system mode is in.
- 8 ON/OFF BUTTON Press the button and the system will start. Press the button again and the system will stop.
- 9 FAN SPEED CONTROL BUTTON Press this button to select the fan speed, LOW, MEDIUM or HIGH, of your choice.
- 10 TEMPERATURE SETTING BUTTON Use this button for SETTING TEMPERATURE.
- 11 TIMER MODE START/STOP BUTTON Refer to "TIMER MODE START/STOP" on page 6.
- 12 TIMER RESERVE/CANCEL BUTTON Refer to "PROGRAMMING TIME" on page 6.
- 13 AIR FLOW DIRECTION ADJUST BUTTON Refer to "AIR FLOW DIRECTION ADJUST" on page 5.
- 14 OPERATION MODE SELECTOR BUTTON Press this button to select OPERATION MODE.
- 15 FILTER SIGN RESET BUTTON Refer to the section of MAINTENANCE in the operation manual attached to the indoor unit.
- 16 INSPECTION/TEST OPERATION BUTTON This button is used only by qualified service persons for maintenance purposes.

See figure 3, (receiver on decoration panel)

- 17 EMERGENCY OPERATION SWITCH This switch is readily used if the remote controller does not work.
- 18 RECEIVER This receives the signals from the remote controller.
- 19 OPERATION LAMP (Red) This lamp stays lit while the air conditioner runs. It blinks when the unit is in trouble.
- 20 TIMER LAMP (Green)
 This lamp stays lit while the timer is set.
- 21 AIR FILTER CLEANING TIME INDICATOR LAMP (Red) Lights up when it is time to clean the air filter.
- 22 DEFROST LAMP (Orange) Lights up when the defrosting operation has started.

receiver will go out.

NOTE

- For the sake of explanation, all indications are shown on the display in figure 1 contrary to actual running situations.
- If the AIR FILTER CLEANING TIME INDICATOR lamp lights up, clean the air filter as explained in the operation manual provided with the indoor unit. After cleaning and reattaching the air filter, press the FILTER SIGN RESET button on the remote controller. The AIR FILTER CLEANING TIME INDICATOR lamp on the
- The DEFROST lamp will blink when the power is turned on. This is not a malfunction.

Operation Manual EDUS091617

Handling for wireless remote controller

Precautions in handling remote controller

- Direct the transmitting part of the remote controller to the receiving part of the air conditioner.
- If something blocks the transmitting and receiving path of the indoor unit and the remote controller such as curtains, it will not operate.



- Transmitting distance is approximately 23ft (7m).
- 2 short beeps from the receiver indicates that the transmission is properly done.
- Do not drop or get it wet. It may get damaged.
- Never press the button of the remote controller with a hard, pointed object.


The remote controller may get damaged.

Installation site

- It is possible that signals will not be received in rooms that have electronic fluorescent lighting. Please consult with the salesman before buying new fluorescent lights.
- If the remote controller operated some other electrical apparatus, move that machine away or consult your dealer.


Placing the remote controller in the remote controller holder


Choose a place where the signals reach the unit. Install the remote controller holder to a wall or a pillar with the attached screw.



How to put the batteries

 Slide the back cover to take it off.





3 Replace the back cover.

When to change batteries

Under normal use, batteries last about a year. However, if the remote controller display begins to fade and the possible transmission range becomes shorter within a year, replace both batteries as specified above.



Replace the two batteries at the same time, do not use new and old batteries intermixed. In case the remote controller is not used for a long time, take out all batteries in order to prevent liquid leak of the battery.

In case of a centralized control system

If the indoor unit is under centralized control, it is necessary to switch the remote controller's setting. In this case, contact your dealer.

Operation range

- Refer to the operation manual provided with the indoor unit or with the outdoor unit.
- If the indoor temperature or humidity is beyond operating conditions as listed in the indoor unit or outdoor unit manuals, it may happen
 - that safety devices work,
 - that the air conditioner does not operate,
 - that water drips from the indoor unit.
- The setting temperature range of the remote controller is 60°F (16°C) to 90°F (32°C).

Operation procedure

If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

COOLING, HEATING, AUTOMATIC, FAN and DRY operation

Operate in the following order:

AUTOMATIC operation can be selected only by heat pump system.

For systems without a cool/heat changeover remote control switch

1



OPERATION MODE SELECTOR

See figure 1

Press the OPERATION MODE SELECTOR button several times and select the OPERATION MODE of your choice as follows:

- COOLING operation **
 HEATING operation **
 AUTOMATIC operation **
 In this operation mode, COOL/HEAT changeover is automatically conducted.
 FAN operation **
 DRY operation **
 - This operation is to decrease the humidity in your room with the minimum temperature decrease.
 - The set point is the air temperature when starting operation by DRY operation.
 - Micro computer automatically determines TEMPERATURE and FAN SPEED.
 - DRY operation will not activate when room temperature is 57°F (14°C) or less.

2



ON/OFF

Press ON/OFF button.

The OPERATION lamp lights up or goes off and the system starts or stops operation.



Do not turn OFF power immediately after the unit stops. Wait at least 5 minutes. Failure to do so may result in water leakage etc.

Explanation of HEATING operation DEFROST operation

- As the frost on the coil of an outdoor unit increase, heating effect decreases and the system goes into DEFROST operation.
- The FAN operation stops and the DEFROST lamp of the indoor unit goes on.

After about 4 to 12 minutes of DEFROST operation, the system returns to HEATING operation.

Heating capacity and outdoor air temperature

- Heating capacity drops as outdoor air temperature lowers.
 If feeling cold, use another heater at the same time with this air conditioner.
- Hot air is circulated to warm the room. It will take some time from when the air conditioner is first started until the entire room becomes warm. The internal fan automatically turns at low speed until the air conditioner reaches a certain temperature on the inside.
- If hot air accumulates on the ceiling and feet are left feeling cold, it is recommended to use a circulator. For details, contact the place of purchase.

Operation Manual EDUS091617

Adjustment

For programming TEMPERATURE, FAN SPEED and AIR FLOW DIRECTION, follow the procedure shown below.



TEMPERATURE SETTING

Press TEMPERATURE SETTING button and program the setting temperature.



Each time this button is pressed, setting temperature rises 1°F (0.56°C).



Each time this button is pressed, setting temperature lowers 1°F (0.56°C).

DOWN

In case of AUTOMATIC operation



Each time this button is pressed, setting temperature shifts to "H" side.



Each time this button is pressed, setting temperature shifts to "L" side.

DOWN

н	•	M	•	Ľ,
77	73	71.5	70	66 (19)
	77 (25)	H • 77 73	H • M 77 73 71.5	H • M • 77 73 71.5 70 (25) (23) (22) (21)

- The setting is impossible for FAN operation
- The setting temperature range of the remote controller is 60°F (16°C) to 90°F (32°C).





FAN SPEED CONTROL

Press FAN SPEED CONTROL button.

- LOW, MEDIUM or HIGH fan speed can be selected.
- The micro computer may sometimes control the fan speed in order to protect the unit.






AIR FLOW DIRECTION ADJUST

The movable limit of the flap is changeable. Contact your dealer for details.

Up and down adjustment



Press the AIR FLOW DIRECTION ADJUST button to select the air direction as shown below.



Display appears and the air flow direction continuously varies.

(Automatic swing setting.)

Press AIR FLOW DIRECTION ADJUST button to select the air direction of your

Display vanishes and the air flow direction is fixed. (Fixed air flow direction setting.)

■ Movement of the swing flap For the following conditions, the micro computer controls the air flow direction so it may be different from the display.

Operation mode	HEATING
Operation conditions	 When starting operation. When room temperature is higher than the set temperature. In DEFROST operation. (The flaps turn to the horizontal position to avoid blowing cold air directly on the occupants of the room.)



oF(oC)

■ Operation mode includes AUTOMATIC operation.

Program timer operation

Operate in the following order.

- The timer is operated in the following two ways:
 - Programming the stop time (←) () The system stops operating after the set time has elapsed.
 - Programming the start time (←) |). The system starts operating after the set time has elapsed.
- The timer can be programmed for a maximum of 72 hours.
- The start and the stop time can be simultaneously programmed.



TIMER MODE START/STOP

Press the TIMER MODE START/STOP button several times and select the mode on the display. The display blinks.





2



PROGRAMMING TIME

Press the TEMPERATURE SETTING button and set the time for stopping or starting the system.



When this button is pressed, the time advances by 1 hour.

UP

When this button is pressed, the time goes backward by 1 hour.

DOWN

TIMER RESERVE

Press the TIMER RESERVE button.


- The timer setting procedure ends.
- The display changes from blinking light to a constant light.




TIMER CANCEL

Press the TIMER CANCEL button to cancel programming. The display vanishes.

For example. When the timer is programmed to stop the system after 3 hours and start the system after 4 hours, the system will stop after 3 hours and then 1 hour later the system will start.



NOTE



6

Emergency operation

When the remote controller does not work due to battery failure or the absence thereof, use the switch which is located beside the discharge grille on the indoor unit. When the remote controller does not work, contact your dealer.

START


Press the emergency operation switch.

- The unit runs in the previous mode.
- The system operates with the previously set air flow direction.

2

STOP

Press the emergency operation switch again.



Precautions for group control system or two remote control system

This system provides two other control systems beside individual control (one remote controller controls one indoor unit) system. Confirm the following if your unit is of the following control system type:

- Group control system One remote controller controls up to 16 indoor units. All indoor units are equally set.
- Two remote controller control system Two remote controllers control one indoor unit. (In case of group control system, one group of indoor units.) The unit follows individual operation.

- Cannot have a two remote controller control system with only wireless remote controllers. (It will be a two remote controller control system having one wired remote controller and one wireless remote controller.)
- Under two remote controller control system, wireless remote controller cannot control timer operation.
- Only the OPERATION lamp out of 3 other lamps on the indoor unit display functions. Contact your dealer in case of changing the combination or setting of group control and two remote controller control systems.

Troubleshooting

Emergency stop

(See figure 2)

When the air conditioner stops unexpectedly, the OPERATION lamp on the indoor unit starts blinking. Take the following steps yourself to read the malfunction code that appears on the display. Contact your dealer with this code. It will help pinpoint the cause of the trouble and speeding up the repair.



Press the INSPECTION/TEST button to select the inspection mode

"UNIT No." lights up and the unit number " 3 " blinks.



Press the TEMPERATURE SETTING button and change the unit number.

Hold down the TEMPERATURE SETTING button until the indoor unit emits one of the following beep tones.

Number of beeps

- 3 short beeps perform all steps from 3 to 6 - 1 short beep perform steps 3 and 6
- 1 long beep......No trouble

3



Press the OPERATION MODE SELECTOR button. " [] " on the left-hand of the malfunction code blinks.





Press the TEMPERATURE SETTING button and change the malfunction code

Press until the indoor unit makes 2 short beeps.





Press the OPERATION MODE SELECTOR button. " []" on the right-hand of the malfunction code blinks.





Press the TEMPERATURE SETTING button and change the malfunction code

Press until the indoor unit makes a long beep.

The malfunction code is fixed when the indoor unit makes a long beep.



Reset of the display.

Press OPERATION MODE SELECTOR button to get the display back to its normal state.

In case besides emergency stop

- 1 The unit does not operate at all.
 - Check if the receiver is exposed of sunlight or strong light. Keep receiver away from light.
 - Check if there are batteries in the remote controller. Place the batteries
 - Check if the indoor unit number and wireless remote controller number are equal. See figure 4. Operate the indoor unit with the remote controller of the same number.

Signals transmitted from a remote controller of a different number cannot be accepted. (If the number is not mentioned, it is considered as "1".)

- 2 The system operates but it does not sufficiently cool or
 - Check if the set temperature is proper.
 - Check if the FAN SPEED is not set to LOW SPEED.
 - Check if the air flow angle is proper.

Contact the place of purchase in the following case.



When you detect a burning odor, shut OFF power immediately and contact the place of purchase. Using the equipment in anything but proper working condition can result in equipment damage, electric shock and/or fire.

Trouble

The OPERATION lamp of the indoor unit is blinking and the unit does not work at all. See figure 5.

- Malfunction code
- 2 Unit No. which sensed trouble
- 3 INSPECTION display

Remedial action

Check the malfunction code (8 I-UF) on the remote controller. Notify and inform the model name and what the malfunction code indicates to your dealer.

When you think there is something wrong

The following symptoms do not indicate air conditioner malfunction:

Symptom 1: The system does not operate

Example	Reason
The system does not restart immediately after the ON/ OFF button is pressed.	If the OPERATION lamp lights, the system is in normal condition. It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.
If operation stops as a result of changing the temperature setting, there will be a delay before operation restarts if the setting is lowered (in COOLING) or raised (in HEATING) again.	It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.
If the reception beep is rapidly repeated 3 times (It sounds only twice when operating normally.)	Control is set to the optional controller for centralized control.
the indoor unit's display is lit when heating is started. against blown fr is nothir	This indication is to warn against cold air being blown from the unit. There is nothing wrong with the equipment.
The outdoor unit stops.	Because the room temperature reaches to the set temperature. The indoor unit goes into FAN operation

Symptom 2: The unit stops once in a while

Example	Reason
The remote controller indicates "U" and "US", the unit stops. Within several minutes the unit restarts.	Due to electrical noise other than that from the air conditioner, the communication between the units is cut off and the unit stops. When the noise is gone, the unit automatically restarts.

Symptom 3: No changeover is available between HEATING and COOLING modes

Example	Reason
The indoor unit makes a long beep sound.	When operation changeover is under control, the control is set to the mode that cannot be carried out.

Symptom 4: Air flow rate cannot be obtained as set

Example	Reason
During HEATING operation, even if the FAN SPEED CONTROL button is pressed, the air flow rate does not change.	When the room temperature reaches the indoor unit set temperature, the outdoor unit stops and the air flow rate of indoor unit drops to the minimum. This is to avoid the cold air from getting in contact with the people in the room.

Symptom 5: Air discharge direction is not as set

Example	Reason
The remote controller indication and the air discharge direction is not the same. Air discharge direction swing is impossible.	Because it is controlled by microcomputer. Refer to "AIR FLOW DIRECTION ADJUST" on page 5.

Symptom 6: Only a part of indication shows

Example	Reason
Even if the unit is operated, only the operation indication shows, or even if the indication shows, soon after, the indication other than that for operation disappears.	The corresponding indoor unit is that for multi-system and the remote controller is set to the multi-system.

Symptom 7: No indication shows or all indication show

Example	Reason	
When the remote controller button is pressed.	The battery is dead.	

Symptom 8: Insufficient cooling

Example	Reason
It is in DRY operation.	The DRY operation is an operation mode trying to keep the room temperature constant as much as possible. Refer to "COOLING, HEATING, AUTOMATIC, FAN and DRY operation" on page 4.

8

3P444561-1

13. Option List

13.1 Indoor Unit

	Option Name		Model Name	
	Decoration panel (required)	New design (white)	BYFQ60C2W1W	
1		New design (silver)	BYFQ60C2W1S	
		Current design (white)	BYFQ60B3W1	
		Wired type ★1	BRC1E73	
2	Remote controller (required)	Wireless type	BRC082A42W ★2 ★6 BRC082A42S ★3 ★6 BRC082A41W ★4 ★6	
3	Sensor kit	•	BRYQ60A2W ★2 / BRYQ60A2S ★3	
4	Sealing member of air discha	rge outlet	BDBHQ44C60	
5	Panel spacer		KDBQ44BA60A ★4	
6	Fresh air intake kit (direct installation type)		KDDQ44XA60	
7	Longlife filter		KAFQ441BA60	
8	Central remote controller		DCS302C71	
9	Unified ON/OFF controller		DCS301C71	
10	Schedule timer controller		DST301BA61	
11	Adaptor for wiring ★5		KRP1C75	
12	Wiring adaptor for electrical appendices ★5		KRP4A74	
13	Installation box for adaptor PCB		KRP1BA101	
14	Remote sensor		KRCS01-4B	

Notes:

- \star 1 Wiring for wired remote controller should be obtained locally.
- ★2 For BYFQ60C2W1W
- ★3 For BYFQ60C2W1S
- ★4 For BYFQ60B3W1
- ★5 Installation box for adaptor PCB (KRP1BA101) is necessary.
- \star 6 Sensing function and individual flap control function are not available.


13.2 Outdoor Unit

	Option Name	09/12 Class	15 Class	
1	Air direction adjustment grille	KPW937E4	KPW063A4	
2	Back protection wire net	KKG067A41	KKG063A42	
3	Drain plug ★	KKP937A4		
4	Drain pan heater	FTDBHMS, KEH067A41E	FTDBHML, KEH063A4E	
5	Snow hood (intake side plate)	KPS067A41	KPS063A41	
6	Snow hood (intake rear plate)	KPS067A42	KPS063A44	
7	Snow hood (outlet)	KPS067A44	KPS063A47	

Note: ★ Standard accessory


EDUS091617 **Option List**

<KRP1C75> Adaptor for Wiring



<Caution>

- All wiring must be performed by an authorized electrician.
- For electric wiring work, refer to also "Wiring diagram" attached to the control box lid and this manual.
- All wiring must be worked after shutting down power supply.
- All field supplied parts and materials and electric works must conform to local codes.
- A circuit breaker capable of shutting down power supply to the entire system must be installed.





• Refer to the wiring diagram attached to the indoor unit before attempting to wire.

[Make sure wires to units do not pass over the PCB when wiring.]

• Wire the adaptor to the indoor unit as shown below.




Note)1 Connector No. X33A

- 1 Thermo-ON and Fan ON status
- Thermo-ON status
- Contact terminals X1 and X2 close while the indoor unit is Thermo-ON (call for cooling or heating)
- Fan ON status Contact terminals X3 and X4 close when indoor unit fan is


· Energized while heating Thermo-ON (call for heating)

24VAC

Relay or Actuator




- 2 Interlocking Heater and Humidifier Humidifier output
- Heater output
 - Auxiliary heater output with heat pump heating • Primary heater output when
 - heat pump lockout enabled



(c) Installation


- Installation differs according to models as shown below.
- Do not bundle low and high voltage wires together.
- Bundle any excess wires with the attached clamps so as to keep loose wires off the indoor unit PCB.



2P263038-1E

13.4 <KRP4A74> Wiring Adaptor for Electrical Appendices

Accessories Check if the following accessories are included in the kit.



PCB support	×4
Clamp	×3
Installation manual	×1

1 System outline

This kit enables remote control (ON/OFF control, temperature setting, operation display, error display) and can be used with the following systems though it cannot be used in conjunction with other optional controllers for centralized control.

1. Individual control (Each indoor unit is controlled individually.)

This system requires the following parts.


- Adaptor.....
- Remote controller (For operation control).....BRC1E71


(Ex.)When individually controlling 8 units KRP4A74 ×8 kits BRC1E71 ×8 kits


2. Group control (Multiple indoor units are controlled as a group.)

This system requires the following parts.

- Adaptor
- Remote controller (For operation control).....BRC1E71







1P161220-1A

EDUS091617 **Option List**

13.5 <KRP1BA101> Installation Box for Adaptor PCB

Accessories Check the following accessories are included in this kit. Lid of installation box Name Installation box Cord sticker Clamp Screw Installation manual Screw KRP1B101 English KRP1BA101 Englishx1, Japanesex1 x2 Quantity хЗ хЗ **x**3 1 2 3 4 (5) 7 Shape P (This manual)


Method of attaching the adaptor

Attach the adaptor


Attach the adaptor in the installation box (1) by the PCB supports.

(PCB supports are accessories of adaptor.)

• Detach the aluminum tapes of the installation box ① to insert the PCB




- Connect wires with the adaptor before attaching to the installation box ①.
 Low voltage wires and high voltage wires should be kept space at least 50 mm from each other.




Attach the lid of installation box

Attach the lid of installation box ② to indoor unit with two screws. If two adaptors are installed, the second adaptor is attached to side of first one.




Attach the installation box


Attach the installation box ① into the lid of installation box ② with the screw.



Method of wiring processing

• Connect wires with the control box. (Refer to the installation manual attached to the adaptor.)





1P107687-1D

EDUS091617 Option List

13.6 < KRCS01-4B > Remote Sensor

Notes

- Please check applicable kit model name by catalog etc.
- When installed on Skyair Round-flow type models, the dehumidification by detection of humidity does not operate.

Accessories

Check the following accessories.

Name	Remote sensor (sensor box)	Extension cable (2-core, 12m)	Clamp	Installation manual (this drawing)	Mounting screw (M4x16)
Shape	0		3		(b)
Quantity	x 1	x 1	x 2	x 1	x 2

1 Mounting

1) Selection of mounting location.

The thermistor for temperature detection is incorporated into the remote sensor. Select the mounting location taking the following cautions into account.


- (1) Where the average temperature of an air conditioned room can be detected.
- ② Where it is not exposed to the direct sunlight.
- ③ Where it is not influenced by other heat sources.
- 4 Where it is not exposed to the direct discharge air from the air conditioner.
- (5) Where it is not exposed to the outdoor air infiltrated into the room by opening the door.
- 2) Mounting
 - Remove the cover of the sensor box.

about 6mm width flat blade screw driver


- 1) Insert a flat blade screw driver into the sensor box concave part (2 locations).
- 2 Remove the cover pushig up the nail to the cover of the sensor box.

<Cautions>

Do not push the nail powerfully with a narrow flat blade screw driver, because you may break off the nail.




- Break open the knockout hole in the sensor box with a nipper or a similar tool. Pass the extension wires through the hole and fasten the wires to the terminals with screws.
- To avoid tensile force on the terminals, pass the attached clamp through the holes shown in the below right figure and tighten the extension cable with the attached clamp at the sheathed part. (The knot must come to the box inside.)




• Screw the sensor box securely to the wall surface with screws M4x16 (2 places).

If the sensor box cannot be screwed to wall surface, tear off the released paper and mount it on the wall surface.



- Pass the extension cable through the switch box cable hole and carry out the wiring.
- Pass the attached clamp through the clamp holes and tighten the extension cable at the sheathed part as shown in the upper right figure.
- Tap M4 screw holes in the metal plate (field supplied) as shown in the right drawing and mount the switch box on the metal plate.



Holes to be tapped in the metal plate on site (unit: mm)

<Cautions>

- When wiring the extension cable, the air holes will not be blocked.
- When the extension cable is longer than necessary, cut it to the appropriate length, peel the insulation, attach the round crimp terminal for M3 (field supplied) and carry out the wiring. The length of insulation to be peeled off is as shown.
 (Work carefully so that the connector side may not be cut.)



EDUS091617 Option List

2 Wiring method

Connect the extension cable connector side to the indoor unit PCB (printed circuit board) For connection to the indoor unit, follow the procedure shown below.


- 1) Make sure to turn off the power supply before starting the wiring work and do not turn on until all the work is completed. Read also the installation manual and the wiring diagram of the indoor unit when carrying out the work.
- 2) When wiring the extension cable, do not pass where the extension cable may be affected by the power line or noise.
- Make sure to securely connect the connectors.
 Defective connection may result in incorrect detection of room temperature or malfunction.
- 4) Do not splice wires.
- 5) Since the connector marking of the thermistor for detection of inlet air temperature differ depending on the indoor unit type, make sure to check the indoor unit wiring diagram and follow it correctly.
- 6) Lay and clamp the extension cable inside the indoor unit switch box just like the low voltage line (cord for remote controller).
 - And do not pass where the extension cable inside the indoor unit switch box may be affected by the power line (cord for the indoor unit and the other electric line).

<Procedure>

1) When wiring to the indoor unit PCB, remove the existing thermistor (for detection of inlet air temperature) and then connect the extension cable.

When doing this work, make sure to check the symbol of connecting address on the PCB whether it is correct or not referring to the wiring diagram.

<For Skyair and VRV>



2) Lay and clamp the extension cable inside the indoor unit switch box just like the existing thermistor. When doing this work, keep a certain distance between the high voltage wiring and the low voltage wiring to avoid error of sensor.

Provide protection of the existing cable for thermistor without affecting other components.


3) Fit the sensor box cover into the sensor box.

© Operation test after mounting the sensor


Conduct cooling and heating operation test after the sensor is mounted and the wiring is completed.

3K019189-1D

13.7 <BRYQ60A2W(S)> Sensor Kit



EDUS091617 Option List



4P343368-1A

<KDBQ44BA60A> Panel Spacer

- to have 2-way air outlet.
- Refer to the installation manual for both indoor unit and the Panel spacer for its installation.

Caution

Contents of kit

Check if following parts are included with your kit.

Name	Panel spacer frame	Resin corner part	Fixing metal	Screw
Quantity	4 PCS.	4 PCS.	4 PCS.	28 PCS.
Shape · number	0	2	3	M4×12 Tapping screw (Class 2)
Name	Sealing material			
Quantity	2 PCS	2 PCS		


Name	Sealing material			
Quantity	2 PCS.	2 PCS.		
	5	6		
Shape · number				

Preparation of the decoration panel


• Handle the decoration panel with care.

Never place the panel face down, or lean the panel against wall or place on the projective object. (It causes the dent or damage of the surface of the panel or damage of swing motor.)

- (1) Remove the suction grill from the decoration panel.
 (Refer to the installation manual of the decoration panel how to remove.)
- (2) Place the panel face down on the corrugated board or the vinyl sheet to protect the surface of the panel.




Installation of the indoor unit




EDUS091617 Option List


Assembly of panel spacer



4 Fixing to the decoration panel



Adhesion of the sealing material



6 Installation of the decoration panel

Install the decoration panel to the indoor unit according to the installation manual of decoration panel.

The panel spacer is not firmly fixed to the decoration panel, so that never hold the panel spacer directly or lean the decoration panel extremely.

1P107764-1C

13.9 <KDDQ44XA60> Fresh Air Intake Kit

Remarks:

- 1. This kit can be installed to the Ceiling mounted cassette type (Multi-flow).
- 2. When installing this kit, duct (Nominal dia.: φ100) is required on site.
 - In case that metal duct is penetrated through wooden walls, make sure the duct and the wall electrically insulated.
 - Install the duct inclined downwardly to outdoor so that the rain may not get into the duct. (Inclination 1/100 to 1/50)
 - · To avoid birds, small animals or insects getting inside the duct, make sure to install net where it contacts the outside air.

Contents

Prior to installation, make sure you have the complete kit of parts.

Name	① Duct flange	② Screws	③ Insulation for duct flange	4 Insulation for opening of unit	⑤ Installation manual
Q'ty	1 piece	4 pieces	1 piece	1 piece	1 piece
Shape		€ M4×12	Ø		A


Necessary tools

Philips head screw driver, nipper, cutter etc.

Installation procedures of duct flange

1. Cut off the knockout hole on the side plate. (Fig.1)

The knockout hole is opposite to ref. pipe.




EDUS091617 Option List


2. Adhere the insulation 4 for opening of unit to the opening. (Fig. 2)

Put the insulation ④ to be suitable for the hole of the insulation ④ and hole of the indoor unit.

However, put the insulation (4) so as not to conceal the screw hole of the indoor unit.




3. Install the duct flange ① with screws ② (M4×12, 4 screws) to the opening and adhere the insulation ③ (Fig. 3)




Installation procedures of duct <Nominal diameter of duct : φ100>


- 1. Connect the duct to the duct flange. (Flange fits inside the duct.) (Fig. 4)
- 2. After connection, wrap vinyl tape (field supply) around the duct connection to prevent air leak.



Precaution

- · All ducts must be completely insulated.
- · Do not do the followings when installing duct.







C) To reduce the duct diameter

WRONG

WRONG

WRONG

2P108307-1A

13.10 <KPW937E4> Air Direction Adjustment Grille

Component parts Be sure to check that the following parts are included before installation.

Name	① Air direction adjustment grille	② Screw	③ Installation manual
Shape		(3) Managaman	
Q' ty	1 pc.	4 pcs.	1 sheet(this sheet)

Selection of installation site

- Use the air direction adjustment grille for installation at a location that fits the following conditions.
 - 1. When installing the outdoor unit near the neighbouring house.
 - When changing the airflow direction to prevent exhaust blowing directly onto passersby or garden plants.

Cautions for usage


- Be sure to perform the following as installation precautions to ensure correct and safe use of the air direction adjustment grille.
 - 1. Be sure to stop the operation before installation.
 - 2. Avoid short-circuits during installation.
 - 3. When using the unit in areas with snow, install the grille to create a left-right or downward airflow. Do not install the grille to create an upward airflow to prevent snow accumulating in the air outlet of the outdoor unit as this may damage the unit.
 - 4. Be careful of foreign substances such as dead leaves, which may accumulate on the air outlet after installing the grille to create an upward airflow.
 - 5. Do not use screws other than those provided. Tighten the screws securely without any looseness.

Installation of air direction adjustment grille


- Pitch of the installation screws for the air direction adjustment grille(①) is 434mm in the vertical and horizontal directions.
- Installation can be performed in 4 directions: top, bottom, left and right.
- Temporarily secure the air direction adjustment grille(1) using 4 screws(2), check the installation angle, and then tighten the screws.


<Steel wire outlet grille>

1 Remove the 4 outlet grille fixing screws.



EDUS091617 Option List






3P397163-1

13.11 <KPW063A4> Air Direction Adjustment Grille

Component parts) Be sure to check that the following parts are included before installation.

Component parts



(Selection of installation site)


Install only on an outdoor unit in a location that satisfies the following conditions:

- •When installing the outdoor unit near the neighbouring house.
- •Where you wish to change the exhaust airflow direction because the outdoorunit has been installed facing a road, so that passing people are not exposed to its exhaust air
- ●When changing the airflow direction to prevent exhaust blowing directly onto passersby or garden plants.


(Cautions for usage)

- Be sure to perform the following as installation precautions to ensure correct and safe use of he air direction adjustment grille.
 - Install the product so that it is situated high enough to allow access to the outdoor unit for maintenance purposes.
 - When installing the product in a location in which it may be exposed to strong winds, install a rollover prevention bracket (sold separately) at the same time.
 - 3. Tighten screws securely. Failure to do so may result in vibration.


1 Verifying the amount of space required for installation



2 Installation of air direction adjustment grille



Appearance of the air direction adjustment grille after installation (when installed with the louvers facing up)



3P398171-1

13.12 <FTDBHMS, FTDBHML, KEH067A41E, KEH063A4E> Drain Pan Heater

Safety Considerations for Installation of Drain Pan Heater

Read these Safety Considerations carefully before installing the drain pan heater. After completing the installation, check if the unit operates properly during the start-up operation.

Meaning of DANGER, WARNING and CAUTION symbols.

⚠ DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.	⚠ CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate	
⚠ WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.	ZIZ CAUTION	injury. It may also be used to alert against unsafe practices.	

- Inform users that they should store this installation manual for future reference.
- · After completing the installation, make sure that the unit operates properly during the startup operation.
- · All phases of the field-installation, including, but not limited to, electrical, piping, and safety, must be done in accordance with manufacturer's instructions and must comply with national, state, provincial, and local codes.
- . This product is a heater designed to melt snow that is blown into the product from the outside to prevent the drain pan of the outdoor
- . Install the product with a snow-break hood on a high stand if this product is used in heavy snow areas.



· Do not touch the heater unit without wearing gloves.

The temperature of the heater unit will become high when the heater is turned on. Touching the heater unit with bare hands will result in burns or injury.



- · Request the dealer or an authorized technician to install the product.
- Improper installation of the product could result in water leakage, an electric shock, or fire.
- The product must be installed according to the instructions given in this manual.

The Incomplete installation of the product could result in water leakage, an electric shock, or fire

- · Use the supplied or specified installation parts.
- Use of other parts could result in the unit becoming loose and falling, water leakage, electric shock, or fire.
- . Turn off the power supply at the time of installation.

Touching any electrical parts may with the power supply turned on could result in electric shock

- Use specified wires. Connect and fix the wires so that the wires will not put improper force on the terminal junctions. Wires connected or fixed improperly could result in terminal overheating, an electric shock, or fire.
- . When wiring and connecting the indoor and outdoor units, carefully arrange the wiring so that they will not put improper force on the structures.

Install covers over the wires. Incomplete cover installation could result in terminal overheating, an electric shock, or fire.

CAUTION

- Wear protective gloves at the time of installation.
 - Touching the suction mouth or aluminum fin of the outdoor unit may result in injury.
- Do not install the product in places where there is danger of exposure to inflammable gas leakage. If the gas leaks and builds up around the unit, it may catch fire.
- · Do not grab the top plate of the outdoor unit carelessly when removing the top plate.

The sharp edge of the top plate may cause injury.

. Do not install the outdoor unit in places where small animals may nest in the outdoor unit.

If small animals intrude and touch the internal parts of the outdoor unit, the outdoor unit may malfunction, generate smoke, or ignite. Advise the user to keep the place clean

· Do not touch the heater unit with bare hands.

The temperature of the heater unit will become high when the heater is turned on.

Touching the heater unit with bare hands may result in burns or injury.

	KEH067A41E FTDBHMS	KEH063A4E FTDBHML
E Installation manual (multi-language)	1	1
Electric wiring diagram label	1	1
(Information label	1	1

Appearance of the (a) drain pan heater may differ from some models.

Tools Required for Installation

Electric drill

φ1/8 inch (φ3.2mm) drill

· Phillips screwdriver

Nippers

Installation Procedure (1)

♠ WARNING

. Be sure to check that the power supply of the product is turned off.

Some stages in the installation procedure differ by model of outdoor unit. Refer to the instructions for the relevant model.

Type A models : RX09/12, RXN09/12, RXL09/12

Type B models : RX18/24, RXN18/24, RXL15


Type C models : 2/3/4MXS, 2/3MXL

Remove each component of the outdoor unit.

- 1) Remove the top plate.
- Affix the (F) electric wiring diagram label where there is enough space available on the back of the top plate.
- Remove the screws from the protective wire mesh if one is fitted. (2 screws) (For type B and C models only)
- 4) Remove the front plate.
- 5) Remove the anti-drip cover. (For type B and C models only)
- The appearance of the outdoor unit and the number of screws may differ from some models
- Screw types for each component are indicated as below.

No icon: Hexagon tapping screw


△ : Truss head tapping screw



Installation Procedure (2)

Remove the fan motor base.

- 1) Remove the fixing screws at the lower section of the fan motor base. (2 screws)
- Remove the fan motor base together with the propeller fan and ensure that stress is not placed on the propeller fan when placing them aside.
 - · Do not remove the fan motor harness.
 - Ensure that the fan motor harness does not come into contact with the edges of the heat exchanger or other components.




3. Install the drain pan heater.

⚠ CAUTION

. When drilling a hole, be careful not to damage the soundproofing material and other components on the back side.

For details, refer to "Installation Procedure (3)" also.

- Remove 1 screw from the bottom frame so that the plates of the A drain pan heater can be inserted under the heat exchanger with ease.
- 2) Lift up the heat exchanger, and insert the plates of the (A) drain pan heater under the heat exchanger.
 - The ground plate of the (a) drain pan heater should be installed so that, in type A models, it firmly adheres to the bottom frame and, in type B and C models, it firmly adheres to the partition plate.
 - Install the (a) drain pan heater in a position where it does not come into contact with the fan motor base.
- - · Place the actual components to ensure positioning is correct before drilling holes.
 - · The holes can be made with the included piercing-screw as well.
- 4) Fix the (A) drain pan heater with the (B) piercing screws.
- 5) Reattach the screw that was removed from the bottom frame.



Installation Procedure (4)


4. Route the harnesses.

MARNING

· When drilling a hole, be careful not to damage the soundproofing material and other components on the back side.


For type A models

- 1) If there is no hole, drill a \$1/8 inch (\$3.2mm) hole in the partition plate. (1 location)
- 2) Fix in place the binding band attached to the (A) drain pan heater harness by screwing the (B) M4 piercing screw into the hole. (1 location)
- 3) Install the fan motor base.
 - . Be careful not to confuse screw types. Refer to "Installation Procedure (2)".
- 4) Place the (a) drain pan heater harness on top of the fan motor harness, and fix it in place with the (a) sealing material.



For type B and C models


- 1) If there are no holes, drill ϕ 1/8 inch (ϕ 3.2mm) holes in the partition plate. (3 locations)
- 2) Fix the (A) drain pan heater harness in place by screwing the (B) M4 piercing screws into the holes. (3 locations)
- 3) Install the fan motor base.
 - Be careful not to confuse screw types. Refer to "Installation Procedure (2)".
- 4) Trim the electrical wiring box with nippers at the locations shown in the figures, then cover the trimmed edges with the ① sealing material.
- 5) Insert the (A) drain pan heater harness into the space that was trimmed, and fix it in place using the (D) sealing material.





Installation Procedure (5)

Connect the faston terminals of the drain pan heater to the terminal block of the outdoor unit.

- Connect the thermostat-side terminal (black harness) to the leftmost terminal and the heater-side terminal (white harness) to the second leftmost terminal.
 - . For type C models, connect to the last terminal block of the terminal blocks in use.
- 2) Bundle the (A) drain pan heater harness so that there is no slack, and secure it with the (C) binding band. (1 location)
 - . Cut the tip of the @ binding band.








6. Install each component to the original position.


- · Be careful not to confuse screw types. Refer to "Installation Procedure (1) ".
 - 1) Install the front plate.
 - 2) Install the anti-drip cover. (For type B and C models only)
 - 3) Install the top plate.


3P421082-1

13.13 < KPS067A41> Snow Hood (Intake Side Plate)




1 Installing the snow hood (intake side plate)






Appearance of the snow hood (intake side plate) following installation





3P436077-1

13.14 <KPS067A42> Snow Hood (Intake Rear Plate)




Installing the snow hood (intake rear plate)






Appearance of the snow hood (intake rear plate) following installation



3P436078-1

13.15 **KPS067A44> Snow Hood (Outlet)**

Parts Before assembling the product, verify that all of the following parts have been included:



⚠ Caution Read these safety considerations for installation carefully before installing the product,


- ◆Be sure to observe the following installation precautions to ensure that the product can be used safely:

 Install the product so that it is situated high enough to allow access to the outdoor unit for maintenance.
- Installing the product in a location in which it may be exposed to strong winds, secure the outdoor unit with wire or other means.
- 3. Choose a location where the operating sound will not cause a nuisance to the neighbors of the user.


4. Tighten screws securely. Failure to do so may result in vibration.

▲ Caution • • • • Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practises,


1 Installing the snow hood (outlet)



1. Remove the 4 screws that hold the discharge grille, then remove the discharge grille.




② Appearance of the snow hood (outlet) after installation



3P436079-1

13.16 < KPS063A41 > Snow Hood (Intake Side Plate)




⚠ Caution Read these safety considerations for installation carefully before installing the product,

- ⊕Be sure to observe the following installation precautions to ensure that the product can be used safely:
- Install the product so that it is situated high enough to allow access to the outdoor unit for maintenance,
 Installing the product in a location in which it may be exposed to strong winds, secure the outdoor unit with wire or other means.
- 3. Choose a location where the operating sound will not cause a nuisance to the neighbors of the user.
- 4. Tighten screws securely. Failure to do so may result in vibration.


A Caution • • • •
Indicates a potentially hazardous
situation which, if not avoided, may
result in minor or moderate injury,
It may also be used to alert against
unsafe practises.

1 Installing the snow hood (intake side plate)




- 1. Remove the 2 screws that hold the protective wire mesh.
- 2. Remove the 6 screws that hold the top plate and remove the top plate.
- Remove the protective wire mesh, being careful of the part that is attached to the heat exchanger.
- 4. Attach the top plate removed in step 2 using the 6 screws removed in step 2.

2 Attach the side plate (right) 1




- Install the side plate (right) ① with the 2 screws that were used in the protective wire mesh that was removed in step 1 .
 - Use the second hook slot from the top and the 2 screw hole from the bottom.
 - Installation is easiest if you start with the hook slot.


Screw hole



 Install the side plate (left) ② with the 2 screws that were used in the protective wire mesh that was removed in step 1.


- Use the second hook slot from the top and the 2 screw hole from the bottom.
- Installation is easiest if you start with the hook slot.






1. Temporarily secure the front plate 4 in place with the 4 screws(5),






- 1. Attach the top plate 3 with the 6 screws 5.
- 2. Temporarily secure the top plate ③ and the front plate ④ to the side plate (right) ① and the side plate (left) ② with the 2 screws⑤.
- 3. Tighten the 12 screws (5) that you used to temporarily secure parts in steps 4 and (5).

②Appearance of the snow hood (intake side plate) after installation)



3P436071-1

13.17 <KPS063A44> Snow Hood (Intake Rear Plate)




⚠ Caution Read these safety considerations for installation carefully before installing the product,

- ●Be sure to observe the following installation precautions to ensure that the product can be used safely:
- Install the product so that it is situated high enough to allow access to the outdoor unit for maintenance,
 Installing the product in a location in which it may be exposed to strong winds, secure the outdoor unit with wire or other means.
- 3. Choose a location where the operating sound will not cause a nuisance to the neighbors of the user.
- 4. Tighten screws securely. Failure to do so may result in vibration.


A Caution - - - Indicates a potentially hazardous
situation which, if not avoided, may
result in minor or moderate injury.
It may also be used to alert against
unsafe practises.

Installing the snow hood (intake rear plate)




- 1. Use the 3 piercing screws @included in the kit to install the side plate (right) ①.
 - For the hook slot, use the first hook slot from the top.
 - For the screw hole, use the first screw hole from the bottom.
 - Installation is easiest if you start with the hook slot.
 - Align the screw installation position with the dowel hole.


2 Attach the side plate (left) 2



- 1. Remove the 2 screws (☆) that hold the heat exchanger.
- 2. Install the side plate (left) ② using the 2 screws removed in step 1.




Appearance of the snow hood (intake rear plate) after installation





3P436072-1

13.18 **<KPS063A47> Snow Hood (Outlet)**




Installing the snow hood (outlet)





Appearance of the snow hood (outlet) after installation



3P436073-1





- Warning Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
 - Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
 - Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

- 1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
- 2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.